

HF/VHF/UHF ALL MODE TRANSCEIVER

FT-991

OPERATING MANUAL



ABOUT THIS MANUAL . . .

The **FT-991A** is a leading-edge transceiver with a number of new and exciting features, some of which may be unfamiliar to you. In order to gain the most enjoyment and operating efficiency from your **FT-991A**, we recommend that you read this manual in its entirety, and keep it handy for reference as you explore the many capabilities of your new transceiver.

Before using your **FT-991A**, be sure to read and follow the instructions in the "Before You Begin" section of this manual.

About TFT Displays

FT-991A utilizes a TFT liquid-crystal display.

- Although TFT liquid-crystal displays are made using very precise technology, they are prone to develop dead pixels (dark dot) or pixels that are always on (bright dot). Please understand that such phenomena do not constitute product defects or malfunctions. Rather, this phenomena occurs due to limitations in the manufacturing technology with respect to TFT liquid-crystal displays.
- Depending on the viewing angle, unevenness in color or brightness may occur. Please note that any unevenness observed is inherent to the construction of TFT liquid crystal displays and therefore does not constitute a product defect or malfunction.
- If your TFT liquid-crystal display becomes dirty, please use a dry soft cloth or tissue to wipe the display clean. Use of glass cleaner, household cleaners, organic solvents, alcohol, abrasives, and/or like substance may damage the TFT liquid-crystal display.

Built-in high-brightness TFT full-color display with touch-panel functionality

The **FT-991A** is equipped with a 3.5 inch full-color TFT display. Functions, including the receiving band, the noise and signal interference reduction tools are graphically displayed. Even while performing rigorous operations, during DX pditions or contests, the operator may instantly grasp the status of each function.

Equipped with C4FM digital mode

This transceiver C4FM mode provides good error correction performance, and supports the V/D mode (voice/ data simultaneous transmission mode) which makes the transceiver suitable for mobile communication, and the Voice FR mode (voice full rate mode) which allows the transceiver to transmit high quality digital audio. The AMS function recognizes the contacting stations transmission method and automatically switches the transceiver to the same C4FM digital or analog (FM) communications mode as the received signal.

DG-ID (Digital Group ID) feature, the Group Monitor (GM) feature enables automatically locating, and communicating with other stations that have the same DG-ID number within contact range.

The two-digit DG-ID numbers (00 to 99) can be set separately for Transmit and Receive. By setting both transmit and receive to "00", communication with all the other stations in the digital C4FM mode is possible, regardless of their DG-ID number setting. Matching the transmit DG-ID number to the uplink DG-ID number set in the DR-2X System Fusion II digital repeater, will permit access to the digital repeater DR-2X used by the club.

DP-ID (Digital Personal ID) feature may communicate only by the transceivers registered the individual ID information.

Every C4FM digital transmit communication contains the individual ID information (Radio ID) of each transceiver. The DP-ID function uses this individual ID information. When the DP-IDs of the transceiver are registered with each other, they can communicate even if the DG-ID numbers are different. By registering the DP-ID of the transceiver to the DR-2X System Fusion II digital repeater, the digital repeater may be controlled by remote operation.

GM (group monitor) function automatically inquires to find if there are any stations with the GM function in operation on the same frequency within communication range. The members may then automatically exchange (send/ receive) station location information. The transceiver automatically checks the channel frequency for registered member stations that are within communicating range. The distance and direction information of the call sign members of the group may be shown on the TFT display.

Comes equipped with two types of roofing filters

This transceiver is equipped with two types of roofing filters for 3 kHz and 15 kHz bandwidths. These narrow band filters are especially useful on a very crowded band during contests, because they can dramatically attenuate powerful out-of-band signals in the first IF stage and reduce their impact in the second stage to further optimizing the excellent dynamic range and IP3 characteristics for processing signals ranging from faint to powerful.

Two selectable RF amplifiers provide the optimal receiver gain for each low-to high HF band (see page 48.)

Configure the front end RF circuitry for the precise gain and performance to suit the conditions of each HF band.Select the IPO (Intercept Point Optimization) feature to optimize the proximal multi-signal and mutual modulation characteristics in order to minimize the effects of powerful broadcast stations, especially in the low-band so that even the faintest signals can be received. When higher gain is advantageous, select the single low noise RF amplifier AMP1. In the high bands, adding AMP2 provides maximum useful gain.

High stability built-in TCXO

The 30.225 MHz standard oscillator provides exceptional frequency stability. It is temperature compensated and boasts an enhanced ± 0.5 ppm stability from -10° C to $+50^{\circ}$ C.

WIDTH feature and continuously variable bandwidth SHIFT feature. Optimal wide to narrow bandwidth switching (see pages 51, 52.)

The SHIFT feature, can eliminate interference in one side of the passband. The WIDTH feature allows the bandwidth to be narrowed by rotating the WIDTH knob. The moment weak signals disappear due to interfering signals (including pile-ups), you can eliminate the interfering signals and extract only the desired signal, thanks to the unique DSP sharp filtering characteristic.

CONTOUR feature is renowned for effective noise control (see page 50.)

Rather than using the DSP extremely sharp attenuation characteristics, the CONTOUR circuit provides gentle shaping of the DSP passband filter and can thus attenuate or peak bandwidth components in segments. The interfering signal can be naturally shaped without having part of the signal suddenly interrupted. The contour function is very effective in making the desired signal rise out of the interference.

General Description

DNR (Digital Noise Reduction) by DSP digital processing (see page 56.)

The incorporated digital noise reduction circuit may be set to the optimal working point by varying the 15 step parameters according to the noise type.

NOTCH feature that significantly eliminates unwanted beat signals; and DNF feature that instantly attenuates multiple beat signals (see page 56.)

When interfering beat signals are present in the receiver passband, the IF NOTCH feature can significantly eliminate a part of the passband and remove the beat signal. Moreover, the function is equipped with an Automatic Tracking System DNF (Digital Notch Filter) that can be engaged by DSP when there are multiple interfering signals, even when the frequency is changing.

Reliable High-output Final Amplifier Stage

In the HF/50MHz frequency range, a pair of RD100HHF1 transistors in a push-pull RF amplifier arrangement delivers 100 watts of low-distortion, high-quality transmitter power. The final amplifier for the 144 MHz/430 MHz bands uses the high-output RDH70HUF2 device, providing ample output power of 50 watts.

Microphone Amplifier that includes Parametric Equalizer (see page 65.)

The microphone amplifier equalizer feature is equipped with a three-stage parametric equalizer that can alter the Low, Mid, and High frequencies of the audio separately; this feature permits the bandwidth and gain for each part of the audio spectrum to be precisely adjusted independently.

Real-Time Spectrum Scope and Multi-Color Waterfall Display (see page 42.)

The spectrum scope function provides a visual display of the strength and distribution of signals across the band in real time. The Waterfall Display Mode portrays color differentiation between strong and weak signals.

High speed antenna tuner (see page 63.)

The transceiver is equipped with the relay switching high speed digital tuner which supports 1.8 MHz to 50 MHz. The large 100-channel tuning data memory allows immediate recall of the optimum matching conditions for previously tuned frequencies.

Optional Five Channel Message Memory (voice memory) (see page 70.)

You can use the 5 channel voice memory function which is useful for operating in contests, etc. This voice memory enables recording of up to 20 seconds of audio for each message you want to send.

Custom selection (C.S) button (see page 39.)

This feature lets you select any Menu item for one-touch access via the **C.S** button.

TABLE OF CONTENTS

General Description	1
Table of Contents	3
Safety Precautions	5
Accessories & Options	7
Supplied Accessories	7
Available Options	8
Before You Begin	9
Base Station Wire Stand	9
Adjusting the Main Tuning Dial Torque	9
Adjusting the Clock	10
Inputting the Call Sign	11
Resetting the Microprocessor	12
Antenna Considerations	13
About Coaxial Cable	13
Grounding	14
Connection of Antenna and Power Cables	15
Installation and Interconnections	16
Connection of Microphone, Headphone and	
Remote Control Keypad	16
Key, Keyer, and Computer-Driven Keying	1.7
Interconnections	[7]
VL-1000 Linear Amplifier Interconnections	18
Plug/Connector Pinout Diagrams	19
Front Panel Controls & Switches	20
About the Display	24
TFT Liquid Crystal Display	24
LED Indicators	26
Rear Panel	27
MH-31A8J Microphone Switches	29
Optional MH-36E8J Microphone Switches.	31
Basic Operation: Receiving on Amateur Bands	s32
Operation on 60-Meter (5 MHz) Band	
(U.S. and U.K. version only)	35
CLAR (Clarifier) Operation	36
LOCK	
DIMMER	
VFO COLOR	38
Convenience Features	39
Band Stack Operation	39
C.S (Custom Switch)	39
AMS (Automatic Mode Select) Operation	40
SCOPE	42
More Frequency Navigation Techniques	44
Receiver Operation (Front End Block Diagram)	40
Interference Rejection	47
Al I (Attenuator)	/ 4/ / 9/
IF Noise Planker (ND) Operation	4 0 40
11 INDISE DIALIKET (IND) Operation	49 50
IF SHIFT Operation	
(SSB/CW/RTTY/DATA Modes)	51

1	WIDTH (IF DSP Bandwidth) Tuning
3	(SSB/CW/RTTY/DATA Modes)52
5	NARROW (NAR) One-Touch IF Filter Selection54
7	IF NOTCH Filter Operation
7	(SSB/CW/RTTY/DATA/AM Modes)55
, 8	Digital NOTCH Filter (DNF) Operation56
0	Digital Noise Reduction (DNR) Operation56
9	Tools for Comfortable and Effective Reception 57
9	RF Gain57
0	Audio Peak Filter
1	AGC (Automatic Gain Control)
2	Adjustable Receiver Audio Filter60
3	SSB/AM Mode Transmission61
3	Using the Automatic Antenna Tuner63
4	ATU Operation63
5	About ATU Operation64
6	Enhancing Transmit Signal Quality65
	Parametric Microphone Equalizer
6	(SSB/AM mode)65
	Using the Speech Processor (SSB Mode)
7	Adjusting the SSB Transmitted Bandwidth
8	(SSB Mode)
9	Transmitter Convenience Features
0	Voice Memory (SSB/AM modes)
4	VOX (SSB/AM/FM Modes: Automatic
4	A NONITOR (SSD/AM modes) 74
6	MUNITOR (SSB/AM modes)
7	Split-Frequency Operation 76
9	CW Made On emotion 70
1	Cw Mode Operation
2	emulation) Operation 78
	Using the Built-in Electronic Kever 80
5	CW Convenience Festures 84
6	CW Spotting (Zero-Beating)
7	CW Delay Time Setting
7	CW Pitch Adjustment
8	Contest Memory Keyer
9	FM Mode Operation
9	Basic Operation
9	Repeater Operation
0	DCS Operation
2	Tone Squelch Operation96
4	C4FM Mode (Digital Mode) Operation97
-	DG-ID/DP-ID Features
7 7	Digital Group ID (DG-ID) feature
/ 8	Digital Personal ID (DP-ID) feature101
0	Memory Operation
ፆ በ	Convenient Memory functions
0	QMB (Quick Memory Bank)103
1	Standard Memory Operation104
	Memory Groups110

TABLE OF CONTENTS

Operation on Alaska Emergency Frequency:
5167.5 khz (U.S. Version Only) 112
VFO and Memory Scanning 113
VFO Scanning 113
Memory Scan114
PMS (Programmable Memory Scanning) 115
Using the GPS Function116
What is GPS?116
Positioning Using GPS116
Displaying the Position Information118
Using the GM / WIRES-X Function 119
What is the GM Function? 119
Basic Methods to Use the GM Function 119
What is the WIRES-X Function? 119
RTTY (Radio Teletype) Operation 120
Example of Connecting
RTTY Communications Device
DATA (PSK) Operation
Example of Data Communications Device 122
Menu Mode124
Installation of Optional Accessories
Wire Antenna)
Active-Tuning Antenna System (ATAS-120A)
Operation
Mounting Bracket MMB-90 Installation147
Specifications148
Index150

Safety Precautions

Note beforehand that the company shall not be liable for any damages suffered by the customer or third parties in using this product, or for any failures and faults that occur during the use or misuse of this product, unless otherwise provided for under the law.

Type and meaning of the marks

	DANGER	This symbol indicates the possibi	lity of o	death c	or serious injury being inflicted on the user and the
	WARNING	This symbol indicates the possibi surrounding people when these in	lity of o	death c	or serious injury being inflicted on the user and the eignored and the product is mishandled.
Â	CAUTION	This symbol indicates the possibi flicted on the user and the surroun is mishandled.	lity of p ding p	ohysica eople v	al impediments occurring or impediments being in- when these instructions are ignored and the product
Туре	and meaning o	of symbols			
\bigcirc	Prohibited action For example, 🔇	ns that must not be attempted, in o) signifies that disassembly is proh	rder to ibited.	use th	is radio safely.
0	Precautions that is to be disconne	must be adhered to in order to use ected.	this ra	dio saf	ely. For example, 🚭 signifies that the power supply
			AN	GER	
\bigcirc	Do not use the and vehicles w as in hospitals This may exert a cal devices.	e device in "regions or aircrafts here its use is prohibited" such and airplanes. an impact on electronic and medi-		\bigcirc	Do not operate the device when flammable gas is generated. Doing so may result in fire and explosion.
\Diamond	Do not use this a motorbike. T Make sure to si before use if th the driver.	s product while driving or riding his may result in accidents. top the car in a safe location first le device is going to be used by		\bigcirc	When an alarm goes off with the external an- tenna connected, cut off the power supply to this radio immediately and disconnect the ex- ternal antenna from this radio. If not, this may result in fire, electric shock and equipment failure.
\Diamond	Do not transm eration of peo devices such a Electromagnetic fect the medica caused by malfu	it in crowded places in consid- ple who are fitted with medical as heart pacemakers. c waves from the device may af- al device, resulting in accidents unctions.		\bigcirc	Do not touch any liquid leaking from the liquid display with your bare hands. There is a risk of chemical burns occurring when the liquid comes into contact with the skin or gets into the eyes. In this case, seek medical treat- ment immediately.
\bigcirc	Never touch th This may result ment failure.	e antenna during transmission. in injury, electric shock and equip-			
_		<u> </u>	ARN	INC	3
					When smoke or strange odors are emitted
\bigcirc	Do not use vo power supply Doing so may re	Itages other than the specified voltage. esult in fire and electric shock.			from the radio, turn off the power and discon- nect the power cord from the socket. This may result in fire, liquid leak, overheating,
\bigcirc	Do not transmi of time. This may cause	the temperature of the main body			damage, ignition and equipment failure. Please contact our company customer support or the re- tail store where you purchased the device.
	overheating. Do not disman This may result	tle or modify the device. in injury, electric shock and equip-		0	ing areas clean at all times. This may result in fire, liquid leak, overheating, breakage, ignition etc.
\odot	ment failure. Do not handle etc. with wet h plug the power This may result	the power plug and connector ands. Also do not plug and un- r plug with wet hands. in injury, liquid leak, electric shock			Disconnect the power cord and connection cables before incorporating items sold sepa- rately and replacing the fuse. This may result in fire, electric shock and equip- ment failure.
\bigcirc	Do not use fus Doing so may re	es other than those specified. esult in fire and equipment failure.		\bigcirc	Never cut off the fuse holder of the DC power cord. This may cause short-circuiting and result in ignition and fire.

SAFETY PRECAUTIONS

\bigcirc	Do not allow metallic objects such as wires and water to get inside the product. This may result in fire, electric shock and equip- ment failure.		\bigcirc	Refrain fr phones at Continuous in hearing
\bigcirc	Do not place the device in areas that may get wet easily (e.g. near a humidifier). This may result in fire, electric shock and equip- ment failure.			Do not us and conn when the plugged in
0	When connecting a DC power cord, pay due care not to mix up the positive and negative polarities. This may result in fire, electric shock and equip-			Please cor the retail s as this may ment failur
\bigcirc	Do not use DC power cords other than the one enclosed or specified. This may result in fire, electric shock and equip-		\bigcirc	Follow the items sold This may r ment failur
\bigcirc	ment failure. Do not bend, twist, pull, heat and modify the power cord and connection cables in an un- reasonable manner. This may cut or damage the cables and result in fire, electric shock and equipment failure.		\bigcirc	Do not us off. For safety the DC por uct out of t Never touc
\bigcirc	Do not pull the cable when plugging and un- plugging the power cord and connection ca- bles. Please hold the plug or connector when unplug- ging. If not, this may result in fire, electric shock and equipment failure.			to thunder.
_		AUT	TION	1
\bigcirc	Do not place this device near a heating instru- ment or in a location exposed to direct sun-			For safety pull out the
\bigcirc	This may result in deformation and discoloration.			going to b
\odot	This may result in deformation and discoloration. Do not place this device in a location where there is a lot of dust and humidity. Doing so may result in fire and equipment failure.			going to b If not, this Do not the impact for
\odot	This may result in deformation and discoloration. Do not place this device in a location where there is a lot of dust and humidity. Doing so may result in fire and equipment failure. Stay as far away from the antenna as possible during transmission. Long-term exposure to electromagnetic radiation may have a negative effect on the human body.			going to b If not, this Do not the impact for This may r Do not the and video The data ir
	This may result in deformation and discoloration. Do not place this device in a location where there is a lot of dust and humidity. Doing so may result in fire and equipment failure. Stay as far away from the antenna as possible during transmission. Long-term exposure to electromagnetic radiation may have a negative effect on the human body. Do not wipe the case using thinner and ben- zene etc. Please use a soft and dry piece of cloth to wipe away the stains on the case.			going to b If not, this Do not the impact for This may r Do not the and video The data ir be erased. Do not pl sloping su is a lot of
	This may result in deformation and discoloration. Do not place this device in a location where there is a lot of dust and humidity. Doing so may result in fire and equipment failure. Stay as far away from the antenna as possible during transmission. Long-term exposure to electromagnetic radiation may have a negative effect on the human body. Do not wipe the case using thinner and ben- zene etc. Please use a soft and dry piece of cloth to wipe away the stains on the case. Keep out of the reach of small children. If not, this may result in injuries to children.			going to b If not, this Do not the impact for This may r Do not the and video The data in be erased. Do not pl sloping su is a lot of The device injury and Do not sta
	This may result in deformation and discoloration. Do not place this device in a location where there is a lot of dust and humidity. Doing so may result in fire and equipment failure. Stay as far away from the antenna as possible during transmission. Long-term exposure to electromagnetic radiation may have a negative effect on the human body. Do not wipe the case using thinner and ben- zene etc. Please use a soft and dry piece of cloth to wipe away the stains on the case. Keep out of the reach of small children. If not, this may result in injuries to children. If not, this may result in injuries. This may damage the power cord and connection cables, resulting in fire and electric shock.			going to b If not, this Do not the impact for This may r Do not the and video The data ir be erased. Do not pl sloping si is a lot of The device injury and Do not sta place hea inside it. If not, this
	This may result in deformation and discoloration. Do not place this device in a location where there is a lot of dust and humidity. Doing so may result in fire and equipment failure. Stay as far away from the antenna as possible during transmission. Long-term exposure to electromagnetic radiation may have a negative effect on the human body. Do not wipe the case using thinner and ben- zene etc. Please use a soft and dry piece of cloth to wipe away the stains on the case. Keep out of the reach of small children. If not, this may result in injuries to children. If not, this may result in injuries to children. This may damage the power cord and connection cables, resulting in fire and electric shock. Do not transmit near the television and radio. This may result in electromagnetic interference.			going to b If not, this Do not the impact for This may r Do not the and video The data in be erased. Do not pl sloping su is a lot of The device injury and Do not sta place hea inside it. If not, this Do not us specified
	This may result in deformation and discoloration. Do not place this device in a location where there is a lot of dust and humidity. Doing so may result in fire and equipment failure. Stay as far away from the antenna as possible during transmission. Long-term exposure to electromagnetic radiation may have a negative effect on the human body. Do not wipe the case using thinner and ben- zene etc. Please use a soft and dry piece of cloth to wipe away the stains on the case. Keep out of the reach of small children. If not, this may result in injuries to children. If not, this may result in injuries to children. This may damage the power cord and connection cables, resulting in fire and electric shock. Do not transmit near the television and radio. This may result in electromagnetic interference. Do not use optional products other than those specified by our company.			going to b If not, this Do not the impact for This may r Do not the and video The data ir be erased. Do not pl sloping si is a lot of The device injury and Do not sta place hea inside it. If not, this Do not us specified the device If not, this Do not tou
	This may result in deformation and discoloration. Do not place this device in a location where there is a lot of dust and humidity. Doing so may result in fire and equipment failure. Stay as far away from the antenna as possible during transmission. Long-term exposure to electromagnetic radiation may have a negative effect on the human body. Do not wipe the case using thinner and ben- zene etc. Please use a soft and dry piece of cloth to wipe away the stains on the case. Keep out of the reach of small children. If not, this may result in injuries to children. If not, this may result in injuries to children. This may damage the power cord and connection cables, resulting in fire and electric shock. Do not transmit near the television and radio. This may result in electromagnetic interference. Do not use optional products other than those specified by our company. If not, this may result in equipment failure. When using the device in a hybrid car or fuel- saving car, make sure to check with the car manufacture before using			going to b If not, this Do not the impact for This may r Do not the and video The data in be erased. Do not pl sloping su is a lot of The device injury and Do not sta place hea inside it. If not, this Do not tou specified the device If not, this Do not tou When used ture of the sulting in b
	This may result in deformation and discoloration. Do not place this device in a location where there is a lot of dust and humidity. Doing so may result in fire and equipment failure. Stay as far away from the antenna as possible during transmission. Long-term exposure to electromagnetic radiation may have a negative effect on the human body. Do not wipe the case using thinner and ben- zene etc. Please use a soft and dry piece of cloth to wipe away the stains on the case. Keep out of the reach of small children. If not, this may result in injuries to children. If not, this may result in injuries to children. This may damage the power cord and connection cables, resulting in fire and electric shock. Do not transmit near the television and radio. This may result in electromagnetic interference. Do not use optional products other than those specified by our company. If not, this may result in equipment failure. When using the device in a hybrid car or fuel- saving car, make sure to check with the car manufacturer before using. The device may not be able to receive transmis- sions normally due to the influence of noises from the electrical devices (inverters etc.) fitted in the car.			going to b If not, this Do not the impact for This may r Do not the and video The data ir be erased. Do not pl sloping si is a lot of The device injury and Do not sta place hea inside it. If not, this Do not tou specified the device If not, this Do not tou when used ture of the sulting in b Do not op when repl items sold This may r ment failur

rom using headphones and eara loud volume. s exposure to loud volumes may result impairment. se the device when the power cord nection cables are damaged, and DC power connector cannot be n tightİy. ntact our company customer support or store where you purchased the device y result in fire, electric shock and equipe. e instructions given when installing d separately and replacing the fuse. result in fire, electric shock and equipe. se the device when the alarm goes reasons, please pull the power plug of wer equipment connected to the prodthe AC socket. ch the antenna as well. This may result ctric shock and equipment failure due

	For safety reasons, switch off the power and pull out the DC power cord connected to the DC power connector when the device is not going to be used for a long period of time. If not, this may result in fire and overheating.
0	Do not throw or subject the device to strong impact forces. This may result in equipment failure.
0	Do not the put this device near magnetic cards and video tapes. The data in the cash card and video tape etc. may be erased.
\bigcirc	Do not place the device on an unsteady or sloping surface, or in a location where there is a lot of vibration. The device may fall over or drop, resulting in fire, injury and equipment failure.
\bigcirc	Do not stand on top of the product, and do not place heavy objects on top or insert objects inside it. If not, this may result in equipment failure.
\bigcirc	Do not use a microphone other than those specified when connecting a microphone to the device. If not, this may result in equipment failure.
\bigcirc	Do not touch the heat radiating parts. When used for a long period of time, the tempera- ture of the heat radiating parts will get higher, re- sulting in burns when touched.
\bigcirc	Do not open the case of the product except when replacing the fuse and when installing items sold separately. This may result in injury, electric shock and equip- ment failure.

ACCESSORIES & OPTIONS

SUPPLIED ACCESSORIES



DC Power Cord







Spare	Fuse	(25A)	

Operating Manual Warranty Card World Map Sticker

The illustrations above may vary slightly from the actual accessories.

AVAILABLE OPTIONS

□ For details, see "Installation of Optional Accessories" on page 143 or the catalog.







Lightweight Stereo Headphone YH-77STA



Remote Control Keypad FH-2



Linear Amplifier/AC Power Supply VL-1000/VP-1000



External Automatic Antenna Tuner FC-40

Others Hand Microphone DTMF Hand Microphone Dual Element Microphone Ultra-High-Fidelity Desktop Microphone Desktop Microphone Active Tuning Antenna (Automatic Type) Antenna Base Kit Active Tuning Antenna (Manual Type) Mobile Bracket External Power Supply (13.8 VDC 23 A) External Power Supply (13.8 VDC 25 A) **VL-1000** Linear Amplifier Connection Cable Packet Interface Cable

MH-31A8J (equivalent to the supplied microphone) MH-36E8J M-100 MD-200A8X MD-100A8X ATAS-120A ATAS-120A ATBK-100 ATAS-25 MMB-90 FP-1023A (U.S.A. only) FP-1030A CT-58 CT-39A

BASE STATION WIRE STAND

The heavy wire stand on the bottom of the transceiver allows the transceiver to be tilted upward for better viewing. Simply fold the stand forward to raise the front of the transceiver, and fold it back against the bottom case to lower the front of the **FT-991A**.



Adjusting the Main Tuning Dial Torque

The torque (drag) of the Main Tuning Dial knob may be adjusted according to your preferences. Rotate the skirt at the base of the knob clockwise to reduce the drag, or counter-clockwise to increase the drag.



ADJUSTING THE CLOCK

Use the following procedure to adjust the clock shown at the top right of the LCD display.

- 1. Press and hold the **MENU(SETUP)** button.
- 2. Touch [**TIME/DATE**] on the LCD.



3. Enter the present time with the number keys on the LCD, then touch [**ENT**].



4. Touch [**DATE**] on the LCD to switch the screen.



5. Enter month, day, and year with the number keys on the LCD, then touch [**ENT**].



- 6. Touch [**BACK**] on the LCD to return to the setup mode display.
- 7. Press the **MENU(SETUP)** button to return to the radio operation display.



<i>vfo-A USB MIC-G</i>	<u>14</u> .	19	09:40 z
DAT	E 10,	/30/20	14
1	2	3	TIME
4	5	6	DATE
7	8	9	DST
BACK	0	CE	ENT

[TIME]

Sets the time display. Touching this button toggles between UTC (Coordinated Universal Time) and the local time. When UTC is displayed, "**Z**" appears on the right side of the time.

Note:

The user may decide the time preference.

The Local or UTC time must be set manually; the time does not adjust automatically when the setting is switched between Local and UTC time.

Only the "Z" indicator for UTC is changed.

[DATE]

Sets the date display. Touching this button toggles between MM/DD/YYYY and YYYY/MM/DD.

[DST]

Touching this button switches daylight saving time between ON and OFF. When daylight saving time is set to on, " \mathbf{D} " appears on the right side of the time.

INPUTTING THE CALL SIGN

When turning on the power for the first time after purchase, or after resetting the transceiver, enter your own call sign.

The call sign will be displayed on the start screen when turning on the power and will be used to identify the station when sending messages during digital communication.

- 1. Press and hold the **MENU(SETUP)** button.
- 2. Touch [**MY CALL**] on the LCD.





ADVICE:

The time duration of the initial call sign start up screen display may be changed from the Menu item "OO5 MY CALL INDICATION".

3. Touch a character key. The touched character will be displayed at the top of the screen. Enter each character of your call sign.



ADVICE:

- □ Up to 10 characters (letters, numbers, and symbols) can be entered.
- 4. Touch **[ENT]** on the LCD. The call sign setting is completed and the display will switch to the frequency display screen.



Resetting the Microprocessor

RESETTING MEMORIES (ONLY)

Use this procedure to reset (clear) the previously stored Memory channels, without affecting any configuration changes you may have made to the Menu settings.

- 1. Press the front panel **ON/OFF** switch to turn the transceiver off.
- While holding the A►M button in, press and hold in the front panel ON/OFF switch to turn the transceiver on. Once the transceiver comes on, you may release the buttons.

Note:

The **FT-991A** cannot erase the memory channels "O1" (and "5-O1" through "5-10": U.S. version).

MENU RESETTING

Use this procedure to restore the Menu settings to their factory defaults, without affecting the programmed memories.

- 1. Press the front panel **ON/OFF** switch to turn the transceiver off.
- 2. While holding the **MENU(SETUP)** button in, press and hold in the front panel **ON/OFF** switch to turn the transceiver on. Once the transceiver comes on, release the buttons.

FULL RESET (Except SETUP settings)

Use this procedure to restore all Menu and Memory settings except SETUP settings (MY CALL, LAT/LON, TIME/DATE, and CW TEXT) to their original factory defaults . All Memories will be cleared by this procedure.

- 1. Press the front panel **ON/OFF** switch to turn the transceiver off.
- 2. While holding the **F**(M-LIST) in, press and hold in the front panel **ON/OFF** switch to turn the transceiver on. Once the transceiver comes on, release the buttons.

FULL RESET

Use this procedure to restore all Menu and Memory settings to their original factory defaults. All Memories will be cleared by this procedure.

- 1. Press the front panel **ON/OFF** switch to turn the transceiver off.
- 2. While holding the **FAST** and **LOCK** buttons in, press and hold in the front panel **ON/OFF** switch to turn the transceiver on. Once the transceiver comes on, release the buttons.









ANTENNA CONSIDERATIONS

The **FT-991A** is designed for use with any antenna system providing a 50 Ohm resistive impedance at the desired operating frequency. While minor excursions from the 50-Ohm specification are of no consequence, if the Standing Wave Ratio (SWR) present at the Antenna jack is greater than 3:1, the transceiver's Automatic Antenna Tuner may not be able to reduce the impedance mismatch to an acceptable value.

Every effort should be made to ensure that the impedance of the antenna system be as close as possible to the specified 50-Ohm value. Note that the "G5RV" type antenna does not provide a 50-Ohm impedance on all HF Amateur bands. An external wide-range antenna coupler must be used with this antenna type.

Any antenna to be used with the **FT-991A** must be fed from the transceiver with 50 Ohm coaxial cable. Therefore, when using a "balanced" antenna such as a dipole, remember that a balun or other matching/balancing device must be used to ensure proper antenna performance.

The same precautions apply to any additional (receive-only) antennas connected to the antenna jacks. If the receive only antennas do not have impedance near 50 Ohms at the operating frequency, It may be necessary to install an external antenna tuner to obtain optimum performance.

ABOUT COAXIAL CABLE

Use high-quality 50-Ohm coaxial cable for the lead-in to your **FT-991A** transceiver. All efforts at providing an efficient antenna system will be wasted if poor quality, lossy coaxial cable is used. This transceiver utilizes standard "M" ("PL-259") type connectors.



Before You Begin

GROUNDING

The **FT-991A** transceiver, like any other HF communications apparatus, requires an effective ground system for maximum electrical safety and best communications effectiveness. A good ground system can contribute to station efficiency in a number of ways:

- □ It can minimize the possibility of electrical shock to the operator.
- □ It can minimize RF currents flowing on the shield of the coaxial cable and the chassis of the transceiver. Such currents may lead to radiation, which can cause interference to home entertainment devices or laboratory test equipment.
- □ It can minimize the possibility of erratic transceiver/accessory operation caused by RF feedback and/or improper current flow through logic devices.

An effective earth ground system may take several forms. For a more complete discussion, see an appropriate RF engineering text. The information below is intended only as a guideline.

Typically, the ground connection consists of one or more copper-clad steel rods, driven into the ground. If multiple ground rods are used, they should be positioned in a "V" configuration and bonded together at the base of the "V" which is nearest the station location. Use a heavy, braided cable (such as the discarded shield from type RG-213 coaxial cable) and strong cable clamps to secure the braided cable(s) to the ground rods. Be sure to weatherproof the connections to ensure many years of reliable service. Use the same type of heavy, braided cable for the connections to the station ground bus (described below).

Inside the station, a common ground bus consisting of a copper pipe of at least 25 mm diameter should be used. An alternative station ground bus may consist of a wide copper plate (single-sided circuit board material is ideal) secured to the bottom of the operating desk. Grounding connections from individual transceivers, power supplies, and data communications devices (TNCs, etc.) should be made directly to the ground bus using a heavy, braided cable.

Do not "Daisy-Chain" ground connections from one electrical device to another and thence to the ground bus. This method may nullify any attempt at effective radio frequency grounding. See the drawing below for examples of proper grounding techniques.

Inspect the ground system - inside the station as well as outside - on a regular basis to ensure continued performance and safety.

Besides following the above guidelines carefully, note that household or industrial gas lines must never be used in an attempt to establish an electrical ground. Cold water pipes may, in some instances, help in the grounding effort, but gas lines represent a significant explosion hazard, and must never be used.



PROPER GROUND CONNECTION



IMPROPER GROUND CONNECTION

CONNECTION OF ANTENNA AND POWER CABLES

Please follow the outline in the illustration regarding the proper connection of antenna coaxial cables, as well as the DC power cable. The DC power connector for the **FT-991A** must only be connected to a DC source providing 13.8 Volts DC (\pm 15 %), and capable of at least 23 Amperes of current. Always observe proper polarity when making DC connection:

The RED DC power lead connects to the Positive (+) DC terminal. The BLACK DC power lead connects to the Negative (-) DC terminal.



We recommend the use of the **FP-1030A** (USA market only) AC Power Supply. Other models of power supplies may be used with the **FT-991A**, but the 13.8 VDC input voltage, 23 Ampere current capability, and DC cable polarity guide-lines described above must be strictly followed.

Note that other manufacturers may use the same type of DC power connections as the **FT-991A** transceiver; however, the wiring configuration may be different from that specified for the **FT-991A** transceiver. Serious damage can be caused if improper DC connections are made; consult with a qualified service technician when in doubt.

High RF voltage is present in the TX RF section of the transceiver while transmitting.

Â

Absolutely! Do not touch the TX RF section while transmitting.

Permanent damage can result when improper supply voltage, or reverse-polarity voltage, is applied to the **FT-991A**. The Limited Warranty on this transceiver does not cover damage caused by application of AC voltage, reverse polarity DC, or DC voltage outside the specified range of 13.8 V \pm 15 %. When replacing fuses, be certain to use a fuse of the proper rating. The **FT-991A** requires a 25 Amp blade fuse.

NOTE:

- Do not place the **FT-991A** in a location with direct exposure to sunshine.
- Do not place the **FT-991A** in a location exposed to dust and/or high humidity.
- Ensure adequate ventilation around the FT-991A, to prevent heat build-up and possible reduction of performance due to high heat.
- Do not install the FT-991A on an unstable desk or table. Do not place it in a location where objects may fall onto it from above.
- □ To minimize the possibility of interference to home entertainment devices, take all precautionary steps including separation of TV/FM antennas from Amateur transmitting antennas to the greatest extent possible, and keep transmitting coaxial cables separated from cables connected to home entertainment devices.
- Ensure that the DC power cord is not subject to undue stress or bending, which could damage the cable or cause it to be accidentally unplugged from the rear panel DC IN jack.
- Be certain to install your transmitting antenna(s) so they cannot possibly come in contact with TV/FM radio or other antennas, or with power or telephone lines.

INSTALLATION AND INTERCONNECTIONS

CONNECTION OF MICROPHONE, HEADPHONE AND REMOTE CONTROL KEYPAD



NOTE:

Make sure to turn off the power of the transceiver before connecting or disconnecting the microphone.



INSTALLATION AND INTERCONNECTIONS

Key, Keyer, and Computer-Driven Keying Interconnections

The **FT-991A** includes many features for the CW operator. These functions will be detailed in the "CW Mode Operation" section later. This 3.5 mm, 3-contact jack accepts a CW key or keyer paddles (for the built-in electronic keyer), or the output from an external electronic keyer.

The Menu selections permit configuring the front panel **KEY** jack according to the device connected. For example, a keyer paddle may be connected to the front panel **KEY** jack, and Menu item "O12 KEYER TYPE" used to select paddle input.

The **KEY** jack on the **FT-991A** utilize "Positive" keying voltage. Key-up voltage is approximately +3.3V DC, and keydown current is approximately 4 mA. When connecting a key or other device to the **KEY** jack, use *only* a 3-contact ("stereo") 3.5 mm phone plug; a 2-contact plug will place a short between the ring and shaft (ground) of the plug, resulting in a constant "key-down" condition in some circumstances.



VL-1000 LINEAR AMPLIFIER INTERCONNECTIONS

Be sure that both the **FT-991A** and **VL-1000** are turned off, and then follow the installation recommendations contained in the illustration.

Note:

- □ Refer to the VL-1000 Operating Manual for details regarding amplifier operation.
- Do not attempt to connect or disconnect coaxial cables when your hands are wet.
- □ Set the Menu item "141 TUNER SELECT" to "LAMP".
- □ Since the ALC cable is connected to the **REM/ALC** jack, the optional **FH-2** cannot be connected.



the "ON" position.

PLUG/CONNECTOR PINOUT DIAGRAMS



FRONT PANEL CONTROLS & SWITCHES



1 ON/OFF Switch

Press and hold in this switch for one second to turn the transceiver on. Similarly, press and hold in this switch for one second to turn the transceiver off.

- Connect the **FT-991A** transceiver to a commercially available DC power supply. Turn the DC supply on to place the transceiver in standby mode. The transceiver must be in standby mode to turn it on using the **ON/OFF** switch. For details on how to connect a commercially available DC power supply, see page 15.
- Press the **ON/OFF** switch briefly while the power is on, the receiver audio from the speaker will be muted for about 3 seconds (Mute function).

② KEY Jack

Connect a telegraph key or electronic keyer paddle to use for CW mode operation.



- When connecting a key or other device to the **KEY** jack, use *only* a 3-contact ("stereo") 3.5 mm phone plug; a 2-contact plug will place a short between the ring and the (grounded) shaft of the plug, resulting in a constant "key-down" condition.
- Key-up voltage is +3.3 V, and key-down current is about 4 mA.

Note:

A 2-contact plug cannot be used in this jack.

③ PHONES Jack

Connect headphones to this $\phi 3.5$ standard stereo jack.

• Inserting a headphone plug into this jack will deactivate the internal and external speakers.

NOTE:

When wearing headphones, we recommend that you turn the AF Gain levels down to their lowest settings before turning power on, to minimize the impact on your hearing caused by audio "**pops**" during switch-on.

④ MIC Jack

This 8-pin jack accepts input from a microphone utilizing a traditional YAESU HF transceiver pinout.



5 F(M-LIST) Button

Press the button briefly to display the function menu screen where the operation settings for a variety of functions may be configured.

Press this button again to close the function menu screen.

Press and hold this button for more than one second to display the menu list screen where the memory channel data may be reviewed.

• While displaying the memory data, rotate the [MULTI] knob to review all data in memory channels.

Press this button again to close the memory list screen.

6 MENU(SETUP) Button

Press this button briefly to display the menu mode screen (see page 124) where you can set a variety of functions.

Press this button again (or touch [**BACK**] on the touch panel) to close the menu mode screen.

Press and hold this button for more than 1 second to display the setup screen where you can configure the following settings.

- **MY CALL**: Setting the call sign (see page 11)
- LAT/LON: Setting longitude/latitude (see page 118)
- **TIME/DATE**: Setting date and time (see page 10)

• **CW TEXT**: Entering CW TEXT (see page 89) Press this button again to close the setup screen.

7 BAND Button

Switch the operation band (operation frequency band). Press this button to display the operation band selection screen, then touch and select the desired band.

<i>vfo-A USB MIC-G</i>	14.	19:	12: 34 z
AMP1	CLAI	R	Онг
1.8	3.5	7.0	AIR
10	14	18	144
2 1	24	28	430
MW	50	GEN	ENT

Image: Book of the second s

Switch the radio modulation form (operating mode). Press this button to display the radio modulation form selection screen, then touch and select your desired modulation form.

VF0-A 12:34z USB 14.19500				
AMP1	CLAR	ОHz		
LSB	USB	AM		
CW-LSB	CW-USB	FM		
RTTY-LSB	RTTY-USB	C4FM		
DATA-LSB	DATA-USB	DATA-FM		

9 MULTI Knob

Adjust transmit output, microphone gain and operations of other functions (see page 24).

Front Panel Controls & Switches



10 A=B Button

Pressing this button momentarily, sets the same frequency and data values of VFO-A to VFO-B.

(1) **A/B** Button

Pressing this button momentarily, exchanges the frequency and memory channel data, of VFO-A and VFO-B.

12 RCL/STO Button

Press and hold this button for more than one second to write the frequency and data currently set for VFO-A onto the quick memory bank (QMB) (see page 103).

• 5 channels are available for QMB memories. Press the button briefly to recall the data written onto the quick memory banks (QMB) one by one.

13 TUNE Button

This is the on/off switch for the **FT-991A** Automatic Antenna Tuner.

• Press the [TUNE] button briefly to display the "TUNER" indicator on the touch panel and activate the antenna tuner.

Press the **[TUNE]** button briefly again to turn the "**TUNER**" indicator off and disable the antenna tuner.

• Press the [**TUNE**] button for about 1 second to start "automatic tuning". The "**TUNER**" indicator will flash.

NOTE:

- □ Since the transceiver transmits automatically during automatic tuning, make sure to connect an antenna or dummy load before tuning up.
- □ When the antenna or dummy load does not match the impedance, "HI-SWR" will appear on the touch panel.

14 C.S Button

Press this button momentarily to directly recall a favorite Menu Selection.

O To program a Menu selection to the C.S button, press the MENU(SETUP) button to enter the Menu. Select the Menu item you want to set as the short cut. Press the C.S button, then press the MENU(SETUP) button; this will lock in the selected Menu item as the short cut.

15 TXW Button

During a split operation, press and hold the **TWX** button to listen on the transmitter frequency while holding the button.

16 Main Tuning Dial Knob

This large knob adjusts the operating frequency of VFO-A.

Rotate clockwise to increase the operating frequency and rotate counter-clockwise to decrease the operating frequency.

OPERATING MODE	1 Step	1 Dial Rotation
LSB/USB/CW/RTTY/	5 Hz (100 Hz)	1 kHz (20 kHz)
DATA-LSB/DATA-		2 64- (20 64-)
USB/AM	10 HZ (100 HZ)	2 KHZ (20 KHZ)
FM/DATA-FM/C4FM	100 Hz (1 kHz)	20 kHz (200 kHz)

Numbers in parentheses indicate steps when the **FAST** button is On. **ADVICE:**

The tuning steps for the Main Dial knob are set at the factory to: 10Hz (SSB/AM), 5 Hz (CW/ RTTY/DATA-LSB/DATA-USB) and 100 Hz (FM/ DATA-FM/C4FM) per step.

In LSB, USB, CW, RTTY, DATA-LSB or DATA-USB mode, the frequency change amount (step width) may be toggled between "5Hz" and "10Hz" by pressing the **F(M-LIST)** button, and then touching **[5/10Hz]** on the LCD.

17 FAST Button

Pressing this button will change the tuning of the Main Tuning Dial knob (VFO-A) to a higher step rate.

Press this button to double the main dial frequency variation. "FAST" in the LED indicator area will light up.

Press this button again to restore the frequency variation to the original value. "FAST" will disappear.

18 LOCK Button

This button toggles on/off locking of the Main Tuning Dial knob.

Press this button to lock the main dial operations. "LOCK" will light up in the LED indicator area.

Press this button again to unlock the main dial operations. "LOCK" will disappear.

19 CLAR Button

During reception, press this button, then rotate the **CLAR/VFO-B** knob to adjust the VFO-A

RX clarifier offset value (see page 36).

- The clarifier offset value (frequency) can be restored to "0 (zero)" by pressing the **CLAR** button for more than 1 second.
- Depending on the menu mode "040 CLAR MODE SELECT" setting, this button can work as the TX clarifier for changing only the transmit frequency (see page 75) or RX/TX clarifier for both receiving and transmitting (see page 36, 75).

20 V/M Button

This button toggles frequency control between VFO-A and the memory system.

• Pressing this button alternately recalls the VFO frequency data and the frequency data saved in a memory channel by turns.

(2) A►M Button

Pressing and holding this key for one second (until the double beep) copies the current operating data into the currently selected memory channel, overwriting any previous data stored there.

Press this button briefly to display the memory check function screen, where the data saved in a memory channel may be reviewed.

• While displaying memory data, rotate the **MULTI** knob to review the data in each memory channel.

Press this button again, to close the memory list screen.

2 SPLIT Button

Press this button to operate split frequency between VFO-A (used for reception) and VFO-B (used for transmission) (see page 76).

• Press and hold in the **SPLIT** button for one second to engage the "Quick Split" (see page 76) feature. VFO-B transmit will automatically be set to a frequency 5 kHz higher than the VFO-A receive frequency, with the same operating mode. The transceiver will operate in the Split mode.

3 CLAR/VFO-B Knob

During the VFO-A operation, rotate this knob to adjust the clarifier.

During Split operation, this knob adjusts the operating frequency of VFO-B.

24 RF GAIN Knob

Adjust the receiver gain of the high frequency and mid-range frequency amplifier stages.

• Rotate the knob clockwise to increase the gain. Rotate the knob fully clockwise to set the gain to the highest level for normal operations.

25 AF GAIN Knob

The **AF GAIN** knob sets the receiver audio volume level.

• Rotate the knob clockwise to increase the receiver audio volume level.

TFT LIQUID CRYSTAL DISPLAY

A variety of information such as VFO-A/VFO-B frequencies, mode, S-meter will appear on the LCD.



Operating Mode Indicators

Displays the current operating mode.

VFO-A	Operating in VFO-A mode
MEM	Operating in memory mode
МТ	The memory tuning feature is in use
QMB	Operating with the quick memory feature
PMS	Programmable memory scanning
МСК	The memory check function is in use
HOME	Recalling the home channel
EMG	Recalling the frequency for emergency contact

Current Mode

(Modulation Form) Indicator

Displays the current modulation form.

HI-SWR Indicator

Indicates antenna matching errors.

When this warning appears, stop transmitting immediately, check and repair the antenna, connectors, cables, etc.

MULTI Knob Operations

Displays the functions operated with the **MULTI** knob (see page 21).

The progress bar shows the operation status.

RF-P (RF PWR)	Adjusts transmission output	
MIC-G (MIC GAIN)	Adjusts the microphone gain	
NB-L	Adjusts the noise blanker level	
SHIFT	Shift function	
WIDTH	Width function	
NOTCH	Notch function	
CONT	Contour function	
DNR	Digital Noise Reduction function	

PROC	Adjusts Speech Processor Gain	
MONI	Adjusts the monitor level	
DT-G (DT GAIN)	N) Adjusts the input level during data com- munication	
CH-D (CH DIAL)	Frequency tuning in the pre-pro- grammed steps	
SPEED	Adjusts keying speed	
APF	Audio Peak Filter function	
PITCH	Adjusts the CW pitch	
SQL	Adjusts the squelch level	
МСН	Selects the memory channel	
GRP	Selects the memory group	

lcons

Displays currently used functions.

TUNER	Antenna tuner	
ATAS	Active Tuning Antenna System	
ATT	The attenuator is in use	
SPLIT	Running split operation	
DUP	Recalling duplex memories	
[+]	Plus shift	
[-]	Minus shift	
IPO	The receiver amplifier is OFF	
AMP1		
AMP2		
D.VOX	The VOX function activates during data communi-	
	cation	
VOX	The VOX function is in use	
ENC	The tone encoder is in use	
DEC	The tone decoder is in use	
DCS	The digital code squelch is in use	

TFT LIQUID CRYSTAL DISPLAY

PLAY	The voice memory/contest memory keyer fur	
REC	uons are in use.	
	PLAY: Playing, REC: Recording	

S-Meter

Displays the reception signal strength.

To change the meter peak hold time

- 1. Press the **MENU(SETUP)** button.
- 2. Rotate the **MULTI** knob to select "OO9 BAR MTR PEAK HOLD".
- 3. Touch [SELECT], then rotate the MULTI knob to select the time to hold (OFF/0.5/1.0/2.0 seconds).
- 4. Touch [ENTER], then [BACK] or press the **MENU(SETUP)** button.

Meters

The following information can be displayed below the S-meter.

The displayed information is switched each time [**ME-TER**] is touched on the panel.

PO	Displays transmitter output power.	
ALC	Displays ALC voltage	
SWR	Displays antenna matching state	
COMP	Displays the speech processor compression level	
ID	Displays the drain current of the final stage FET transistors	
VDD	VDD Displays the drain voltage of the final stage ampl fier. The proper voltage is 13.8 V.	

Scope/Waterfall

Displays a spectrum or waterfall when the scope function (see page 42) is in use.

Menu List

Displays the menu item list when making settings in the menu mode.

Memory List

Displays the data saved in the memory channels.

Function Menu

Displays the function menu from which you can set a variety of functions.

Touch [**BACK**]/[**FWD**] to switch the menu screen.

Operation Frequency

Displays the current operation frequency.

Clock

Indicates the current time.

When receiving a GPS signal, the time is set automatically.

GPS Signal Capturing Indicator

Appears when an external GPS device is connected to the **GPS/CAT** jack on the rear panel and GPS signals are being acquired.

VFO-B Data/Clarifier Operation

Displays operation status of the radio modulation form and VFO-B frequency, etc.

Displays the offset operation status and the clarifier offset value, etc.

Main Control Buttons (SWAP)

Frequently used functions can be assigned to these buttons.

To change the function assigned to the main control button

- 1. Press the **F(M-LIST)** button.
- Touch [BACK]/[FWD] to display screens
 "SWAP F1" to "SWAP F4".
- Touch one of the "SWAP F1" to "SWAP F4" screens and confirm the function you want to change flashes.
- Touch [BACK]/[FWD] to display the function you want to assign, then select and touch the function.
- 5. Press the **F(M-LIST)** button.

About the Display

LED INDICATORS

Displays the transmit/receive status of the transceiver, and the main dial "FAST" and "LOCK".



RX Indicator (Green)

This indicator illuminates when the squelch opens.

TX Indicator (Red)

This indicator illuminates during transmission.

Memory Mode RX/TX Indicators Green (Left):

This indicator illuminates when the receiver is active on the memory channel.

Red (Right):

This indicator illuminates when the transmitter is active on the memory channel.

Main Band RX/TX Indicators

Green (Left):

This indicator illuminates when the receiver is active on the main band (VFO-A).

Red (Right):

This indicator illuminates when the transmitter is active on the main band (VFO-A).

Sub Band TX Indicator Red (Right):

This indicator illuminates when the transmitter is active on the main band (VFO-B).

FAST Indicators

This indicator appears when the Main Tuning Dial knob tuning rate is set to "fast" (see page 23).

LOCK Indicators

This indicator appears when the Main Tuning Dial knob is locked (see page 23).

Rear Panel



Use this terminal to connect the transceiver to a good earth ground, for safety and optimum performance. Use a large diameter, short braided cable to make the ground connections. For details on grounding the transceiver, see "Grounding" on page 14.

2 ANT Jack (144/430MHz)

This is the M-type (European version: N-type) coaxial connector for the 144 MHz band and 430 MHz band antennas (50 ohms).

③ RTTY/DATA Jack

This is the input/output jack to connect a terminal unit for RTTY and TNC for packet communications.



(4) TUN/LIN Jack

Connect the optional external antenna tuner "**FC-40**" or the linear amplifier "**VL-1000**".



5 GPS/CAT Jack

This is the **RS-232C** jack for connecting a computer or a commercially available external GPS device. Connecting a computer to this jack, using a commercially available **RS-232C** straight cable, enables CAT control of the transceiver.



6 DC IN Jack

This is the DC power supply connection for the transceiver. Use the supplied DC cable to connect directly to a DC power supply, which must be capable of supplying at least 23 A @13.8 VDC.



Rear Panel

OUSB Jack

Connect a computer with a commercially available USB cable to control the transceiver remotely from the computer using the CAT command.

Inputting/Outputting audio signals and transmission control can also be done from the computer.

Note:

- □ To control the transceiver remotely from the computer, a USB driver is required. For details on the USB driver, visit the Yaesu website.
- □ When using a USB cable connected to a computer, the transceiver may change to the transmit mode when the computer is started.

8 EXT SPKR Jack

This is the monaural jack to connect an external speaker (4 Ω to 8 Ω).

Connecting an external speaker to this jack will deactivate the internal speaker.



Image: Second
Connect the optional remote control keypad "**FH-2**". When a device such as a linear amplifier is connected, this is an external ALC current input jack.



10 ANT Jack (HF/50MHz)

This is the M-type coaxial connector to connect HF band and 50 MHz band antennas (50 ohms).

1 Cooling fan

MH-31A8J MICROPHONE SWITCHES



1 PTT Switch

Switches transmission/reception. Press to transmit and release to receive.

2 **DWN** Button

Press the **DWN** (Down) button to scan the frequency downward.

③ **FST** Button

Allows switching the frequency variation (step), working in the same way as the **FAST** button on the transceiver front panel.

4 UP Button

Press the $\boldsymbol{\mathsf{UP}}$ button to scan the frequency upward.

⁵ Microphone

Speak into the microphone in a normal tone of voice with the microphone 5 cm away from the mouth.

6TONE Switch

Switches transmission sound quality. Slide to the "**1**" side to make the transmit audio flat. Slide to the "**2**" side to emphasize transmit audio.

Optional FH-2 Remote Control Switches

With the optional remote control keypad **FH-2**, you can record and transmit your voice (Voice Memory) and control the Contest Memory Keyer during CW operation.

- O On SSB/AM modes, five channels of storage and playback of voice memory (20 seconds each), using your own voice for recording (see page 70).
- For the CW Memory Keyer, 5 channels are available for each of the MESSAGE Memory and the TEXT Memory (see page 86).



Ovoice Memory: 5 Memory Channels for the Memory Keyer

In the case of Voice Memory, up to 20 seconds of audio may be stored on each channel.

"MESSAGE Memory" and "TEXT Memory" are available for the Contest Memory Keyer.

Each "MESSAGE Memory" channel is capable of retaining a 50-character CW message using the PARIS standard for characters and word length.

Each "TEXT Memory" channel is capable of retaining a maximum of 50 characters.

② Cursor Buttons

When programming the Contest Memory Keyer, these buttons are used to move the cursor and select the text characters.

The cursor may be moved in 4 different directions (up/down/right/left).

Usually, these buttons are used for tuning the VFO frequency. Press the $[\blacktriangle]/[\lor]$ buttons to change the frequency in the same increments as the microphone [UP]/[DWN] switches. Press the $[\blacktriangleleft]/[\blacktriangleright]$ buttons to change the frequency by 100 kHz steps.

③ [P/B] Button

When entering text, a space may be inserted where the cursor is flashing.

④ [LOCK] Button

The **FH-2** key buttons may be locked by setting this switch to "ON".

(5) [MEM] Button

Press this button to store either a Voice Memory, or a Contest Keyer Memory.

6 [**DEC**] Button

When utilizing the sequential contest number capability of the Contest Keyer, press this button to decrement (decrease) the current Contest Number by one digit (i.e. to back up from #198 to #197, etc.).

Optional MH-36E8J Microphone Switches

The optional **MH-36E8J** is a handheld microphone equipped with the DTMF function that enables DTMF (Dual Tone Multi Frequencies) transmission.

A lamp switch illuminates the DTMF keypad for easy viewing in the dark.



DWN Button

Press to tune down, hold to start scanning.

2UP Button

Press to tune up, hold to start scanning.

③ Microphone Element

Speak across the face of the mic from about two inches away.

4 DTMF Indicator

When the DTMF is transmitted, this indicator glows red.

5 PTT Switch

Press and hold to transmit.

6 **DTMF** Keypad

Press a key button while holding the **PTT** switch to transmit a DTMF tone.

OLOCK Switch

Slide upward to lock the microphone controls and buttons.

8 LAMP Switch

Slide upward to illuminate the keypad.

Image:
This activates an accessory function. Activates the "first" mode when used with the **FT-991A**.

10 **B** Button

This activates a second accessory function. This button has no function when used with the **FT-991A**.

Basic Operation: Receiving on Amateur Bands

Before turning on the main power, please verify the following items once more.

- □ Have you made all ground connections securely? See page 14 for details.
- Do you have your antenna(s) connected to the rear-panel Antenna jack(s)? See page 15 for details.
- □ Is your microphone (and/or key or paddle) connected? See pages 16, 17 for details.
- □ If using a linear amplifier, have all interconnections been successfully completed? See pages 18 for details.
- Please rotate the AF GAIN control to the fully counter-clockwise position, to avoid a loud blast of audio when the transceiver turns on. See page 23 for details.

Basic Operation: Receiving on Amateur Bands

Here is the typical start-up procedure for normal operation:



- 1. Turn on the external DC power supply.
- 2. Press and hold in the front-panel **ON/OFF** switch until the transceiver turns on.
- 3. The transceiver will start up on 7.000.00 MHz LSB, (or the previously used operating frequency) and normal operation may begin.

Note:

To turn power off, press and hold in the front panel **ON/OFF** switch for one second.

4. Rotate the **AF GAIN** knob to set a comfortable audio level of the incoming signals or noise. Clockwise rotation of the **AF GAIN** knob increases the volume level.

NOTE:

When using headphones, start by rotating the **AF GAIN** knob counter-clockwise, then bring the volume level up after you put the headphones on. This will minimize the chance of damage to your hearing caused by an unexpectedly high audio level.

 Press the **BAND** button to display the list of Amateur bands on the LCD, then touch a key corresponding to the band on which you wish to begin operation.

ADVICE:

- One-touch selection of each Amateur band between 1.8 and 50 MHz, 144 MHz, and 430 MHz is provided.
- □ Touch and hold [14] on the screen displayed by pressing the **BAND** button to selection 5 MHz is provided.
- □ The FT-991A utilizes a triple band-stack VFO selection technique, which permits storing up to three favorite frequencies and modes onto each VFO band register. For example, you may store one frequency each on 14 MHz CW, RTTY, and USB, then recall these frequencies by successive, momentary touches of the [14] on the screen

displayed by pressing the **BAND** button. Each Amateur band key may similarly have up to three frequency/mode settings applied. See page 39 for details.

6. Press the **MODE** button to display the available selections.

Touch the corresponding key to select the desired operating mode.

ADVICE:

- By convention in the Amateur bands, LSB is used on the 7 MHz and lower bands (with the exception of 60 meters), while USB is utilized on the 14 MHz and higher bands.
- □ When changing modes from SSB to CW, you will observe a frequency shift on the display. This shift represents the BFO offset between the "zero beat" frequency and the audible CW pitch (tone) you can hear (the pitch is programmed via the Menu item "D59 CW FREQ DISPLAY"), even though the actual tone that you hear is not changing.
- □ To eliminate noise while the transceiver is not receiving any signal, press the F(M-LIST) button, then touch [SQL] on the LCD. "SQL" will appear on the LCD and the MULTI knob will function as the squelch knob. Rotate the MULTI knob to adjust the squelch until the noise disappears.

7. Rotate the Main Tuning Dial knob to tune around the band, and begin normal operation.

ADVICE:

□ Clockwise rotation of the Main Tuning Dial knob increases the operating frequency, one "step" of the synthesizer at a time; similarly, counterclockwise rotation of the Main Tuning Dial knob will decrease the frequency. Two settings, one "normal" and one "fast", are available for each operating mode. Pressing the **FAST** button engages the "Fast" tuning selection (see chart below).

OPERATING MODE	1 Step	1 Dial Rotation
LSB/USB/CW/RTTY/	5 Hz (100 Hz)	1 kHz (20 kHz)
DATA-LSB/DATA-		
USB/AM	10 Hz (100 Hz)	2 kHz (20 kHz)
FM/DATA-FM/C4FM	100 Hz (1 kHz)	20 kHz (200 kHz)

MAIN TUNING DIAL KNOB TUNING RATE

□ If you want to make rapid frequency changes,

Numbers in parentheses indicate steps when the FAST button is On.

- there are several techniques available:Direct keyboard entry of the frequency.
- Use the microphone UP/DWN scanning keys, if your microphone is so equipped.
OPERATION ON 60-METER (5 MHz) BAND (U.S. AND U.K. VERSION ONLY)

The recently-released 60-meter band is covered, in the **FT-991A**, by fixed memory channels. These channels are set to USB or CW, and they appear between the "last" PMS channel ("P9U") and the first "regular" memory channel (Channel 1):

- 1. Press the **V/M** button once to enter the "Memory" mode; the "**MEM**" icon will appear in the display.
- Touch [MCH] on the screen displayed by pressing the F(M-LIST) button. The "MCH" notation and a memory channel number will appear on the display to signify that rotation of the MULTI knob will allow selection of the memory channel.



- 3. Memory channels ("5-01" through "5-10") are pre-programmed, at the factory, with the permitted frequencies in the 5 MHz band, and the USB or CW mode is automatically selected on these channels.
- To exit from 60-meter operation and return to the VFO mode, just press the V/M button.

NOTE:

The frequencies and operating mode for 5 MHz band operation are fixed, and may not be changed.



CHANNEL	FREQUENCY		
NUMBER	U.S. VERSION	U.K. VERSION	
5-01	5.332000 MHz (SSB)	5.260000 MHz (SSB)	
5-02	5.348000 MHz (SSB)	5.280000 MHz (SSB)	
5-03	5.358500 MHz (SSB)	5.290000 MHz (SSB)	
5-04	5.373000 MHz (SSB)	5.368000 MHz (SSB)	
5-05	5.405000 MHz (SSB)	5.373000 MHz (SSB)	
5-06	5.332000 MHz (CW)	5.400000 MHz (SSB)	
5-07	5.348000 MHz (CW)	5.405000 MHz (SSB)	
5-08	5.358500 MHz (CW)	-	
5-09	5.373000 MHz (CW)	-	
5-10	5.405000 MHz (CW)	-	

CLAR (CLARIFIER) OPERATION

The **CLAR** button and **CLAR/VFO-B** knob are used to offset the receive frequency, the transmit frequency, or both, from their settings on the VFO-A frequency. Four small numbers on the TFT Display show the current Clarifier offset. The Clarifier controls on the **FT-991A** are designed to allow setting a preset offset (up to ± 9.99 kHz) without actually retuning, and then to activate it via the Clarifier **CLAR** button. This feature is ideal for following a drifting station, or for setting the small frequency offsets sometimes utilized in DX "Split" work.

Here is the technique for utilizing the Clarifier:

- 1. Press the **CLAR** button. The "**RX**" notation will appear in the TFT Display, and the programmed offset will be applied to the receive frequency.
- Rotation of the CLAR/VFO-B knob will allow you to modify your initial offset on the fly. Offsets of up to ±9.99 kHz may be set using the Clarifier.



To cancel Clarifier operation, press the **CLAR** button. The "**RX**" notation will disappear from the display.

ADVICE:

Turning the Clarifier off merely cancels the application of the programmed offset from the receive and/or the transmit frequencies. To clear the Clarifier offset, and reset it to "zero," press and hold the **CLAR** button. The programmed offset is displayed in the small multichannel window of the frequency display.



LOCK

You may lock the setting of the Main Tuning Dial knob (for VFO-A frequency tuning) to prevent accidental frequency change.

Main Tuning Dial Knob Lock

To lock the Main Tuning Dial knob, press the **LOCK** button that is located to the right of the Main Tuning Dial knob.

"Lock" in the LED indicator area will light up

To unlock the Dial setting, and restore normal tuning, press the **LOCK** button once more.



DIMMER

The illumination level of the TFT display and LED indicators (above the Main Tuning Dial knob), may be adjusted via Menu items 007 and 008.

To adjust the illumination level:

- 1. Press the **MENU** button to enter the Menu mode.
- Rotate the MULTI knob to select Menu item "OO7 DIMMER LED" (for LED indicators) or "OO8 DIM-MER TFT" (for TFT display).
- Touch [SELECT] on the LCD then rotate the MULTI knob to select the desired illumination level.



4. Touch **[ENTER]** on the LCD, then touch **[BACK]** on the LCD or press the **MENU** button to save the new setting and exit to normal operation.





VFO COLOR

The background color of the VFO-A frequency in the TFT display may be selected via Menu item 006.

- 1. Press the $\ensuremath{\mathsf{MENU}}$ button to enter the Menu mode.
- Rotate the MULTI knob to select Menu item "OO6 DISPLAY COLOR".
- Touch [SELECT] on the LCD, then rotate the MULTI knob to select from the following colors: BLUE (default) / GRAY / GREEN / ORANGE / PURPLE / RED / SKY BLUE



4. Touch **[ENTER]** on the LCD, then touch **[BACK]** on the LCD or press the **MENU** button to save the new setting and exit to normal operation.







BAND STACK OPERATION

The **FT-991A** utilizes a triple band-stack VFO selection technique that permits storing of up to three favorite frequencies and modes onto each band VFO register. For example, one frequency each on 14 MHz CW, RTTY, and USB may be stored and then recalled by successive, momentary touches of **[14]** on the screen displayed by the **BAND** button. Each Amateur band key may similarly have up to three frequency/mode settings applied. Note that only the VFO-A system has the band stacks.

A typical setup, for the 14 MHz band, might be arranged like this:

- Program 14.025 MHz, CW Mode, then press the BAND button, and then touch [14] on the LCD.
- 2. Program 14.080 MHz, RTTY Mode, then press the **BAND** button, and then touch **[14]** on the LCD.
- 3. Program 14.195 MHz, SSB Mode, then press the **BAND** button, and then touch **[14]** on the LCD.

To individually recall each of the three stored operating states, press the **BAND** button, and then touch **[14]** on the screen repeatedly.





VFO-A			14.402
USB	14	19!	500
MIC-G			
	CLAI	7	Онz
1.8	3.5	7.0	AIR
10	14	18	144
2 1	24	28	430
MW	50	GEN	ENT

ADVICE:

The 5MHz band stack may be recalled by touching and holding [14] on the LCD in a similar operation.

C.S (CUSTOM SWITCH)

The front panel C.S button may be programmed to directly access an often-used Menu Mode selection.

C.S Setup

- 1. Press the **MENU** button to engage the Menu mode; the Menu list will appear on the display.
- 2. Rotate the **MULTI** knob to select the Menu item you want to access with the front panel **C.S** button.
- 3. Press the **C.S** button to lock in your selection.
- Press the MENU button or touch [BACK] on the LCD to save the new configuration and exit to normal operation.

Menu Selection Recall via C.S button

Press the **C.S** button.

The programmed Menu item will appear on the display. Press the **MENU** button or touch [**BACK**] on the LCD exit to normal operation.



AMS (AUTOMATIC MODE SELECT) OPERATION

The transceiver has the AMS (Automatic Mode Select) function which enables the transceiver to automatically select the most appropriate option out of the three communication modes according to the received signal while operating in C4FM mode.

Besides C4FM digital signals, analog signals (FM) are also identified in order to automatically match the communication mode of the partner station.

Note:

The AMS function recognizes the three modes listed in the following table. Other communication modes cannot be recognized.

OPERATING MODE	DISPLAY	EXPLANATION OF MODES
V/D mode	DN	As the audio signal error is detected and repaired at the
(simultaneous voice and data	When AMS is "ON": Red	same time as the transmission of the digital audio signal,
communication mode)	When AMS is "OFF": Light blue	it becomes more difficult for conversations to be cut off. A
		basic digital mode of C4FM FDMA.
Voice FR mode	VW	Digital voice data is transmitted using the entire 12.5 kHz
(Voice full-rate mode)	When AMS is "ON": Red	bandwidth. High quality voice communication is possible.
	When AMS is "OFF": Light blue	
Analog FM mode	AN	Analog communication mode using the FM mode.
	Only when AMS is "ON": Lights red	This mode is effective for communication when the signal
		strength is so weak that the voice is cut off midway in the
		digital mode.

 Press the MODE button, and then touch the corresponding key on the LCD to select the C4FM operating mode. The "C4FM" icon appears in the display.

CAFM 146.52000			
	CLAR	Онz	
LSB	USB	AM	
CW-LSB	CW-USB	FM	
RTTY-LSB	RTTY-USB	C4FM	
DATA-LSB	DATA-USB	DATA-FM	

2. Touch **[AMS]** on the LCD. The AMS function will switched to "ON" and the communication mode will be switched to match the received signal.



Note:



In the V/D mode ("**DN**" displayed), the position information is included in the transmitted signal during the conversation, but in the Voice FR mode ("**VW**" displayed), the position information is not included.

AMS (AUTOMATIC MODE SELECT) OPERATION

Setting the Operation of the AMS Function

Using the AMS function switches the communication mode to match the received signal but you can alternatively select and lock the transmission mode.

- 1. Press the **MENU(SETUP)** button to enter the Menu mode.
- Rotate the MULTI knob to select Menu item "O90 AMS TX MODE".
- 3. Touch [**SELECT**] on the LCD, rotate the **MULTI** knob to select the desired operation (see the following table).



MENU(SETUP) Button

4. Touch [ENTER] on the LCD to save the new setting.



5. Press the **MENU(SETUP)** button or touch [**BACK**] on the LCD to exit to normal operation.

Available Settings	EXPLANATION OF FUNCTION		
AUTO	TX/RX	The operating mode is automatically selected from the three communication modes to match the received signal.	
MANUAL	TX/RX	The operating mode is automatically selected from three communication modes to match the received signal. Pressing the Microphone PTT switch momentarily, toggles between the Digital (C4FM) and Analog (FM) communication modes.	
DN	RX	RX The RX mode is automatically selected from the three communication modes to match the received signal.	
	ΤX	The TX mode is automatically changed to the "DN" mode.	
VW	RX	The RX mode is automatically selected from the three communication modes to match the received signal.	
	ΤX	The TX mode is automatically changed to the "VW" mode.	
ANALOG	RX The RX mode is automatically selected from the three communication modes to match the received sigr		
	ТΧ	The TX mode is automatically changed to the "FM" mode.	

Toggling to the Digital Communication Mode

Without using the AMS function, you can select and lock the digital communication mode (DN or VW).

- 1. Touch **[AMS**] on the screen to set the AMS function to "OFF".
- 2. Touching [**DIGITAL**] on the screen switches the digital communication mode between the following modes.

DN (V/D Mode): As the audio signal error is detected and repaired at the same time as the transmission of the digital audio signal, it becomes more difficult for conversations to be cut off. A basic digital mode of C4FM FDMA.



VW (FR Mode): Digital voice data is transmitted using the entire 12.5 kHz bandwidth. High quality voice communication is possible.

Convenience Features

SCOPE

The SCOPE function provides a real time spectrum display of the band conditions. Both strong and weak signals can be clearly displayed on the TFT screen. In the MANUAL mode, the scope frequency spectrum is scanned one time and displayed. In the "Continuous Sweeping mode", the scope spectrum is repeatedly swept and displayed. The scope sweep and span, the color of the SPECTRUM display, and the color of the WATER FALL display may be optimized according to your preference.

Touch [**SWEEP**] on the LCD to display the band conditions (spectrum).

□ The transceiver is equipped with two types of sweeping mode: "MANUAL mode" and "Continuous sweeping mode". Refer to the advice below to select the optimal mode according to your preferences and purposes.

ADVICE:

- □ "Touch [**SWEEP**] on the LCD to access the Manual mode. Each time [**SWEEP**] on the LCD is touched, a new scan of the spectrum scope is shown on the TFT display.
- □ Touch and hold [**SWEEP**] on the LCD to cause the spectrum scope to scan continuously until [**SWEEP**] on the LCD is touched again.
- Spectrum display mode" or "Waterfall display mode" may be selected in Menu item "115 SCP DISPLAY MODE".
- Width of scope display may be set in Menu item "116 SCP SPAN FREQ".
- □ Color of the SPECTRUM display may be set in Menu item "117 SPECTRUM COLOR".
- □ Color of the WATER FALL display may be set in Menu item "118 WATER FALL COLOR".







Example of waterfall display

SCOPE

Sweep Mode

Two sweep modes are available for the scope function as described below.

MANUAL Mode

Touch [SWEEP] on the LCD to sweep across the band one time, and display band conditions.

Continuous Sweeping Mode

Touch and hold [**SWEEP**] on the LCD to begin the continuous sweep operation. The spectrum scope will start sweeping the band segment continuously. While rotating the main dial, you can continuously monitor the band condition.

To stop sweeping, touch [SWEEP] on the LCD again.

More Frequency Navigation Techniques

Keyboard Frequency Entry

The Operating frequency may be entered directly into the current VFO, using the display screen keyboard by pressing the front panel **BAND** button.

Example: Enter 14.250.00 MHz

- 1. Press the **BAND** button to begin the direct frequency entry process.
- 2. Touch **[ENT]** on the LCD. The first digit of the frequency (the leftmost digit) will blink.
- Enter, in order, the digits of the operating frequency, touching the keys on the LCD
 The decimal point after the "MHz" portion of the

The decimal point after the "MHz" portion of the frequency must be entered, but no decimal point is required after the "kHz" portion.

4. Touch **[ENT]** on the LCD once more to complete the operating frequency entry. A short "beep" will confirm that the entry was successful, and the new operating frequency will appear on the display.

	14.	25	14:46 Z
AMP1	CLA	R	Онz
1	2	3	1MHz UP
4	5	6	1MHz DN
7	8	9	000
	0	CE	ENT
			<u> </u>

ADVICE:

If you attempt to enter a frequency outside the operating range of 30 kHz - 56 MHz, 118 MHz - 164 MHz or 420 MHz - 470 MHz the microprocessor will ignore the attempt, and will return to the previous operating frequency. If this happens, please try again, taking care not to repeat the error in the frequency entry process.

Setting with the MULTI Knob

Rotate the **MULTI** knob to set the frequency in the preprogrammed frequency steps. The frequency step can be changed.

1. Press the **F(M-LIST)** button to display the function menu list. Touch the **[CH DIAL]** icon to activate this function and cause the **MULTI** knob to function as the frequency adjustment knob.

CH-D (CH DIAL) indicator



2. Touch [CH DIAL] to select the desired frequency step. Touching [CH DIAL] switches the frequency as follows.

OPERATING MODE	FREQUENCY STEP	
AM	$2.5 \rightarrow 5 \rightarrow 9 \rightarrow 10 \rightarrow 12.5 \rightarrow 25 \rightarrow$	
	2.5 →	
SSB/CW/RTTY/	$1 \rightarrow 2.5 \rightarrow 5 \rightarrow 1 \rightarrow \dots$	
DATA-LSB/DATA-USB		
FM/C4FM/	$5 \rightarrow 6.25 \rightarrow 10 \rightarrow 12.5 \rightarrow 15 \rightarrow 20$	
DATA-FM	$\rightarrow 25 \rightarrow 5 \rightarrow \dots$	

3. Rotate the **MULTI** knob to change the frequency in the selected frequency steps.

MORE FREQUENCY NAVIGATION TECHNIQUES

Using the UP/DWN Buttons of the Supplied MH-31A8J Hand Microphone

The **UP/DWN** buttons on the supplied **MH-31A8J** Hand Microphone may also be used to manually scan the frequency upward or downward.

In modes other than AM/FM, the frequency changes by the same step as the main dial.

When the microphone **FST** button is pressed, the tuning rate increases by a factor of ten, in a manner similar to the transceiver front panel **FAST** button.

The frequency change amount (step size) differs depending on the preset modulation form and FST button condition.



Operating Mode	UP	DWN	FST + UP	FST + DWN
CW/RTTY/ DATA-LSB/ DATA-USB	+5 Hz	−5 Hz	+100 Hz	-100 Hz
LSB/USB/AM	+10 Hz	-10 Hz	+100 Hz	–100 Hz
FM/C4FM/ DATA-FM	+5 kHz	−5 kHz	+50 kHz	−50 kHz

Convenience Features

Receiver Operation (Front End Block Diagram)

The **FT-991A** includes a wide range of special features to suppress the many types of interference that may be encountered on the HF bands. However, real world interference conditions are constantly changing, so optimum setting of the controls is somewhat of an art, requiring familiarity with the types of interference and the subtle effects of some of the controls. Therefore, the following information is provided as a general guideline for typical situations, and a starting point for your own experimentation.

The **FT-991A** interference-fighting circuitry begins in its "RF" stages, and continues throughout the entire receiver section. **FT-991A** allows configuration of the features described below.

CONTOUR Filter

The DSP Contour filter has the unique ability to provide either a null or a peak in tunable segments of the receiver passband. You may suppress interference and excessive frequency components of an incoming signal, or you may peak those tunable frequency segments. The level of the null or peak, and the bandwidth, over which it is applied, are adjustable via the Menu.

IF SHIFT

The passband center frequency of the IF DSP filter may be moved up or down by adjusting this control.

IF WIDTH

The width of the IF DSP filtering may be adjusted using this control.

IF NOTCH

The IF Notch filter is a high-Q notch filter that can eliminate, or significantly reduce an interfering carrier.

DNF (Digital Notch filter)

When multiple interfering carriers are encountered during reception, the Digital Notch Filter can significantly reduce the level of these signals.

DNR (Digital Noise Reduction)

The DSP's Digital Noise Reduction (DNR) feature utilizes 15 different mathematical algorithms to analyze and suppress different noise profiles encountered on the HF/50 MHz bands. Choose the selection that provides the best noise suppression, and allows the signal to rise up out of the noise.

AGC

The AGC system automatically adapts to changing signal and fading characteristics, making reception possible under the most difficult conditions.

The **FT-991A** uses the 15 kHz roofing filter on AM/FM/C4FM modes. All the other modes use the 3 KHz filter automatically. There is no manual selection possible.



FRONT END BLOCK DIAGRAM

ATT (ATTENUATOR)

When the desired signal is extremely strong or the noise level is high on a low frequency band, activate the attenuator to reduce the incoming signal from the antenna.

 Press the F(M-LIST) button, then touch [ATT] on the LCD. The "ATT" indicator will appear in the DSP display.

ADVICE:

☐ The incoming signal level is reduced by 12dB (Signal voltage is reduced to 1/4 compared to OFF).



 To restore full signal strength through the Attenuator circuit, touch [ATT] on the LCD to return the ATT display to the "OFF" position.

ADVICE:

If the noise level is high or the received signal is extremely strong, the incoming signal level can be suppressed with the IPO/ATT settings.

If the S-meter fluctuates S-3 or more in the noise level, or the received signal is extremely strong and it causes a high S-meter indication (+20dB or more), activate the attenuator.

Since IPO does not only attenuate the incoming signal, but also improves the cross modulation characteristic, try to activate the IPO first. If the signal is still strong, also use the ATT. In this way, you can attenuate the incoming signal and noise effectively.



Interference Rejection

IPO (INTERCEPT POINT OPTIMIZATION)

The IPO feature allows the operator to optimize the characteristics of the receiver front end, contingent on the current noise level and the strength of incoming signals.

Press the **F(M-LIST)** button to display the function menu list. Touch the **[IPO]** function repeatedly, to set the desired characteristic of the receiver front end, according to the chart below.

- **AMP1**: Amplifies the incoming signals, using a low distortion RF preamplifier (gain: approx. 10 dB).
- **AMP2**: Amplifies the incoming signals, using a 2-stage low-distortion RF preamplifier (total gain: approx. 20 dB).
- **IPO**: Bypasses the RF preamplifier, yielding direct feed to the first mixer.



1.8 MHz ~ 56 MHz

Note:

AMP1 does not function below the 1.8 MHz frequency range.

The selected receiver RF preamplifier will be indicated in the IPO column of the Key Function Display on the TFT screen.



ADVICE:

On the 10 MHz and lower bands, it is generally not necessary to use any preamplifier at all; selecting the "IPO" position as described above will increase the strong-signal-handling capability of the receiver, and generally result in more pleasant reception due to the reduced ambient noise level. If you can hear band noise with the preamplifiers disengaged, then a preamplifier is generally not needed.





IF NOISE BLANKER (NB) OPERATION

The **FT-991A** includes an effective IF Noise Blanker, which can significantly reduce noise caused by automotive ignition systems.

NOTE:

The NB function may be less effective on some other types of interference.

 Press the F(M-LIST) button to display the function menu list. Touch the [NB] function icon briefly to reduce *short duration pulse noise* like that from switching transients, automobile ignitions and power lines. The Noise Blanker will be set to "ON".





 If desired, the Noise Blanker level may be adjusted via Menu item "O25 NB LEVEL" to the point where the offending noise is best reduced or eliminated. See box below for details.

ADVICE:

- ☐ The noise attenuation can be selected from 10dB/30dB/50dB via Menu item "O24 NB RE-JECTION".
- 3. To end Noise Blanker operation, touch **[NB]** on the TFT display once more. The "OFF" will appear in the TFT display, confirming the Noise Blanker is no longer in operation.



Interference Rejection

CONTOUR CONTROL OPERATION

The Contour filter system provides a gentle perturbation of the IF filter passband. The Contour is set to either suppress, or boost specific frequency components, and thus enhances the sound and readability of a received signal.

- Press the F(M-LIST) button to display the function menu list. Touch [CONT] to activate the CONTOUR function and set the MULTI knob as the CONTOUR adjustment knob.
- 2. Touch [**CONT**] on the TFT display. The Contour function will be set to "ON".





- Rotate the MULTI knob to achieve the most natural sounding audio reproduction of the incoming signal. ADVICE:
 - □ Rotate the MULTI knob to display the Contour center frequency (10 Hz to 3,200 Hz) below the [CONT] indicator.
 - ☐ The level indicator shows the amount of attenuation for your reference.
- 4. To cancel Contour tuning, touch [**CONT**] on the TFT display.

ADVICE:

- □ The Contour circuit operation will be set to "OFF".
- □ Touching [**CONT**] changes the Contour circuit operation between "ON" and "OFF".
- The Contour function attenuation and bandwidth can be set in Menu items "112 CONTOUR LEVEL" and "113 CONTOUR WIDTH" (refer to the instruction on the right).



Refer to Figure "**B**", this illustrates a "dip" in the center of the Contour filter passband. The Contour filter places a low-Q "notch" in the passband, per the settings of Menu items "112 CONTOUR LEVEL" and "113 CONTOUR WIDTH". Counterclockwise rotation of the **MULTI** knob causes the notch to move toward a lower frequency within the passband, while clockwise rotation causes the notch to move toward a higher frequency within the passband. By removing interference or unwanted frequency components of the incoming signal, it is possible to make the desired signal rise out of the background noise/interference, and significantly enhance intelligibility.



QUICK POINT:

By judicious use of the Contour filter, the "shoulder" of the passband response may be altered, or components may be removed from within the passband, allowing the desired signal to rise above the background noise and interference in a manner not obtainable with other filtering systems.

IF SHIFT OPERATION (SSB/CW/RTTY/DATA MODES)

IF SHIFT permits moving the DSP filter passband higher or lower, without changing the pitch of the incoming signal, and thus reduces or eliminates interference. Because the tuned carrier frequency is not varied, there is no need to re-tune the operating frequency to eliminate the interference. The total passband tuning range for the IF SHIFT system is ± 1.2 kHz.

 Press the F(M-LIST) button to display the function menu list. Touch [SHIFT] to reduce the interference. The MULTI knob functions as the SHIFT adjustment knob.



2. Rotate the **MULTI** knob to the left or right to reduce interfering signals.

ADVICE:

- □ Rotate the **MULTI** knob to display the shift offset of the IF filter (-1,200 Hz to +1,200 Hz) below the [**SHIFT**] indicator.
- □ The level indicator shows the shift offset direction for your reference.

Referring to Figure "**A**", note the depiction of the IF DSP filter as the thick line, with **MULTI** knob in the 12 o'clock position. In Figure "**B**", an interfering signal has appeared inside the original passband. In Figure "**C**", you can see the effect of rotating the **MULTI** knob. The interference level is reduced by moving the filter passband so that the interference is outside of the passband.





Interference Rejection

WIDTH (IF DSP BANDWIDTH) TUNING (SSB/CW/RTTY/DATA MODES)

The IF WIDTH tuning system allows you to vary the width of the DSP IF passband, to reduce or eliminate interference. Moreover, the bandwidth may actually be *expanded* from its default setting, should you wish to enhance incoming signal fidelity when interference on the band is low.

1. Press the **F(M-LIST)** button to display the function menu list. Touch the [**WIDTH**] icon to activate this function and cause the **MULTI** knob to function as the WIDTH adjustment knob.



2. Rotate the **MULTI** knob counter-clockwise to narrow the bandwidth and reduce interference.



ADVICE:

- To increase the bandwidth, rotate the knob clockwise.
- Rotate the MULTI knob to display the bandwidth of the IF filter below the [WIDTH] indicator (Refer to the instruction below).
- □ For reference, the level indicator on the TFT display shows the bandwidth.

Referring to Figure "**B**", you can see the default bandwidth of the SSB mode.

By rotating the **MULTI** knob to the left, the bandwidth will narrow (see Figure "**A**"), while rotation of the **MULTI** knob to the right, will increase the bandwidth as depicted in Figure "**C**".

The default bandwidths, and total bandwidth adjustment range, will vary according to the operating mode:

SSB Mode: 1.8 kHz - 3.2 kHz (default: 2.4 kHz). CW Mode: 500 Hz - 3 kHz (default: 2.4 kHz) RTTY/DATA (LSB, USB) Modes: 500 Hz - 3 kHz (default: 500 Hz) AM Mode: Fixed at 9 kHz FM/DATA-FM/C4FM Modes: Fixed at 16 kHz



WIDTH (IF DSP BANDWIDTH) TUNING (SSB/CW/RTTY/DATA MODES)

Using IF SHIFT and WIDTH Together

The IF SHIFT and Variable IF WIDTH features together form a very effective interference-fight-ing filtering system.

For example, in Figure "**A**", you can see how interference has appeared both on the high and low sides of the desired signal. Touch [**WIDTH**] on the LCD, the interference from one side can be eliminated (Figure "**B**"). Next, rotate the **MULTI** knob to re-position the passband (Figure "**C**"), the interference on the opposite side can be removed, without re-introducing the interference previously eliminated in Figure "**B**".



ADVICE:

The WIDTH and SHIFT features are the primary tools to use for best interference reduction. After narrowing the bandwidth (WIDTH) and/ or adjusting the center of the passband (SHIFT), the Contour control may then yield additional signal-enhancement benefits on the net residual bandwidth. Even more, the IF NOTCH Filter (described later) may also be used, in conjunction with these filter systems, to significant advantage.

Interference Rejection

NARROW (NAR) ONE-TOUCH IF FILTER SELECTION

Press the **F(M-LIST)** button to display the function menu list. Touch the **[NAR/WIDE]** button to enable one-touch, mode-specific, selection of a narrow IF DSP filter setting that does not require resetting the bandwidth control to the WIDTH/SHIFT system.

Touching **[NAR/WIDE]** on the LCD once more returns the bandwidth control to the WIDTH/SHIFT system. The factory default bandwidths are:

OPERATING MODE	[NAR/WIDE] TOUCH KEY		
	"ON"	"OFF"	
SSB	200 Hz - 1.8 kHz*	1.8 - 3.0 kHz*	
	(1.5 kHz)	(2.4 kHz)	
CW	50 - 500 Hz*	500 Hz - 3.0 kHz [*]	
	(500 Hz)	(2.4 kHz)	
RTTY/DATA-LSB/	50 - 500 Hz*	500 Hz - 3.0 kHz*	
DATA-USB	(300 Hz)	(500 Hz)	
AM	6 kHz	9 kHz	
FM/DATA-FM	9 kHz	16 kHz	
(28/50/144/430			
MHz Bands)			

*: Depends on the [**WIDTH**] setting (): Default Bandwidth

ע נ	<i>ifo-A USB</i> JIDTH	<u>14</u> .	195	14:46z
A		CLA	R	Онz
	S 1. PO 0	3 5 7 S 10	+20 +40 50 100	+60dB 150W
	NAR/WIDE	N B OFF	AGC AUTO	5/10Hz 10Hz
Ć	ACK	ATT OFF	IPO AMP1	FWD
	METER PO	RF PWR 100W	MIC GAIN 30	SWEEP

ADVICE:

- □ If [NAR/WIDE] on the LCD has been touched to engage the narrow filter, you may further adjust the narrow IF bandwidth by touching [WIDTH] on the TFT display and rotating the MULTI knob. The IF SHIFT may also be operated.
- □ When in the FM mode, touching [**NAR/WIDE**] on the TFT display will narrow both transmit and receive bandwidths.



IF NOTCH FILTER OPERATION (SSB/CW/RTTY/DATA/AM MODES)

The IF NOTCH filter is a highly effective system that allows cutting out an interfering beat note or other carrier signal from inside the receiver passband.

- 1. Press the **F(MLIST)** button to show the functions listed on the TFT display.
- 2. Touch [**NOTCH**] on the TFT display. The Notch function will be set to "ON".



- 3. Rotate the **MULTI** knob to adjust the "null" position of the Notch filter.
- 4. To cancel the NOTCH filter, touch [**NOTCH**] on the TFT display, "OFF" will appear in the display, confirming that the NOTCH filter is no longer in operation.

ADVICE:

Alternate touches of [**NOTCH**], will switch the NOTCH filter between on and off.

ADVICE:

The bandwidth of the NOTCH filter (either narrow or wide) may be adjusted using Menu item "114 IF NOTCH WIDTH". The factory default setting is "WIDE".



The performance of the IF NOTCH filter is illustrated in Figure "**A**", where the desired signal and the interfering heterodyne are shown within the IF passband. In Figure "B" the notching effect of the IF NOTCH filter is illustrated as the **MULTI** knob is rotated to eliminate the interfering heterodyne.



Interference Rejection

DIGITAL NOTCH FILTER (DNF) OPERATION

The Digital NOTCH Filter (DNF) is an effective beat-canceling filter that can null out a number of interfering beat notes inside the receiver passband. Because this is an Auto-Notch feature, there is no adjustment knob associated with this filter.

ADVICE:

If a very strong interfering carrier is encountered, we recommend using the IF NOTCH filter first, as it is the most effective notching tool in the receiver section.

 Press the F(M-LIST) button to show the functions listed on the TFT display, then touch [DNF] on the TFT display. The Digital NOTCH Filter will be set to "ON".





To disable the Digital NOTCH Filter, just repeat the above procedure, touching [**DNF**] on the LCD to choose "OFF". The "**DNF**" will turn off, confirming that the Digital NOTCH Filter is not active.

DIGITAL NOISE REDUCTION (DNR) OPERATION

The Digital Noise Reduction (DNR) system is designed to reduce the level of ambient noise found on the HF and 50 MHz bands. The (DNR) system is especially effective during SSB operation. While DNR is functioning, rotate the **MULTI** knob to adjust the DNR level. Any of 15 different noise-reduction algorithms can be selected; each of these algorithms was created to deal with a different noise profile. You will want to experiment with the DNR system to find the best setting corresponding to the noise currently being experienced.

- 1. Press the **F(MLIST)** button to reveal the functions list on the TFT LCD display.
- Touch [DNR] on the LCD. The DNR function will be set to "ON".





- 3. Rotate the **MULTI** knob to choose one of 15 algorithms that best reduces the noise level.
- To cancel the DNR filter, touch [DNR] on the LCD, "OFF" will appear in the display, confirming that the DNR system is no longer in operation.

RF GAIN

The RF Gain control provides manual adjustment of the gain levels for the receiver RF and IF stages, to account for noise and signal strength conditions at the moment.

- 1. The **RF GAIN** knob should, initially, be rotated to the fully clockwise position. This is the point of maximum receiver sensitivity.
- 2. Counter-clockwise rotation of the **RF GAIN** knob will gradually reduce the system gain.

ADVICE:

- ☐ As the **RF GAIN** knob is rotated counterclockwise to reduce the gain, the S-meter reading will rise. This indicates that the AGC voltage being applied to the receiver is increasing (this causes a *reduction* in receiver gain).
- Rotating the RF GAIN knob control to the fully counter-clockwise position will essentially disable the receiver, as the gain will be greatly reduced. In this case, the S-meter will appear to be "pegged" against the right edge of the analog S-meter scale.

QUICK POINT:

- Reception frequently can be improved by rotating the RF GAIN knob slightly counter-clockwise to the point where the "stationary" meter indication is set just about the same as the incoming noise level. This will reduce the RF gain to find a level of improved signal to noise ratio.
- □ The RF Gain control, along with the IPO and the Attenuator features, all affect the system receiver gain in different ways. The IPO generally should be the first feature engaged when dealing with a high noise level, or a crowded, high-level signal environment. Also, the IPO generally should be the first feature engaged, if the frequency is low enough to allow the preamplifier to be bypassed. Thereafter, the RF Gain and Attenuator features may be employed to provide precise, delicate adjustment of the receiver gain to fully optimize performance.



Audio Peak Filter

- 1. Press the **F(MLIST)** button to reveal the functions list on the TFT LCD display.
- 2. Touch **[APF]** on the LCD. The APF function will be set to "ON".



3. Rotate the **MULTI** knob to set the sound volume to a comfortable level.

ADVICE:

- □ The APF bandwidth can be selected from NAR-ROW/MEDIUM/WIDE via the Menu item "111 APF WIDTH".
- 4. To cancel the APF action, touch **[APF]** on the LCD. The "OFF" will appear in the display, confirming that the APF system is no longer in operation.

ADVICE:

The APF may only be activated while the transceiver is in CW mode.



AGC (AUTOMATIC GAIN CONTROL)

The AGC system is designed to help compensate for fading and other propagation effects. The AGC characteristics can be individually set for each operating mode. The basic objective of AGC is to maintain a constant audio output level once a certain minimum threshold of signal strength is achieved.

Press the **F(M-LIST)** button, then touch **[AGC]** on the LCD repeatedly to select the desired receiver-recovery time constant. You will observe the AGC status notation in the AGC column of the Key Function Display on the TFT display, denoting the AGC receiver-recovery time currently in use. For most operations, we recommend the "AUTO" mode. Additionally, you may disable the AGC by touching **[AGC]** on the LCD.



NOTE:

□ The "AUTO" selection mode selects the optimum receiver-recovery time for the reception mode.

In this case, the selected receiver-recovery time in the AGC column of the Key Function Display glows green (Normally it glows blue).

□ Touching [AGC] on the LCD allows selection of the desired receiver-recovery time constant. Normally, the "AUTO" selection is satisfactory for most situations, but in the event of operation on a crowded band where you wish to receive a weak signal, you may wish to change the setting to FAST. The AUTO mode selections are:

OPERATING MODE	AUTO AGC SELECTION
LSB/USB/AM	SLOW
CW/FM/DATA-FM	FAST
RTTY/DATA-LSB/DATA-USB	MID



ADVICE:

□ If the AGC receiver-recovery time is set to "Off" by touching [AGC] on the LCD, the S-meter will no longer deflect. Additionally, you will likely encounter distortion on stronger signals, as the IF amplifiers and the following stages are probably being overloaded.

QUICK POINT:

Several aspects of AGC performance may be configured via the Menu. However, because AGC can have such a profound impact on overall receiver performance, we generally do not recommend any changes to the AGC Menu selections until you are thoroughly familiar with the performance of the **FT-991A**.

TERMINOLOGY:

Automatic Gain Control, or AGC, is a circuit that senses the received signal strength, and then limits the gain of the RF and IF stages to keep the output audio volume at a more-or-less constant level. AGC also protects the RF, IF, Audio, and DSP stages from overload, as it limits the signal strength that is allowed to flow, irrespective of the input signal level.

ADJUSTABLE RECEIVER AUDIO FILTER

The **FT-991A** includes an adjustable receiver audio filter, that provides precise, independent control of the low; and upper audio ranges.

- 1. Press the **MENU** button to enter the Menu mode.
- 2. Rotate the MULTI knob to find Menu items "O41" through "O44" these parameters apply to the adjustment of the receiver audio filter in the AM mode, Menu items "O50" through "O53" apply to the adjustment of the RX audio filter in the CW mode, Menu items "O66" through "O69" apply to the adjustment of the RX audio filter in the DATA mode, Menu items "O92" through "O95" apply to the adjustment of the RX audio filter in the RTTY mode, and Menu items "102" through "105" apply to the adjustment of the RX audio filter in the SSB mode
- 3. Touch [**SELECT**] on the LCD.





- 4. Rotate the **MULTI** knob to adjust the receiver audio response as desired.
- 5. Touch [ENTER] on the LCD to save the new setting.



6. Press the **MENU** button or touch [**BACK**] on the LCD to exit to normal operation.

Mode	Menu Item	AVAILABLE VALUES
	041 AM LCUT FREQ	OFF/100(Hz) - 1000(Hz)
0.04	042 AM LCUT SLOPE	6dB/oct / 18dB/oct
Alvi	043 AM HCUT FREQ	700(Hz) - 4000(Hz)/OFF
	044 AM HCUT SLOPE	6dB/oct / 18dB/oct
	050 CW LCUT FREQ	OFF/100(Hz) - 1000(Hz)
CW	051 CW LCUT SLOPE	6dB/oct / 18dB/oct
000	052 CW HCUT FREQ	700(Hz) - 4000(Hz)/OFF
	053 CW HCUT SLOPE	6dB/oct / 18dB/oct
	066 DATA LCUT FREQ	OFF/100(Hz) - 1000(Hz)
	067 DATA LCUT SLOPE	6dB/oct / 18dB/oct
DATA	068 DATA HCUT FREQ	700(Hz) - 4000(Hz)/OFF
	069 DATA HCUT SLOPE	6dB/oct / 18dB/oct
	092 RTTY LCUT FREQ	OFF/100(Hz) - 1000(Hz)
DTTV	093 RTTY LCUT SLOPE	6dB/oct / 18dB/oct
NTTT	094 RTTY HCUT FREQ	700(Hz) - 4000(Hz)/OFF
	095 RTTY HCUT SLOPE	6dB/oct / 18dB/oct
	102 SSB LCUT FREQ	OFF/100(Hz) - 1000(Hz)
SCB	103 SSB LCUT SLOPE	6dB/oct / 18dB/oct
330	104 SSB HCUT FREQ	700(Hz) - 4000(Hz)/OFF
	105 SSB HCUT SLOPE	6dB/oct / 18dB/oct

SSB/AM Mode Transmission



- Press the **BAND** button to show the band list, and then touch a band key corresponding to the Amateur band on which you wish to operate.
- 2. Press the **MODE** button to show the mode list, and then select the operating mode by touching the corresponding key.

ADVICE:

By convention, LSB is used in the 7 MHz and lower Amateur bands for SSB communication, and USB is used on the 14 MHz and higher bands (the 10 MHz band is used for CW and data modes only).

- Rotate the Main Tuning Dial knob to adjust the operating frequency. Alternately, you may use the UP/ DWN scanning buttons on the MH-31A8J Hand Microphone to scan up or down the current band.
- 4. Press the microphone **PTT** (Push To Talk) switch to begin transmitting; speak into the microphone in a normal voice level.

ADVICE:

- □ The "♥♥" indicator will light up in the TFT LED indicators area, confirming that transmission is in progress.
- □ When transmitting in the AM mode, set a maximum (carrier) power output of 25 Watts by pressing [**RF PWR**], then rotate the **MULTI** knob.



 Adjust the microphone amplifier gain to match the microphone and your voice level: Touch [METER] on the LCD repeatedly to select the "ALC".

Press and hold the **PTT** switch, and speak into the microphone in a normal voice level.

In the SSB mode, touch [**MIC GAIN**] and then adjust **MULTI** knob so that the ALC meter stays within the ALC zone of the meter (up to half scale deflection) on voice peaks.

UF0-A 14.19500			
AMP1	CLAR		Онz
S 1 3 5 7 9 20 440 60 dB PO 5 10 50 100 150 W			
MOX	VOX	APF OFF	MONI
BACK	MIC-EQ OFF	PROC	FWD
METER PO	RF PWR	$\frac{M C GAIN}{2}$	SWEEP

In the AM mode, touch [**MIC GAIN**] and then adjust the **MULTI** knob so that the ALC meter does not deflect on voice peaks.

- □ When transmitting In the AM mode, adjust the MIC gain so that the PO meter does not deflect when speaking.
- 6. Release the **PTT** switch at the end of the transmission. The transceiver will return to the receive mode.

SSB/AM Mode Transmission

ADVICE:

- □ ALC meter deflection may be caused by excessive drive power, but also by reflected power detected in the antenna system. If the antenna impedance presented to the transceiver is other than 50 Ohms, ALC meter action may be observed that is not related to the proper setting of [MIC GAIN] on the LCD. Therefore, we recommend that you make [MIC GAIN] adjustments into a dummy load or antenna system presenting impedance very close to 50 Ohms.
- □ When making "on air" tests (such as setting the microphone gain), be sure to listen on the frequency before transmitting, to avoid interference to others who may already be using the frequency.

- ☐ Four techniques to implement Transmit/Receive control are provided on the FT-991A. You may choose the technique(s) that best suit your operating needs:
 - O Pressing the microphone **PTT** switch will engage the transmitter.
 - O The rear panel **PTT** jack may be connected to a foot switch or other manual switching device in order to engage the transmitter.
 - O Touching [MOX] on the TFT display functions list will lock the transmitter on (The functions list may be displayed by pressing the F(MLIST) button). Touch [MOX] on the LCD again to return to receive.



• O The VOX (Voice Operated Xmit) circuit will engage the transmitter automatically when you speak into the microphone. For details of VOX operation refer to page 72.

USING THE AUTOMATIC ANTENNA TUNER

The Automatic Antenna Tuner (hereinafter referred to as the "ATU") built into each **FT-991A** is designed to ensure a 50-Ohm load for the final amplifier stage of the transmitter.

ADVICE:

- □ Because the ATU of the **FT-991A** is located inside the station, it only adjusts the impedance presented to the transceiver at the station end of your coaxial cable feedline. It does not "tune" the SWR at the antenna feed point itself. When designing and building your antenna system, we recommend that every effort be made to ensure a low SWR at the antenna feed point.
- □ The ATU of the **FT-991A** includes 100 memories for tuning data. Eleven of these memories are allocated, one for each Amateur band, so that each band has at least one setting preset for use on that band. The remaining 89 memories are reserved for the 89 most-recent tuning points, for quick frequency change without the need to retune the ATU.
- □ The ATU in the **FT-991A** is designed to match impedances within the range of 16.7 Ohms to 150 Ohms, corresponding to an SWR of 3:1 or less on the 160 through 6 meter amateur bands. Accordingly, simple non-resonant whip antennas, along with random-length wires and the "G5RV" antenna (on most bands) may not be within the impedance matching range of the ATU.

ATU OPERATION

- 1. Use the Main Tuning Dial knob to set the radio to the desired operating frequency within the Amateur band.
- 2. Press the **TUNE** button momentarily to place the ATU in the transmit line (no adjustment/tuning will occur yet). The "**TUNER**" icon will appear in the display.

QUICK POINT:

The momentary press of the **TUNE** button will turn the tuner on, and the microprocessor will automatically select the tuning point closest to the current operating frequency.



- 3. Press and hold in the **TUNE** button for one second to begin automatic tuning. The transmitter will be engaged, and the "**TUNER**" icon will blink while tuning is in progress. When the optimum tuning point has been reached, the radio will return to receive, and the "**TUNER**" icon will again glow steadily (instead of blinking).
- 4. To disconnect the ATU from the transmit line, press the **TUNE** button momentarily. The "**TUNER**" icon will turn off, confirming that the ATU has been turned off. In the "Off" mode, the transceiver will be directly connected to the coaxial cable connected to your antenna, and will respond to whatever impedance is present at the station end of the coax.



ADVICE:

The ATU circuit is located between the final amplifier and the rear-panel antenna jack; reception is not affected by the ATU.

QUICK POINTS:

As shipped from the factory, only one ATU alignment point is saved on each Amateur band. This was memorized during the final alignment and performance verification stages on the production line.

NOTE:

Please listen to the operating frequency before beginning the tuning process, to be sure you are not interfering with others who may already be using the frequency.

TERMINOLOGY:

Antenna Tuner Memories: The ATU microprocessor makes a note of the selected tuning capacitors and inductors, and stores the data for each 10 kHz window in which tuning has occurred. This eliminates the need to re-tune every time you return to a frequency on which you have already completed the tuning process.

Using the Automatic Antenna Tuner

ABOUT ATU OPERATION

Figure 1 depicts a situation where normal tuning via the ATU has been successfully completed, and the tuning data has been stored in the ATU memory. The antenna system as seen by the transmitter is shown.

In Figure 2, the operator has changed frequency, and the "**HI-SWR**" icon has appeared. The operator presses and holds in the **TUNE** button for one second to begin impedance matching using the ATU.

If a high SWR condition exists (above 3:1), corrective action must be taken in the antenna system to bring the impedance closer to 50 Ohms. The ATU will refuse to memorize settings on frequencies where the SWR exceeds 3:1. A High SWR may indicate a mechanical failure in the feed system, and can lead to the generation of spurious signals causing TVI, etc.



About ATU Memories

SWR (After tuning) Less than 2:1

The tuner settings are stored in the ATU memory.

SWR (After tuning) Greater than 2:1

Tuning data will not be retained in memory. If you return to the same frequency, the tuning process must be repeated.

SWR (After tuning) Greater than 3:1

The "**HI-SWR**" icon will light up, and the tuner settings, if achieved, will not be memorized. Please investigate the high SWR condition and resolve the problem before attempting further operation using this antenna.

ENHANCING TRANSMIT SIGNAL QUALITY

PARAMETRIC MICROPHONE EQUALIZER (SSB/AM MODE)

The **FT-991A** includes a unique Three-Band Parametric Microphone Equalizer that provides precise, independent control over the low, mid and treble ranges in the voice waveform. You may utilize one group of settings when the speech processor is off and use an alternate group of settings when the speech processor is on. The speech processor feature is described in the next chapter.

QUICK POINT:

The Parametric Equalizer is a unique technique for adjusting the signal quality. The three audio ranges may be adjusted so precisely, it is possible to craft an audio response that provides a natural and pleasant sound that you may not have ever experienced before. Alternately, the effective "talk power" can be significantly enhanced.

The configuration aspects that may be adjusted on the Parametric Equalizer are:

- Center Frequency: The center frequency of each of the three bands may be adjusted.
- Gain: The amount of enhancement (or suppression) within each band may be adjusted.
- **Q**: The bandwidth over which the equalization is applied may be adjusted.

Setup of the Parametric Microphone Equalizer

- 1. Connect the microphone to the $\ensuremath{\text{MIC}}$ jack.
- 2. Set the RF output power to minimum value.

ADVICE:

- We recommend that you connect a dummy load to one of the Antenna jacks, and monitor your signal on a separate receiver, to prevent interference to other users.
- ☐ You will have the best chance of hearing the effects of adjustments if you wear headphones (connected to the separate monitor receiver) while listening to your transmitted signal.
- To adjust the Parametric Microphone Equalizer while the speech processor is disabled, press the F(M-LIST) button, then touch [MIC-EQ] to select "ON".



To adjust the Parametric Microphone Equalizer with the speech processor engaged, press the F(M-LIST) button, then touch [**PROC**] to select "ON".



4. Touch [**MONI**], if you want to listen on the **FT-991A** internal monitor.





- 5. Press the **MENU(SETUP)** button. The Menu list will appear in the TFT display.
- 6. Rotate the MULT knob to find the "EQ" Menu area, containing Menu items "119" through "127"; these parameters apply to the adjustment of the Parametric Microphone Equalizer when the speech processor is disabled. Menu items "128" through "136" apply to the adjustment of the Parametric Microphone Equalizer when the speech processor is engaged.
- 7. Touch [SELECT] on the LCD, then rotate the **MULT** knob to adjust a particular Menu item.



PARAMETRIC MICROPHONE EQUALIZER (SSB/AM MODE)

- 8. Press and hold the **PTT** switch, and speak into the microphone while listening to the effect of the changes you are making. Because the overall effect on the sound will change with each adjustment, make several passes through each adjustment area, to be sure that you achieve the optimum settings.
- 9. When all adjustments have been completed, touch [ENTER] on the LCD to save the new settings.



10. Press the **MENU(SETUP)** button or touch [**BACK**] on the LCD to return to normal operation. If you only touch [**BACK**] momentarily to exit the setup menu, none of the changes you performed will be stored.

ADVICE:

To roll off the excessive bass response prevalent in a wide-range of studio microphones, try setting the microphone equalizer for a 10 dB null at 100 Hz with a bandwidth of "1" or "2", a 3 dB null centered on 800 Hz with a bandwidth of "3", and then put an 8 dB peak centered on 2100 Hz with a bandwidth of "1." These are starting recommendations; each microphone and user's voice will be different, often requiring different settings.

PARAMETRIC MICROPHONE EQUALIZER (SSB/AM MODE)

Activating the Parametric Microphone Equalizer

- 1. Adjust [**MIC GAIN**] on the TFT display, as described on page 61.
- Press the F(M-LIST) button, then touch [MIC-EQ] on the TFT display to select "ON". If you use the Parametric Microphone Equalizer with the speech processor engaged, press the F(M-LIST) button, then touch [PROC] to display the PROC level (from 1 to 100), confirming that the Parametric Microphone Equalizer is engaged.





- 3. Press the **PTT** switch on the microphone, and speak into the microphone in a normal voice level.
- To switch the Parametric Microphone Equalizer off, touch [MIC-EQ] on the LCD again.



USING THE SPEECH PROCESSOR (SSB MODE)

The **FT-991A** Speech Processor is designed to increase "talk power" by increasing the average power output (via a sophisticated compression technique) and adjusting the audio quality to the menu settings ("128 P-PRMTRC EQ1 FREQ", "131 P-PRMTRC EQ2 FREQ", "134 P-PRMTRC EQ3 FREQ"). The result is improved intelligibility when conditions are difficult.

- 1. Adjust [**MIC GAIN**] on the TFT display, as described on page 61.
- 2. Touch [**METER**] on the TFT display to select "COMP" (Compression) meter.



3. Press the **F(M-LIST)** button, then touch [**PROC**] to display the PROC level (from 1 to 100), confirming that the Speech Processor is engaged.



- 4. Press the **PTT** switch on the microphone, and speak into the microphone in a normal voice level.
- 5. Adjust the **MULT** knob to set the compression level within the 5 dB to 10 dB range.
- 6. To switch the Speech Processor off, touch **[PROC]** on the TFT display once more. The "OFF" will appear in the display, confirming that the Speech processor is turned off.

ADVICE:

You may adjust the Parametric Microphone Equalizer when the speech processor is engaged, using Menu Items "128" through "136". See page 139 for details.



Adjusting the SSB Transmitted Bandwidth (SSB Mode)

For SSB transmission, a default bandwidth of 2.4 kHz is available. This bandwidth provides reasonable fidelity along with good talk power, and is the typical bandwidth used for decades for SSB transmission. The transmit bandwidth may be varied by the operator, to provide different levels of fidelity or talk power, according to individual preferences.

Here are the steps to adjust the SSB transmit bandwidth:

- 1. Press the **MENU(SETUP)** button to engage the Menu.
- 2. Rotate the **MULTI** knob to select Menu item "110 SSB TX BPF".
- 3. Touch [SELECT] on the TFT display, then rotate the MULTI knob to select the desired bandwidth. The available selections are: 100-3000 Hz, 100-2900 Hz, 200-2800 Hz, 300-2700 Hz, 400-2600 Hz. The default is 300-2700 Hz. A wider bandwidth will provide greater fidelity. A narrow bandwidth will compress the available transmitter power into less spectrum, resulting in more "talk power" for DX pile-ups.



4. Touch **[ENTER]** on the TFT display to save the new setting.



5. Press the **MENU(SETUP)** button or touch [**BACK**] on the TFT display to exit to normal operation.



ADVICE:

The Transmit Monitor function is a very helpful way to confirm the effect that changing the bandwidth will have on fidelity. To activate the Monitor function, press the F(MLIST) button to reveal the functions list on the TFT LCD display. Then touch the [MONI] button, you will be able to hear the difference in sound quality as you make bandwidth changes.

QUICK POINTS:

The higher fidelity associated with wide bandwidth will be particularly enjoyable on the low bands during local rag-chew QSOs.

TRANSMITTER CONVENIENCE FEATURES

VOICE MEMORY (SSB/AM MODES)

You may utilize the Voice Memory capability of the **FT-991A** for repetitive messages. The Voice Memory system includes five memories capable of storing up to 20 seconds of voice audio each. The maximum that any memory can hold is 20 seconds.

Voice Memory Operation

You may also utilize the Voice Memory capability of the **FT-991A** by operating from the display or the optional **FH-2** Remote Control Keypad, which plugs into the rear panel **REM/ALC** jack.

Recording Your Own Voice in Memory

- 1. Select the LSB, USB, or AM mode using the front panel **MODE** button.
- 2. Adjust [MIC GAIN] on the LCD, as described on page 61.
- 3. Touch **[MEM]** on the LCD or press the **[MEM]** key on the **FH-2**. A blinking "**REC**" icon will appear in the display.



 Touch [CH1] through [CH5] on the LCD or press any of the FH-2 keys numbered [1] through [5] to select that memory storage register.





ADVICE:

If you do not press the **PTT** key (see next step) within five seconds, the memory storage process will be cancelled.

- Press the microphone PTT switch momentarily. The "REC" icon will glow steadily and recording will begin.
- 6. Speak into the microphone in a normal voice level to record the message (such as "CQ DX, CQ DX, this is W 6 Delta X-Ray Charlie, W 6 Delta X-Ray Charlie, Over"). Remember that the time limit for recording any message is 20 seconds.

 Touch [MEM] on the LCD or press the FH-2 [MEM] key to complete the message storage process.



Checking Your Recording

- Be sure that [VOX] and [BK-IN] functions are "Off" so transmit will not be activated. The function statuses may be observed on the TFT display by pressing the F(M-LIST) button.
- Touch [CH1] [CH5] on the LCD or press the FH-2
 [1] [5] key (whichever register you just recorded in). The "PLAY" icon will appear in the display and you will hear the contents of the Voice Memory you just recorded.



ADVICE:

The playback level of the recording may be adjusted via Menu item "O10 DVS RX OUT LEVEL".
VOICE MEMORY (SSB/AM MODES)

Transmitting the Recorded Message

- 1. Select the LSB, USB, or AM mode using the front panel **MODE** button.
- Press the front panel F(M-LIST) button to reveal the functions list on the TFT LCD display, then touch [BK-IN] on the LCD.



Touch [CH1] - [CH5] on the LCD or press the FH-2
 [1] - [5] key (whichever register you just recorded in). A "PLAY" icon will appear in the display and the message will be transmitted.



ADVICE:

The transmit (audio) level of the recording may be adjusted via Menu item "O11 DVS TX OUT LEVEL".

Transmitter Convenience Features

VOX (SSB/AM/FM MODES: AUTOMATIC TX/RX SWITCHING USING VOICE CONTROL)

Instead of using the microphone **PTT** switch or the [**MOX**] function (that may be displayed by pressing the **F(M-LIST)** button) to activate the transmitter, the VOX (Voice Operated Transmit) system may be used for hands-free activation of the transmitter, by the voice input to the microphone.

1. Press the **F(M-LIST)** button, to reveal the functions list on the TFT LCD display, then touch **[VOX]** on the LCD to activate the function, "ON" will appear in the display.



- 2. Without pressing the **PTT** switch, speak into the microphone in a normal voice level. When you start speaking, the transmitter should be activated automatically. When you finish speaking, the transceiver should return to the receive mode (after a short delay).
- 3. To cancel VOX and return to **PTT** operation, touch [**VOX**] on the LCD once more. The "**VOX**" indication will turn OFF, signifying that the VOX circuitry has been turned off.

ADVICE:

- □ The VOX Gain may be adjusted to prevent accidental transmitter activation in a noisy environment. To adjust the VOX Gain:
 - 1) Activate the VOX circuitry, if necessary.
 - Press the MENU(SETUP) button to engage the Menu mode.
 - 3) Rotate the **MULTI** knob to select Menu item "143 VOX GAIN", then touch [**SELECT**] on the LCD.



- 4) While speaking into the microphone, rotate the MULTI knob to the point where the transmitter is quickly activated by your voice, without background noise causing the transmitter to activate.
- 5) When you are satisfied with the setting, touch [ENTER] on the TFT LCD display to save the new setting.





- 6) Press the **MENU(SETUP)** button or touch [**BACK**] on the LCD to exit to normal operation.
- □ The "Hang-Time" of the VOX system (the transmit/ receive delay after the cessation of speech) may also be adjusted via the Menu mode. The default delay is 500 msec. To set a different delay time:
 - 1) Activate the VOX circuitry, if necessary.
 - 2) Press the **MENU(SETUP)** button to engage the Menu mode.
 - Rotate the MULTI knob to select Menu item "144 VOX DELAY", then touch [SELECT] on the LCD.



4) Rotate the **MULTI** knob while saying a brief syllable like "Ah" and listening to the hang time for the desired delay.

VOX (SSB/AM/FM MODES: AUTOMATIC TX/RX SWITCHING USING VOICE CONTROL)

5) When you are satisfied with the setting, touch [**ENTER**] on the TFT LCD display to save the new setting.



- Press the MENU(SETUP) button or touch [BACK] on the LCD to exit to normal operation.
- □ The Anti-Trip setting adjusts the level of negative receiver audio feedback to the microphone, to prevent receiver audio from activating the transmitter (via the microphone). This setting can also be adjusted via Menu item "145 ANTI VOX GAIN".
- □ VOX operation may be engaged on either Voice modes (SSB/AM/FM) or on AFSK-based Data modes. Use Menu item "142 VOX SELECT" (the selections are "MIC" and "DATA").

Transmitter Convenience Features

MONITOR (SSB/AM modes)

You may listen to the quality of your transmitted signal using the Monitor feature.

- 1. Touch [**MONI**] displayed by pressing the **F(M-LIST)** button to reveal the functions list on the TFT LCD display.
- 2. Touch [**MONI**] on the LCD, the Moniter function will be set to "ON". The **MULTI** knob serves as the MONITOR adjustment knob.

MONI (Monitor) indicator



- 3. During transmission, rotate the **MULTI** knob to adjust the audio level in the Headphones or speaker. Clockwise rotation of this knob will increase the volume level.
- 4. To switch the Monitor off again, touch [**MONI**] on the LCD once more. "OFF" will be displayed, confirming that the Monitor function is disengaged.

ADVICE:

Because the Monitor feature samples the transmitter IF signal, it can be very useful for checking the adjustment of the Speech Processor or Parametric Equalizer on SSB, and for checking the general signal quality on AM.



SPLIT OPERATION USING THE TX CLARIFIER

For split TX/RX operation in "casual" pile-ups, where the split is less than 10 kHz, the TX Clarifier (Offset Tuning) feature may be utilized.

- 1. Press the **MENU(SETUP)** button to enter the Menu mode.
- Rotate the MULTI knob to select Menu item "040 CLAR MODE SELECT".
- Touch [SELECT] on the LCD, then rotate the MULTI knob to set this Menu item to "TX" (the default setting is "RX").



4. Touch [ENTER] on the LCD to save the new setting.



- 5. Press the **MENU(SETUP)** button or touch [**BACK**] on the LCD to exit to normal operation.
- 6. Press the **CLAR** button. The "**TX**" icon will appear in the TFT display.



QUICK POINT:

The Clarifier is frequently used for receiver offset tuning. However, for DX pile-ups where the DX station is using a split of less than 10 kHz, the TX Clarifier function is usually the quickest way to set the transmitter to the desired offset frequency.



- Rotate the CLAR/VFO-B knob to set the desired transmitter offset. A maximum split of ±9.999 kHz may be set.
- To exit from TX Clarifier operation, press the CLAR button once more. The "TX" icon will disappear from the display.

ADVICE:

- When listening to a "pile-up" calling a DX station, in order to find the station currently being worked, you may press the CLAR button. Then, use the CLAR/
 VFO-B knob to zero in on the station calling the DX (use the SPOT function on CW for precise alignment of your frequency). You may then press the CLAR button again to cancel the RX Clarifier, and return to reception on the DX station's frequency.
- Just as with receiver Clarifier operation, the amount of offset from the original VFO frequency will appear in the display.
- ☐ As with receiver Clarifier operation, when you turn the TX Clarifier off, the last-used offset is remembered, and will be available if you turn the TX Clarifier back on. To clear the Clarifier offset, press and hold the CLAR button for more than 1 second.

QUICK POINT:

When attempting to work a DX station on CW in a split frequency pile-up, remember that a large number of other stations may also be using Yaesu transceivers with capability similar to that of your **FT-991A**. On the DX side of the pile-up, everyone calling precisely on the same CW frequency will sound like a single tone! So you may have more success if you use the RX Clarifier to find a *hole* in the pile-up, instead of trying to zerobeat the last station worked by the DX station.

Transmitter Convenience Features

SPLIT-FREQUENCY OPERATION

A powerful capability of the **FT-991A** is its flexibility in Split Frequency operation using the VFO-A and VFO-B frequency registers. This makes the **FT-991A** especially useful for high-level DX-peditions. The Split operation capability is very advanced and easy to use.

- 1. Rotate the Main Tuning Dial knob to set the desired RX frequency.
- Press the A/B button, then rotate the Main Tuning Dial knob to set the desired split TX frequency.
- Press the A/B button, then press the SPLIT button. The VFO-B frequency will be shown in the TFT display and the LED indicators will appear as below:
 VFO-A RX Indicator: "ON" (LED glows Green)
 VFO-A TX Indicator: "OFF" (LED Off)
 VFO-B RX Indicator: "OFF" (LED Off)
 VFO-B TX Indicator: "ON" (LED glows Red)



During Split operation, the VFO-A register will be used for reception, while the VFO-B register will be used for transmission. If you press the **SPLIT** button once more, Split operation will be cancelled.

ADVICE:

- During Split operation, pressing the A/ B button will reverse the contents of VFO-A and VFO-B. Press the A/B button once more to return to the original frequency alignment.
- During Split operation you may listen to the TX frequency temporarily while pressing the **TXW** button located on the bottom left of the Main Tuning Dial knob.

While pressing the **TXW** button during split operations, the frequency of transmit on VFO-B can be changed.

During Split operation it is also possible to set VFO-A and VFO-B to different Amateur bands if a multi band antenna is used.

Quick Split Operation

The Quick Split feature allows setting a one-touch offset of +5 kHz compared to the VFO-A frequency, to be applied to the transceiver VFO-B (transmit) frequency,

- Start with regular transceiver operation on the VFO-A.
 VFO-A RX Indicator: "ON" (LED glows Green)
 VFO-A TX Indicator: "ON" (LED glows Red)
 VFO-B RX Indicator: "OFF" (LED Off)
 VFO-B TX Indicator: "OFF" (LED Off)
- Press and hold in the SPLIT button for one second to engage the Quick Split feature, and apply a frequency 5 kHz above the VFO-A frequency to the VFO-B frequency register.

The VFO configuration will then be: VFO-A RX Indicator: "ON" (LED glows Green) VFO-A TX Indicator: "OFF" (LED Off) VFO-B RX Indicator: "OFF" (LED Off) VFO-B TX Indicator: "ON" (LED glows Red)

3. Press and hold in the **SPLIT** switch for one second to increment the Sub (VFO-B) offset frequency another +5 kHz.

QUICK POINTS:

The offset of VFO-B from VFO-A is programmed via the Menu and is set to +5 kHz at the factory. However, other offsets may be selected using the following procedure:

୶ໞໞ୰୶୶ໞໞ୰୶୶ໞໞ୰୶୶୶୶୰୶ଽ୰୶ଽ୰୶ଽ୰୶ଽ୶୶୰୶ଽ୶୶ଽ

- 1. Press the **MENU(SETUP)** button to engage the Menu mode.
- Rotate the MULTI knob to select Menu item "O35 QUICK SPLIT FREQ".
- 3. Touch [SELECT] on the LCD, then rotate the MULT knob to select the desired offset. The available setting range is -20kHz +20kHz (factory default: +5 kHz).



SPLIT-FREQUENCY OPERATION

4. Touch [ENTER] button to save the new setting.



5. Press the **MENU(SETUP)** button or touch [**BACK**] on the LCD to exit to normal operation.

CW Mode Operation

The powerful CW operating capabilities of the **FT-991A** permit operation using an electronic keyer paddle, a "straight key", or a computer-based keying device.

SETUP FOR STRAIGHT KEY (AND STRAIGHT KEY EMULATION) OPERATION

Before starting, connect your key line(s) to the front panel **KEY** jack. Be sure [BK-IN] displayed by pressing the **F(M-LIST)** button is turned off for now.

 Press the MODE button, then touch [CW-LSB] or [CW-USB] on the TFT LCD display. The "C-L" or "C-U" icon will appear in the display. The CW monitor is activated.

vfo-A c-u speed	4.02	141462 2500
AMP1	CLAR	Онz
LSB	USB	AM
CW-LSB	CW-USB	FM
RTTY-LSB	RTTY-USB	C4FM
DATA-LSB	DATA-USB	DATA-FM

- 2. Rotate the Main Tuning Dial knob to select the desired operating frequency.
- 3. Press the **F(M-LIST)** button, then touch [**BK-IN**] on the LCD to engage automatic activation of the transmitter when you close the CW key. The Break-in will be set to "ON".



ADVICE:

- □ When you close the CW key, the transmitter will automatically be activated, and the CW carrier will be transmitted. When you release the key, transmission will cease, and after a brief delay, receive will be restored. The delay time is userprogrammable per the discussion on page 85.
- ☐ As shipped from the factory, the FT-991A TX/ RX system for CW is configured for "Semibreak-in" operation. However, using Menu item "D56 CW BK-IN TYPE", you may change this setup for full break-in (QSK) operation, whereby the switching is quick enough to hear incoming signals in the spaces between the dots and dashes of your transmission. This may prove very useful during contest and traffic handling operations.
- 4. CW operation using the CW key may now proceed.



ADVICE:

- □ The CW sidetone audio level may be adjusted by setting "MONITOR" (see page 74).
- □ You may practice sending CW listening to the sidetone only, without having the signal transmitted out over the air, if you press the front panel F(M-LIST) button to reveal the functions list on the TFT LCD display, and then touch the [BK-IN] button to set break-in to Off.
- □ If you reduce transmit power via the [**RF PWR**] function that may be displayed by pressing the **F(M-LIST)** button, the ALC meter reading will increase; this is normal and does not indicate any problem whatsoever (because increased ALC voltage is being used to lower the power).
- □ To enable the keying operation in LSB/USB mode and send the CW signal without switching to CW mode, change Menu item "O55 CW AUTO MODE".
- □ The same frequency may be displayed when switching between SSB mode and CW mode by setting Menu item "059 CW FREQ DISPLAY".
- By connecting the FT-991A to a computer, CW can be operated using free or commercially available software and setting Menu item "O60 PC KEYING".

SETUP FOR STRAIGHT KEY (AND STRAIGHT KEY EMULATION) OPERATION

TERMINOLOGY: Semi-break-in

This is a pseudo-"VOX" mode used on CW, whereby the closure of the CW key will engage the transmitter, and release of the key will allow the receiver to recover after a short delay. No signals will be heard during the spaces between dots and dashes (unless the sending speed is extremely slow).

Full break-in

Full break-in (also known as "Full QSK") involves very fast switching between transmit and receive, incoming signals may be heard between the dots and dashes as you send them. This allows you to hear a station that suddenly starts transmitting on your frequency, while you are in the midst of a transmission.

CW Mode Operation

USING THE BUILT-IN ELECTRONIC KEYER

Connect the cable from your keyer paddle to the front panel **KEY** jack.

 Press the MODE button, then touch [CW-LSB] or [CW-USB] on the TFT LCD display. The "C-L" or "C-U" icon will appear in the display. The CW monitor is activated.



- 2. Rotate the Main Tuning Dial knob to select the desired operating frequency.
- 3. Press the **F(M-LIST)** button, then touch [**KEYER**] on the LCD to select "ON" to confirm that the built-in Electronic Keyer is now active.



- Touch [SPEED] on the LCD, then rotate the MULTI knob to set the desired sending speed (4 60 WPM).
 ADVICE:
 - □ Rotate the **MULTI** knob to display the keying speed (4 60 WPM) below the [**SPEED**] indicator.
 - □ By pressing either the "Dot" or "Dash" side of the paddle, the CW keying tone will automatically be generated.
- 5. Touch [**BK-IN**] on the TFT display to engage automatic activation of the transmitter when either the "Dot" or "Dash" side of the paddle is pressed. The Break-in will be set to "ON".



6. CW operation utilizing the CW paddle may now commence.



ADVICE:

- □ When the keyer paddle is pressed, the transmitter will automatically be activated, and the CW characters (or a string of dots or dashes) will be transmitted. When the keyer paddle is released, transmission will cease, and after a brief delay, reception will be restored. The delay time is user-programmable, per the discussion on page 85.
- The CW sidetone audio level may be set using "MONITOR" (see page 74).
- □ If [BK-IN] is set to "OFF", you may practice sending CW with the sidetone only, without having the signal go out over the air. (Press the front panel F(M-LIST) button to reveal the functions list on the TFT display).
- □ If the transmitter power is reduced via [**RF PWR**] function, the ALC meter reading will increase; this is normal and does not indicate any problem whatsoever (because increased ALC voltage is being used to lower the power).
- The keying operation may also be enabled in LSB/ USB mode to send the CW signal via the Menu item "O55 CW AUTO MODE" without switching to CW mode.
- □ The same frequency may be displayed when switching between SSB mode and CW mode by setting Menu item "059 CW FREQ DISPLAY".
- By connecting a computer, CW can be operated using free or commercially available software and setting Menu item "O60 PC KEYING".
- □ The electronic keyer operation mode can be changed via the Menu item "O12 KEYER TYPE".

USING THE BUILT-IN ELECTRONIC KEYER



A number of interesting and useful features are available for use with the Electronic Keyer operation.

Setting the Keyer Weight (Dot/Dash) Ratio

This Menu item may be used to adjust the dot/dash ratio for the built-in Electronic Keyer. The default weighting is 3:1 (a dash is three times longer than a dot).

- 1. Press the **MENU(SETUP)** button to engage the Menu.
- Rotate the MULTI knob to select Menu item "O14 CW WEIGHT".
- Touch the [SELECT] button, and then rotate the MULTI knob to set the weight to the desired value. The available adjustment range is a Dot/ Dash ratio of 2.5 - 4.5 (default value: 3.0).



 When your adjustments are complete, touch [EN-TER] on the LCD to save the new setting.



5. Press the **MENU(SETUP)** button or touch [**BACK**] on the LCD to exit to normal operation.

CW Mode Operation

USING THE BUILT-IN ELECTRONIC KEYER

Selecting the Keyer Operating Mode

The configuration of the Electronic Keyer may be customized independently for the front panel **KEY** jack of the **FT-991A**. This permits utilization of Automatic Character Spacing (ACS), if desired. This allows the use of an electronic keyer via the front jack and a straight key or computer-driven keying line via the rear panel jack.

- 1. Press the **MENU(SETUP)** button to engage the Menu.
- 2. Rotate the **MULTI** knob to select Menu item "O12 KEYER TYPE".
- Press the [SELECT] button, and then rotate the MULTI knob to set the keyer to the desired mode. The available selections are:
 - OFF: The built-in Electronic Keyer is turned off ("straight key" mode).
 - BUG: Dots will be generated automatically by the keyer, but dashes must be sent manually.
 - ELEKEY-A: A code element ("Dot" or "Dash" side) is transmitted upon releasing both sides of the paddle.
 - ELEKEY-B: Releasing both sides of the paddle transmits the currently generated "Dash" side followed by "Dot" side (or reverse order).
 - ELEKEY-Y: Pressing both sides of the paddle transmits the currently generated "Dash" side followed by "Dot" side (or reverse order).

While transmitting the "Dash" side, the first transmitted "Dot" side will not be stored.

ACS: Same as "ELEKEY" except that the spacing between characters is precisely set by the keyer to be the same length as a dash (three dots in length).



MENU(SETUP) Button

 When the adjustments are complete, touch [EN-TER] on the LCD to save the new setting.



5. Press the **MENU(SETUP)** button or touch [**BACK**] on the LCD to exit to normal operation.

USING THE BUILT-IN ELECTRONIC KEYER

Reversing the Keyer Polarity

For left-handed operators in a contest, for example, the polarity can be reversed easily in the Menu mode without changing the keyer connection (the default setting is "NOR").

- 1. Press the **MENU(SETUP)** button to engage the Menu.
- 2. Rotate the **MULTI** knob to select Menu item "O13 KEYER DOT/DASH".
- 3. Press the [SELECT] button, then rotate the MULTI knob to select "REV."



4. Touch [**ENTER**] on the LCD to save the new setting.



5. Press the **MENU(SETUP)** button or touch [**BACK**] on the LCD to exit to normal operation.



ADVICE:

□ In the steps on the left, only polarities of the ELEKEY and ACS keyers can be changed.

CW Convenience Features

CW Spotting (Zero-Beating)

"Spotting" (zeroing in on a received CW station) is a handy technique to ensure you and the other station are precisely on the same frequency.

The Tuning Offset Indicator in the display may also be observed so you can adjust the receiver frequency to center the incoming station on the pitch corresponding to that of your transmitted signal.

Using the Auto Zeroing System

Press the **F(M-LIST)** button, then touch [**ZIN**] on the LCD to cause the receiving frequency to zero-in automatically while receiving the CW signal.





Using the SPOT System

- 1. Press the **F(M-LIST)** button to display the function list.
- 2. Touch [**MONI**] on the LCD. The Monitor function will be set to "ON". The **MULTI** knob will function as the MONITOR adjustment knob.



3. Touch [**SPOT**] on the LCD. While you are pressing and holding [**SPOT**], the tone is output from the speaker.





ADVICE:

In a tough DX pile-up, you may actually want to use the SPOT system to find a "gap" in the spread of calling stations, instead of zeroing in precisely on the last station being worked by the DX station. From the DX side, if a dozen or more operators (also using Yaesu's SPOT system) all call precisely on the same frequency, their dots and dashes merge into a single, long tone that the DX station cannot decipher. In such situations, calling slightly higher or lower in frequency may get your call through.

QUICK POINTS:

□ The displayed frequency on CW normally reflects the "zero beat" frequency of your offset carrier. That is, if you were to listen on USB on 14.100.00 MHz to a signal with a 700 Hz offset, the "zero beat" frequency of that CW carrier would be 14.100.70 MHz; the latter frequency is what the **FT-991A** displays, by default. However, you can change the display to be identical to what you would see on SSB by using Menu item "O59 CW FREQ DISPLAY" and setting it to "DIRECT FREQ" instead of the default "PITCH OFFSET" setting.

CW Convenience Features

CW DELAY TIME SETTING

During semi-break-in (not QSK) operation, the hang time of the transmitter, after you have finished sending, may be adjusted to a comfortable value consistent with your sending speed. This is the functional equivalent of the "VOX Delay" adjustment used on voice modes, and the delay may be varied anywhere between 30 msec and 3 seconds via Menu item "D57 CW BK-IN DELAY".

 Press the F(M-LIST) button to display the function list, then touch [BK-IN] on the LCD to enable CW transmission (Menu item "056 CW BK-IN TYPE" must be set to "SEMI").



- 2. Press the **MENU(SETUP)** button to enter the Menu mode.
- Rotate the MULTI knob to select Menu item "057 CW BK-IN DELAY", then touch [SELECT] on the LCD.





- 4. Start sending and rotate the **MULTI** knob to adjust the hang time, as you prefer for comfortable operation.
- 5. When the adjustments are complete, touch [**ENTER**] on the LCD to save the new setting.



6. Press the **MENU(SETUP)** button or touch [**BACK**] on the LCD to exit to normal operation.

CW PITCH ADJUSTMENT

The center frequency of the receiver passband may be adjusted to the CW tone you prefer. By touching [**PITCH**] on the LCD, the pitch of the CW offset carrier may be varied between 300 Hz and 1050 Hz, in 10 Hz steps.

 Press the F(M-LIST) button to display the function list, then touch [PITCH] on the LCD. The MULTI knob functions as the PITCH adjustment knob.



2. Rotate the **MULTI** knob to adjust the PITCH (300 Hz to 1,050 Hz).



TERMINOLOGY:

CW Pitch: If the receiver is tuned to an exact "zero beat" on an incoming CW signal, you could not copy it ("Zero beat" implies a 0 Hz tone). Therefore, the receiver is offset several hundreds of Hz (typically), to produce a beat tone that can be heard. The BFO offset associated with this tuning (that produces the comfortable audio tone) is called the CW Pitch.

The CW message capability of the **FT-991A** may be utilized from the optional **FH-2** Remote Control Keypad, which plugs into the rear panel **REM/ALC** jack.

Message Memory

Five memory channels capable of retaining 50 characters each are provided (using the PARIS standard for characters and word length).

Example: CQ CQ CQ DE W6DXC K (19 characters)

(C) (Q) (C) (Q) (C) (Q) (D)(E) (W) (6) (D) (X) (C) (K)

STORING A MESSAGE INTO MEMORY

- 1. Press the **MENU(SETUP)** button to enter the Menu mode.
- 2. Rotate the **MULTI** knob to select the CW Memory Register into which you wish to store the message; for now, we are just setting the message entry technique to (Keyer entry).

018 CW MEMORY 1 019 CW MEMORY 2 020 CW MEMORY 3 021 CW MEMORY 4 022 CW MEMORY 5

 Touch [SELECT] on the LCD, then rotate the MULTI knob to set the selected CW Memory Register to "MESSAGE". If you want to use your keyer paddle for message entry on all memories, set all five Menu items (#018 - #022) to "MESSAGE".





4. Touch [ENTER] on the LCD to save the new setting.



5. Press the **MENU(SETUP)** button or touch [**BACK**] on the LCD to exit to normal operation.

TERMINOLOGY:

PARIS Word Length: By convention among CW and Amateur operators (utilized by ARRL and others), the length of one "word" of CW is defined as the length of the Morse Code characters spelling the word "PARIS". This character (dot/dash/space) length is used for the specific definition of code speed in "words per minute".

Contest Number Programming

Use this process if you are starting a contest, or if you somehow get out of sync with the proper number in the middle of a contest.

- 1. Press the **MENU(SETUP)** button to enter the Menu mode.
- 2. Rotate the **MULTI** knob to select Menu item "O17 CONTEST NUMBER". The current contest number appears on the TFT display.
- Touch [SELECT] on the LCD, then rotate the MULTI knob to set the Contest Number to the desired value.

ADVICE:

Touch [BACK] on the LCD to cancel the setting.





4. Touch [ENTER] on the LCD to save the new setting.



 Press the MENU(SETUP) button or touch [BACK] on the LCD to exit to normal operation.

Contest Memory Keyer

MESSAGE MEMORY PROGRAMMING (USING YOUR PADDLE)

- 1. Set the operating mode to CW.
- 2. Set [**BK-IN**] on the LCD to "Off".
- 3. Set [**KEYER**] on the LCD to "On".
- Touch [MEM] on the LCD or press the [MEM] key on the FH-2. A blinking "REC" icon will appear in the display.





 Touch [CH1] through [CH5] on the LCD or press any of the FH-2 keys numbered [1] through [5] to begin the memory storage process, and the "REC" icon will glow steadily.



6. Send the desired message using your keyer paddle. **ADVICE:**

If you do not start keying within ten seconds, the memory storage process will be cancelled.

 Touch [MEM] on the LCD or press the [MEM] key on the FH-2 once more at the end of your message. Up to 50 characters may be stored in each of the five memories.





Note:

Care must be exercised when sending to ensure that the spaces between letters and words are accurately done; if the timing is off, the spacing may not come out right in the stored message. For ease in setting up the keyer memories, we recommend setting Menu item "O12 KEYER TYPE" to "ACS" (Automatic Character Spacing) while programming the keyer memories.

CHECKING THE CW MEMORY CONTENTS

- 1. Be sure that Break-in is still turned "Off" by [**BK-IN**] on the LCD.
- 2. Touch [MONI] on the LCD to enable the CW monitor.
- Touch [CH1] [CH5] on the LCD or press the FH-2
 [1] [5] key, whichever memory you just recorded in. You will hear the message played in the sidetone monitor, but no RF energy will be transmitted.



ON-THE-AIR CW MESSAGE PLAYBACK

- Touch [BK-IN] on the LCD to enable transmission. Either Full- or Semi-break-in will be engaged, depending on the setting of Menu item "056 CW BK-IN TYPE".
- Touch [CH1] [CH5] on the LCD or press the FH-2
 [1] [5] key, depending on which CW Memory Register message you wish to transmit. The programmed message will be transmitted on the air.



Note:

If you subsequently decide to use the "Text Memory" technique for memory storage, please note that a message stored using keyer paddle input will not be transferred over when you select "Text Memory technique" on a particular memory register (the Menu Mode Setting is set to "TEXT").

TEXT Memory

The five channels of CW message memory (up to 50 characters each) may also be programmed using a text-entry technique. This technique is somewhat slower than sending message directly from the keyer paddle, but accuracy of character spacing is ensured. Be sure to enter the character "}" at the end of the text message.

Example 1: CQ CQ CQ DE W6DXC K} (20 characters)

The sequential Contest Number ("Count up") feature is another powerful feature of the CW Memory Keyer.

Example 2: 599 10 200 # K} (15 characters)

TEXT MEMORY STORAGE

- 1. Press the **MENU(SETUP)** button to enter the Menu mode.
- 2. Rotate the **MULTI** knob to select the CW Memory Register into which you wish to store the message; we are now setting the message entry technique to (Text entry).

018 CW MEMORY 1 019 CW MEMORY 2 020 CW MEMORY 3 021 CW MEMORY 4 022 CW MEMORY 5

ADVICE:

The following texts are programmed to the MEM-ORY 4 and MEMORY 5 in factory default. MEMORY 4: DE FT-991 K} MEMORY 5: R 5NN K}

- 3. Touch [SELECT] on the LCD, then rotate the **MULTI** knob to set the selected CW Memory Register to "TEXT". If you want to use text message entry on all memories, set all five Menu items (#018 #022) to "TEXT".
- 4. Touch **[ENTER]** on the LCD to save the new setting.
- 5. Press the **MENU(SETUP)** button or touch [**BACK**] on the LCD to exit to normal operation.



TEXT	CW CODE	TEXT	CW CODE	TEXT	CW CODE	TEXT	CW CODE	TEXT	CW CODE	TEXT	CW CODE
!	SN	&	AS	+	ĀR	:	ŌS	?	IMI	^	_
"	ĀF	,	WG	,	MIM	;	KR	@	@	_	ĪQ
#	_	(KN	-	DU	<		[_	}	_
\$	SX)	KK		ĀĀĀ	=	BT	¥ (_)	AL		
%	KA	*		/	DN	>		}			

Text Message Programming

- Press the MODE button to set the operating mode to CW.
- 2. Be sure that Break-in is "Off" with [**BK-IN**] on the LCD, if necessary.
- Touch [MEM] on the LCD or press the FH-2 [MEM] key. A blinking "REC" icon will appear in the display.



4. Touch [CH1] - [CH5] on the LCD or press an FH-2
[1] - [5] key to select the desired CW Memory Register into which you wish to program the text. The text input screen will appear.



- 5. Touch a key on the LCD to enter the letters, numbers, or symbols of the desired label.
- 6. Repeat step 5 to program the remaining letters, numbers, or symbols of the desired text. 12 characters may be used in the creation of a text.

Use [I] and [I] on the LCD to set the cursor position and [I] on the LCD to erase a letter at the left of the cursor.

 When you have completed the creation of the text, touch [ENT] on the LCD.



ADVICE:

Use the **FH-2** $[\blacktriangleleft]$ and $[\blacktriangleright]$ keys to set the cursor position and use the **FH-2**'s $[\blacktriangle]$ and $[\blacktriangledown]$ keys to choose the letter/number to be programmed in each slot of the memory. In the case of the second example on the previous page the "#" character designates the slot where the Contest Number will appear.



- 8. When the message is complete, add the "**}**" character at the end to signify the termination of the message.
- Touch [MEM] on the LCD or press and hold in the FH-2 [MEM] key for one second to exit, once all characters (including ")") have been programmed.

CHECKING THE CW MEMORY CONTENTS

- Be sure that Break-in is still turned "Off" with [BK-IN] on the LCD.
- 2. Touch [MONI] on the LCD to enable the CW monitor.
- Touch [CH1] [CH5] on the LCD or press an FH-2
 [1] [5] key, whichever memory you just recorded in. You will hear the results in the sidetone, but no RF energy will be transmitted.





Inputting the CW TEXT directly on the screen

Without using the remote control keypad **FH-2**, you can also input the CW TEXT directly on the screen.

- 1. Press and hold the **MENU(SETUP)** button.
- 2. Touch [**CW TEXT**] on the LCD. The CW text display screen will appear.



3. Rotate the **MULTI** knob to select the CW TEXT you want to input, then touch [**EDIT**]. The text input screen will appear.



4. Touch a key on the LCD to enter the letters, numbers, or symbols of the desired text.



- Repeat step 4 to program the remaining letters, numbers, or symbols of the desired text. 12 characters may be used in the creation of a text. Use [I←] and [→] on the LCD to set the cursor position and [43] on the LCD to erase a letter at
- the left of the cursor.6. When you have completed the creation of the text, touch [ENT] on the LCD.



7. Press the **MENU(SETUP)** button to save the new setting and return to normal operation.

CW Convenience Features

CONTEST MEMORY KEYER

ON-THE-AIR CW MESSAGE PLAYBACK

- Touch [BK-IN] on the LCD to enable transmission. Either Full-break-in or Semi-break-in will be engaged, depending on the setting of Menu item "D56 CW BK-IN TYPE".
- Touch [CH1] [CH5] on the LCD or press an FH-2
 [1] [5] key, depending on which CW Memory Register message you wish to transmit. The programmed message will be transmitted on the air.



Note:

If you subsequently decide to use the "Message Memory" technique for memory storage, please note that the contents of a message stored using text input will not be transferred over when you set entry to "Message Memory technique" on a particular memory register (the Menu Mode Setting is set to "MESSAGE").

Decrementing the Contest Number

Use this process if the current contest number gets slightly ahead of the actual number you want to send (in case of a duplicate QSO, for example).

Press the **FH-2** [**DEC**] key or touch [**DEC/DEL**] on the LCD momentarily. The current Contest Number will be reduced by one. Press of the **FH-2** [**DEC**] key or touch [**DEC/DEL**] on the LCD as many times as necessary to reach the desired number. If you go too far, use the "Contest Number Programming" technique described previously.

Transmitting in the Beacon Mode

In "Beacon" mode, it is possible to repeatedly transmit any message programmed, either via paddle input, or via the "Text" input method. The time delay between message repeats may be set anywhere between 1 and 690 seconds (1 - 240 sec (1 sec/step) or 270 - 690 sec (30 sec/step)) via Menu item "O15 BEACON INTERVAL" If you do not wish the message to repeat in a "Beacon" mode, please set this Menu item to "OFF".

To transmit the message:

- 1. Touch **[BK-IN]** on the LCD to enable transmission. Either Full-break-in or Semi-breakin will be engaged, depending on the setting of Menu item "O56 CW BK-IN TYPE".
- Touch [CH1] [CH5] on the LCD or press an FH-2 [1] - [5] key. Repetitive transmission of the Beacon message will begin.

BASIC OPERATION

 Press the MODE button, then touch the corresponding key on the LCD to select the FM operating mode. The "FM" icon appears in the display.



- 2. Set the transceiver to the desired frequency.
- 3. Press the microphone **PTT** switch to transmit. Speak into the microphone in a normal voice level. Release the **PTT** switch to return to receive.

ADVICE:

The **MULTI** knob can serve as the frequency setting knob.

To change the **MULTI** knob frequency step, follow the below procedure:

Press the **F(M-LIST)** button, then touch **[CH DIAL]** on the TFT display. Rotate the **MULTI** knob or touch **[CH DIAL]** repeatedly to select the frequency steps in the following order.

You can also switch the frequency steps by touching **[CH DIAL]** repeatedly.

"2.5kHz" → "5kHz" → "9kHz" → "10kHz" → "12.5kHz" → "25kHz" → "2.5kHz"

4. Adjustment of the microphone gain may be accomplished in two ways. At the factory, a default level has been programmed that should be satisfactory for most situations. To change the microphone gain, press the F(M-LIST) button, then touch [MIC GAIN] on the LCD. Rotate the MULTI knob function as the microphone gain adjustment knob. Rotate the MULTI knob to adjust the microphone gain.







ADVICE:

FM is only used in the 28 MHz, 50 MHz, 144 MHz and 430 MHz Amateur bands covered by the FT-991A. Please do not use FM on any other bands.

FM Mode Operation

REPEATER OPERATION

The FT-991A may be utilized on 29 MHz, 50 MHz, 144 MHz and 430 MHz repeaters.

- Rotate the Main Tuning Dial knob to set the FT-991A to the desired repeater's output frequency (downlink from the repeater).
- If CTCSS Tone operation is desired/needed, press the F(M-LIST) button, then touch [TONE/DCS] on the LCD to engage the CTCSS mode.



3. Touch [**TONE/DCS**] on the LCD repeatedly to select the desired CTCSS mode. If the repeater requires an uplink encoding tone, select "ENC." For both uplink and downlink encode/decode operation, choose "CTCSS". The available choices are:

"OFF" \rightarrow "ENC (Tone Encoder)"

 \rightarrow "CTCSS (Tone Squelch)"

→ "DCS (Digital Code Squelch)" → "OFF"

4. Touch [RPT] repeatedly on the LCD to select the desired repeater shift direction. The selections are:
"SIMP" → "+" → "-" → "SIMP"

where "SIMP" represents "Simplex" operation (not used on a repeater).



 Touch [FWD] to switch the display screen, and then touch [TONE]. Rotate the MULTI knob to select the desired CTCSS Tone to be used. A total of 50 standard CTCSS tones are provided (see the CTCSS Tone Chart).

vfo-A FM 4	46.	200	14:46z
[++] EN	CLA	R	ОHz
S . ¹ . PO ¹ ₀	3 5 7 5 10	9 +20 +40 50 100	<u>+60</u> dB 150₩
Gy	AMS		DIGITAL DN
BACK	TONE	DCS 023	FWD
HOME	SQL	CH DIAL 25kHz	SWEEP



		CTCSS	TONE F	REQUEN	ICY (HZ)		
67.0	69.3	71.9	74.4	77.0	79.7	82.5	85.4
88.5	91.5	94.8	97.4	100.0	103.5	107.2	110.9
114.8	118.8	123.0	127.3	131.8	136.5	141.3	146.2
151.4	156.7	159.8	162.2	165.5	167.9	171.3	173.8
177.3	179.9	183.5	186.2	189.9	192.8	196.6	199.5
203.5	206.5	210.7	218.1	225.7	229.1	233.6	241.8
250.3	254.1	-	-	-	-	-	-

6. Press and hold the microphone **PTT** switch to begin transmission. You will observe that the frequency has shifted to correspond to the programming set up in the previous steps. Speak into the microphone in a normal voice level. Release the **PTT** switch to return to the receive mode.

ADVICE:

- □ The conventional repeater shift used on 29 MHz is 100 kHz, while on the 50 MHz band the shift may vary between 500 kHz and 1.7 MHz (or more). On the 144 MHz band, the shift will be 600 kHz; on the 430 MHz band, the shift will be 1.6 MHz or 7.6 MHz (5 MHz for the U.S.A. version). To program the proper repeater shift, use Menu items "O80 RPT SHIFT 28MHz" (28 MHz), "O81 RPT SHIFT 50MHz" (50 MHz), "O82 RPT SHIFT 144MHz" (144 MHz), and "O83 RPT SHIFT 430MHz" (430 MHz) as appropriate.
- Press the F(M-LIST) button, then touch [REV] on the LCD to reverse the transmission and reception frequencies temporarily to check whether direct communication with the partner station is possible. When reversing the frequencies, + or - will flash. When [REV] is touched one more time, the reverse is cancelled.



REPEATER OPERATION

Automatic Repeater Shift (ARS)

The **FT-991A** ARS feature causes the appropriate repeater shift to be automatically applied whenever it is tuned into the designated repeater sub-bands.

If the ARS feature does not appear to be working, you may have accidentally disabled it.

To re-enable ARS:

- 1. Press the **MENU(SETUP)** button to enter the Menu mode.
- To use the ARS function at 144 MHz, select "084 ARS 144MHz". To use the ARS function at 430 MHz, select "085 ARS 430MHz" by rotating the MULTI knob.
- 3. Touch [SELECT] on the LCD, then rotate the MULTI knob to set this Menu item to "ON".



MENU(SETUP) Button

(YAESU)

- 4. Touch [ENTER] on the LCD to save the new setting.
- 5. Press the **MENU(SETUP)** button or touch [**BACK**] on the LCD to exit to normal operation.

Tone Calling (1750 Hz)

Press the **F(M-LIST)** button to display the function list, then touch [**T.CALL**] on the LCD. While you are pressing and holding [**T.CALL**] to generates a 1750 Hz burst tone to access the repeater. The transmitter will automatically be activated, and a 1750 Hz audio tone will be superimposed on the carrier. Once access to the repeater has been gained, you may release the [**T.CALL**], and use the **PTT** switch for activating the transmitter thereafter.

FM Mode Operation

TONE SQUELCH OPERATION

The "Tone Squelch" may be activated to keep the receiver silent until an incoming signal modulated with a matching CTCSS tone is received. The receiver squelch will then open in response to the reception of the required tone.

- 1. Press the **MODE** button, and then touch the corresponding key on the LCD to select the FM operating mode. The "**FM**" icon appears in the display.
- 2. Set the transceiver to the desired frequency.
- If CTCSS Tone operation is desired/needed, press the F(M-LIST) button, then touch [TONE/DCS] on the LCD to engage the CTCSS mode.



4. Touch [TONE/DCS] on the LCD repeatedly to choose "CTCSS" from the available choices of "OFF" → "ENC (Tone Encoder)"

→ "CTCSS (Tone Squelch)"

→ "DCS (Digital Code Squelch)" → "OFF"

 Touch [FWD] to switch the screen, and then touch [TONE]. Rotate the MULTI knob to select the desired CTCSS Tone to be used. A total of 50 standard CTCSS tones are provided (see the CTCSS Tone Chart).

vfo∙A ™ 4	33.	500	14:46Z
DE	c CLA	R	ОHz
S 1. PO 0	3 5 7 10	9 <u>+20 +40</u> 50 100	<u>+60</u> dB 150₩
Gи	AMS OFF		DIGITAL
BACK	TONE	DCS 023	FWD
HOME	SQL	CH DIAL 25kHz	SWEEP

	CTCSS TONE FREQUENCY (Hz)							
67.0	69.3	71.9	74.4	77.0	79.7	82.5	85.4	
88.5	91.5	94.8	97.4	100.0	103.5	107.2	110.9	
114.8	118.8	123.0	127.3	131.8	136.5	141.3	146.2	
151.4	156.7	159.8	162.2	165.5	167.9	171.3	173.8	
177.3	179.9	183.5	186.2	189.9	192.8	196.6	199.5	
203.5	206.5	210.7	218.1	225.7	229.1	233.6	241.8	
250.3	254.1	-	-	-	-	-	-	

DCS OPERATION

The "DCS" may be activated to keep the receiver silent until an incoming signal modulated with a matching DCS code is received. The receiver squelch will then open in response to the reception of the required code.

- Press the MODE button, and then touch the corresponding key on the LCD to select the FM operating mode. The "FM" icon appears in the display.
- 2. Set the transceiver to the desired frequency.
- If DCS operation is desired/needed, press the F(M-LIST) button, then touch [TONE/DCS] on the LCD to engage the DCS mode.



- 4. Touch [**TONE/DCS**] on the LCD repeatedly to choose "DCS" from the available choices of
 - "OFF" → "ENC (Tone Encoder)" → → "CTCSS (Tone Squelch)" →
 - \rightarrow "EDCS (DCS Encoder)" \rightarrow
 - → "DCS (Digital Code Squelch)" → "OFF"

 Touch [FWD] to switch the screen, and then touch [DCS]. Rotate the MULTI knob to select the desired DCS code to be used. A total of 104 DCS codes are provided (see the DCS Code Chart).



	DCS CODE							
023	025	026	031	032	036	043	047	
051	053	054	065	071	072	073	074	
114	115	116	122	125	131	132	134	
143	145	152	155	156	162	165	172	
174	205	212	223	225	226	243	244	
245	246	251	252	255	261	263	265	
266	271	274	306	311	315	325	331	
332	343	346	351	356	364	365	371	
411	412	413	423	431	432	445	446	
452	454	455	462	464	465	466	503	
506	516	523	526	532	546	565	606	
612	624	627	631	632	654	662	664	
703	712	723	731	732	734	743	754	

C4FM Mode (Digital Mode) Operation

The **FT-991A** transceiver is capable of using 2, C4FM digital modes: the "V/D mode" which communicates voice and data simultaneously, and the "Voice FR mode" which transmits digital voice data using the full 12.5 kHz bandwidth.

 Press the MODE button, and then touch the corresponding key on the LCD to select the C4FM operating mode. The "C4FM" icon appears in the display.



2. Set the transceiver to the desired operating frequency.

ADVICE:

The VFO-A frequency can be changed by rotating the Main Tuning Dial knob or using one of the following methods. For details, see page 44.

- Setting the frequency directly using the number keys.
- Setting the frequency by rotating the **MULTI** knob.
- □ Setting the frequency using the **UP/DWN** buttons on the microphone.
- Press and hold the PTT button on the microphone (or touch the [MOX] on the LCD) to change the transceiver to transmit mode, then speak into the microphone.

Release the **PTT** button (or touch the [**MOX**] again if you pressed [**MOX**] to enter the transmit mode) to change the transceiver back to the receive mode.

ADVICE:

- Digital communication mode can be switched between V/D mode and FR mode (see "Toggling to the Digital Communication Mode" on page 41).
- □ The AMS (Automatic Mode Select) function enables the transceiver to select the appropriate communication mode according to the received signal. Using the AMS function, the transceiver recognizes either analog (FM) or C4FM digital signals and automatically changes to the same communication mode as the contact station.

Note:

When communicating in V/D mode ("DN" is displayed on the LCD), the station location information is contained within the transmitted digital signal. In Voice FR mode ("VW" is displayed on the LCD), the location information is not included in the transmitted signals.



C4FM Mode (Digital Mode) Operation

Notification When the Contact Station Completes a Transmission (Standby Beep Function)

When communicating in C4FM mode, an audible beep sounds to indicate that the contact station has completed a transmission (Standby Beep function).

To change the Standby Beep function "ON/OFF", follow the procedure below.

- 1. Press the **MENU(SETUP)** button to enter the Menu mode.
- Rotate the MULTI knob to select Menu item "091 STANDBY BEEP".
- Touch [SELECT] on the LCD, then rotate the MULTI knob to set this Menu item to "ON" or "OFF" (the default setting is "ON").





 Press the MENU(SETUP) button or touch [BACK] on the LCD to exit to normal operation.

DG-ID/DP-ID Features

Digital Group ID (DG-ID) feature

The DG-ID function can set up two-digit DG-ID numbers from "00" to "99" separately for Transmit and Receive. By setting both transmit and receive to "00" (default), you can communicate with all the other stations in the digital C4FM mode.By matching the transmit DG-ID number to the uplink DG-ID number set in club the DR-2X/XE System Fusion II digital repeater, you can access the digital repeater DR-2X/XE used in the club. For communication only among a group of friend's transceivers, you can all match the same DG-ID number; then only your friend's voices will be heard. Also, by using the GM function you can check whether stations with the same DG-ID are in the communication range. The FT-991A may register transmit and receive DG-ID numbers in the DG-ID memories (up to 10 pairs).

Register the DG-ID number in the DG-ID memory

Example: Enter the transmit DG-ID number "50" and the receive DG-ID number "50" into the DG-ID memory "01".

- 1. Press the **MODE** button, then touch [**C4FM**].
- 2. Touch and hold [**GM**] on the LCD. The DG-ID LIST is displayed.



Note:

- ☐ The DG-ID of memory "OO" is fixed at "TX OO, RX OO" and cannot be changed.
- □ The transmit and receive DG-ID default number is set to "OO".
- ☐ Normally, for general operation set the DG-ID number to "OO" for both transmit and receive.
- 3. Rotate the **MULTI** knob to select the DG-ID "O1" memory register to store the TX and RX DG-ID numbers.



4. Touch [**TX**].

The transmit DG-ID number setting screen is displayed.

5. Enter the "50" of the DG-ID number, touching the keys on the LCD.

vfo·A ^{C4FM} 1	46.	<u>520</u>	14:46Z
ТХ		50	
1	2	3	
4	5	6	Â
7	8	9	ENT
BACK	0	00	

ADVICE:

- ☐ The DG-ID of memory "00" is fixed at "TX 00, RX 00" and cannot be changed.
- 6. Touch [**ENT**].
- 7. Touch [**RX**].
 - The receive DG-ID number setting screen is displayed.
- Enter the "50" of the DG-ID number, touching the keys on the LCD.

vfo-A ^{C4FM} 1	<u>46.</u>	<u>520</u>	
RX		50	
1	2	3	
4	5	6	
7	8	9	ENT
BACK	0	00	ENI

- 9. Touch [**ENT**].
- 10. Touch [**TAG**].

The input screen of the DG-ID tag is displayed. Use the keys on the LCD to input the characters of the DG-ID tag. Up to 8 characters can be entered.



- 11. Touch [**ENT**] to save the setting and return to DG-ID LIST screen.
- 12. Touch [BACK] to return to normal operation.

Note:

- when the receive DG-ID number of the transceiver is set to a DG-ID number other than "OO", received signals that do not have the same DG-ID number may not be heard.
- □ The transmit and receive DG-ID default number is set to "OO".
- □ Normally, for general operation set the DG-ID number to "OO" for both transmit and receive.

DG-ID/DP-ID Features

Recall and use the DG-ID number registered in the DG-ID memory

- 1. Press the [MODE] button, then touch [C4FM].
- Touch and hold [GM] on the LCD. The DG-ID LIST is displayed.



- 3. Rotate the **MULTI** knob to select the DG-ID memory number "O1".
- 4. Touch [SELECT].

A check mark is attached to the selected DG-ID list number, and the number and tag are shown in green.



5. Touch [**BACK**] to return to normal operation.

This completes the recalling of the DG-ID. When using the DG-ID memory, the tag of the DG-ID memory being used is displayed every 3 seconds. If the DG-ID memory is "OO", the DG-ID memory tag is not displayed.



Note:

Normally, for general operation set the DG-ID list register number to "OO". DG-ID number "OO" can not be changed. The transmit and receive DG-ID number of register "OO" cannot be changed.

Use the GM (Group Monitor) with the DG-ID function

 Touch [GM] to turn the GM (Group Monitor) function ON, in order to find if other Group Member stations are operating within communications range. The "GM" icon is shown at the upper left of the display.



The other stations must also turn the GM function ON. The call sign, the distance and the direction of up to 24 stations operating with the GM function ON, set to the same DG-ID number, and that are within the communication range, may be tracked.

Rotate the MULTI knob to select the other stations.

2. Touch [**GM**] to turn the GM (Group Monitor) function OFF.

Note:

□ If the receive DG-ID number is set to other than "00", note that signals without the same DG-ID number cannot be heard.

Digital Personal ID (DP-ID) feature

Every C4FM digital transmit communication contains the individual ID information (Radio ID) of each transceiver. The DP-ID function uses this individual ID information. By registering the DP-ID of the transceiver to the DR-2X System Fusion II digital repeater, the digital repeater may be controlled by remote operation. When the DP-IDs of the transceiver are registered with each other, they can communicate even if the DG-ID numbers are different.

Registering the DP-ID to a DR-2X digital repeater

After registering the transceiver's DP-ID to the DR-2X repeater, the settings and functions of the DR-2X can be remotely controlled. Remote control cannot be performed from a transceiver that has not been registered with the DP-ID, so it is possible to securely manage repeaters.

DR-2X Remote Control Feature

- Activate the repeater operation
- Deactivate the repeater operation
- Set the repeater to C4FM mode
- Set the transmit power
- Voice Message Control (Rec / Play / Stop)
- Set the Emergency Call

Register the transceivers

- 1. Press the [**MODE**] button, then touch [**C4FM**].
- 2. Touch and hold [**DIGITAL**] on the LCD. The DP-ID LIST is displayed.



3. While the DP-ID list is displayed, a transmission in the digital C4FM mode from the other transceiver will register the DP-ID.

When a signal from the other station is received, the call sign and the radio ID are displayed on the LCD.



ADVICE:

- When a signal from the already registered transceiver is received, the display of DP-ID list does not change.
- □ When registering a transceiver already registered with a different call sign, the call sign registered in the DP-ID list is changed to register the new call sign.

 Touch [OK] to save the setting. When registering in the DP-ID list is finished, the display returns to the DP-ID list screen. To continue operating without registering the DP-ID, touch [Cancel].

If registering several DP-IDs, repeat steps 3 to 4. A maximum of 24 stations may be registered.



5. Touch [**BACK**] to return to normal operation. Register the DP-ID of all the transceivers in the group to another transceiver using the same operation.

ADVICE:

- Once the DP-ID is registered, the DP-ID is stored until the DG-ID is deleted.
- Register with another transceiver while the transceivers are near each other.

Deleting the registered DP-ID

- 1. Press the [MODE] button, then touch [C4FM].
- Touch and hold [DIGITAL] on the LCD. The DP-ID LIST is displayed.



- 3. Rotate the **MULTI** knob to select the call sign to be deleted.
- 4. Touch [**DELETE**].





 Touch [OK] to delete the call sign. When deleting in the DP-ID list is finished, the display returns to the DP-ID list screen. To return to normal operation without deleting the DP-ID, touch [Cancel]. If deleting several DP-IDs, repeat steps 3 to 5.



6. Touch [BACK] to return to normal operation.

PMS MEMORY CHANNELS

CONVENIENT MEMORY FUNCTIONS

The **FT-991A** contains ninety-nine regular memories, labeled "O1" through "99", nine special programmed band edge memory pairs, labeled "P-1L/P-1U" through "P-9L/P-9U", and five QMB (Quick Memory Bank) memories. Each memory stores various settings, in addition to the VFO-A frequency and mode, but also stores the various settings shown below. By default, the 99 regular memories are contained in one group; however, they can be arranged in up to six separate groups, if desired.

REGULAR MEMORY CHANNELS

QUICK POINT:

The **FT-991A** memory channels store the following data (not just the operating frequency):

- □ VFO-A Frequency
- □ VFO-A Mode
- Clarifier status and its Offset Frequency
- □ IPO status
- □ Attenuator status
- Noise Blanker status
- □ IF SHIFT and WIDTH status
- CONTOUR status and its Peak Frequency
- DSP Noise Reduction (DNR) status and its Reduction algorithm selection.
- □ DSP Notch filter (NOTCH) status
- □ NAR bandwidth status
- □ DSP Auto Notch filter (DNF) status
- □ Repeater Shift Direction
- CTCSS Tone information (CTCSS Encode, Decode ON/OFF; Tone Frequency)
- □ DCS information (DCS On/Off, DCS Code)





QMB (QUICK MEMORY BANK)

The Quick Memory Bank consists of five memories independent from the regular and PMS memories. The QMB memories can quickly store operating parameters for later recall.

QMB Channel Storage

- 1. Tune to the desired frequency on VFO-A.
- 2. Press and hold the **RCL/STO** button for one second. The "beep" will confirm that the VFO-A contents have been written to the currently available QMB memory.

Repeated one second presses of the **RCL/STO** button will write the VFO-A contents to successive QMB memories.

Once all five QMB memories have data on them, previous data will be over-written on a first-in, first-out basis.

QMB Channel Recall

- 1. Press the **RCL/STO** button briefly. The current QMB channel data will be shown on the frequency display area. The "**QMB**" icon will also appear and the Memory Mode indicators in the LED indicators area will illuminate.
- 2. Repeated brief presses of the **RCL/STO** button will toggle through the QMB channels.
- Press the V/M button to return to the VFO or Memory mode.



ADVICE:

Rotating the Main Tuning Dial knob, or changing the operating mode, will place the transceiver in the "Memory Tune" mode, which is a temporary "pseudo-VFO" method of tuning off of a stored memory channel. If you do not over-write the contents of the current memory channel, the original contents will not be disturbed by the initiation of Memory Tune operation.

Memory Operation

STANDARD MEMORY OPERATION

The Standard Memory of the **FT-991A** allows storage and recall of up to 99 memories, each storing frequency, mode, and a wide variety of status information, detailed previously. Memories may be grouped into as many as six Memory Groups. Additionally there are nine pairs of band-limit (PMS) memories along with five QMB (Quick Memory Bank) memories.

Memory Storage

- 1. Set VFO-A up with the frequency, mode, and status, the way you want to have it stored.
- Press the A► M button momentarily; the current channel number will appear in the display and the "MCK" notation will appear.



- 3. Rotate the **MULTI** knob to select the memory channel that you wish to store the data on.
- Press and hold in the A►M button for one second to store the frequency and other data into the selected memory channel. A double beep will sound to confirm that the operation is completed.

Memory Channel Recall

- Press the V/M button, if necessary, to enter the "Memory mode".
- Press the F(M-LIST) button, then touch [MCH] on the LCD. A memory channel number and the "MCH" notation will appear in the display.



 Touch [MCH] on the LCD, and then rotate the MULTI knob to select the desired memory channel.





ADVICE:

To work within a particular Memory Group, press the **F(M-LIST)** button, then touch **[GRP]** on the LCD. Rotate the **MULTI** knob to select the desired Memory Group, then touch **[MCH]** on the LCD (the "**MCH**" notation will appear instead of the "**GRP**"); Now the memory channel may be chosen from within the selected Memory Group.



STANDARD MEMORY OPERATION

Recalling the Home Channel

1. Press the **F(M-LIST)** button, then touch [**HOME**] on the LCD. The home channel frequency will be shown in the display.



ADVICE:

Change the frequency using Main Tuning Dial knob to return to the VFO mode.

Touch **[HOME]** again to return to the VFO mode and display the frequency that was selected before the home channel was recalled.





ADVICE:

In the default setting, the Home channel frequencies of each band are set as follows.

- HF band: 29.60000 MHz (USA/EXP Version) 29.30000 MHz
- 50 MHz band: 52.52500 MHz (USA/EXP Version) 51.00000 MHz

144 MHz band: 146.52000 MHz (USA/EXP Version) 145.00000 MHz

430 MHz band: 446.00000 MHz (USA/EXP Version) 446.00000 MHz

Changing the Frequency of the Home Channel

The default frequency setting of the home channel when shipped from the factory can be changed.

1. Press the **F(M-LIST)** button, then touch [**HOME**] on the LCD. The home channel will be shown in the display.



2. Press the **BAND** button, then touch [**ENT**].

HOME 14:462 TM 440.00000					
clar OHz					
1.8	3.5	7.0	AIR		
10	14	18	144		
21	24	28	430		
MW	50 GEN ENT				



3. Set the desired frequency, then touch [**ENT**] on the LCD to exit to normal operation.

	HOME 14146Z						
	CLAR OHZ						
1.8	3.5	7.0	AIR				
10	14	18	144				
2 1	24	28	430				
MW	50	GEN	ENT				
			6				

When the writing to the home channel is completed, the updated home channel frequency will be displayed.

Memory Operation

STANDARD MEMORY OPERATION

Labeling Memories

An Alphanumeric "Tag" (label) may be appended to a memory or memories, to aid in recollection of the channel's use (such as a club name, etc.). To do this:

- 1. Press and hold in the **F(M-LIST)** button.
- The data stored in the currently selected memory channel will be displayed on the TFT.
- 2. Rotate the **MULTI** knob to recall the memory channel that you wish to append a label.
- Touch [TAG] on the LCD. A cursor will appear on the first digit.



- 4. Touch a key on the LCD to enter the letters, numbers, or symbols of the desired label.
- 5. Repeat step 5 to program the remaining letters, numbers, or symbols of the desired label. 12 characters may be used in the creation of a label.

Use [I] and [] on the LCD to set the cursor position and [] on the LCD to erase a letter at the left of the cursor.

 When you have completed the creation of the label, touch [ENT] on the LCD.



7. Press the **F(M-LIST)** button to save the new setting and return to normal operation.


STANDARD MEMORY OPERATION

Checking a Memory Channel Status

Before programming a channel into memory, you can check the current contents of that channel without the danger of over-writing the channel accidentally.

1. Press the $A \triangleright M$ button momentarily.

The data stored in the currently selected memory channel will be displayed on the TFT. However, since you are only checking the contents of the memory channel, the radio will not have moved to the memory channel frequency.



 Rotate the MULTI knob to select a different memory channel. To exit from the Memory Check mode, press the A►M button momentarily once more.

ADVICE:

□ While operating in the VFO mode, using Memory Check, you may store the current VFO frequency into the selected memory by pressing and holding in the A►M button for one second (until the double beep).



Erasing Memory Channel Data

- 1. Press and hold in the **F(M-LIST)** button.
- 2. Rotate the **MULTI** knob to select the memory channel that you would like to erase.
- 3. Touch [**ERASE**] on the LCD.





ADVICE:

- □ The **FT-991A** cannot erase memory channel "01" (and channels "5-01" through "5-10": U.S. version).
- □ If you make a mistake and wish to restore the memory contents, just repeat steps (1) through (3) above.

STANDARD MEMORY OPERATION

Memory Tune Operation

The frequency may be freely tuned off from any memory channel in "Memory Tune" mode; this is similar to VFO operation. So long as you do not over-write the contents of the current memory, Memory Tune operation will not alter the contents of the memory channel.

- 1. Press the V/M button to recall any memory channel.
- 2. Press the **F(M-LIST)** button, then touch [**MCH**] on the LCD.



- 3. Rotate the **MULTI** knob to select the memory channel.
- 4. Rotate the Main Tuning Dial knob; you will now observe that the memory channel frequency is changing.

ADVICE:

- During Memory Tune operation, you may change operating modes, and engage the offset Clarifier, if desired.
- 5. Press the **V/M** button momentarily to return to the originally memorized frequency of the current memory channel. One more press of the **V/M** button will return to VFO operation.



Note:

Computer software programs utilizing the CAT system interface port may presume that the transceiver is operating in the VFO mode, for certain features like "band mapping" and/or frequency logging, because the "Memory Tune" mode so closely resembles the VFO mode. Be sure that you have the **FT-991A** operating in a control mode compatible with the software's requirements. Use the VFO mode if you're not sure.

STANDARD MEMORY OPERATION

Split Memory

Separate frequencies for transmit and receive can be registered for each memory channel.

- 1. Set VFO-A up with the frequency, mode, and status (see "Convenient Memory Functions" on page 97), the way you want to have it stored.
- Press the A► M button momentarily; the current channel number will appear in the display and the "MCK" notation will appear.



- 3. Rotate the **MULTI** knob to select the memory channel that you wish to store the data on.
- Press and hold in the A►M button for one second to store the receive frequency and other data into the selected memory channel. A double beep will confirm that the A►M button was held in long enough and the data is registered.
- 5. Enter the transmit frequency, mode, and status (see "Convenient Memory Functions" on page 97), the way you want to have it stored.



6. Press the **A**►**M** button. Make sure that the memory channel storing the receive frequency is selected.



7. To register the transmit frequency, press and hold the **PTT** button on the microphone, and simultaneously press and hold the **A**► **M** button. A double beep will confirm that the **A**► **M** button was held in long enough and the data is registered. When the memory writing is completed, the receive frequency will be shown in the display.



ADVICE:

When a split-frequency memory channel is recalled, "**DUP**" is displayed on the LCD.



Memory Operation

MEMORY GROUPS

Memory channels may be arranged into as many as six convenient groups, for easy identification and selection. For example, different memory groups may be designated for AM BC stations, short-wave broadcast stations, contest frequencies, repeater frequencies, PMS limits, or any other groupings you might like.

Each memory group is capable of holding up to 20 memory channels (except Memory Group 01 is 19 memory channels, and the Group size is fixed).

Memory Group Assignment

- 1. Press the **MENU(SETUP)** button to enter the Menu mode.
- Rotate the MULTI knob to select Menu item "O34 MEM GROUP".
- 3. Touch [SELECT] on the LCD, then rotate the MULTI knob to set this Menu item to "ENABLE" (the default setting is "DISABLE").





MULTI Knob

MEMORY CHANNEL NUMBER
01 - 19
20 - 39
40 - 59
60 - 79
80 - 99
P-1L/1U - P-9L/9U
5M-01 - 5M-10

4. Touch **[ENTER]** on the LCD to save the new setting.



5. Press the **MENU(SETUP)** button or [**BACK**] on the LCD to exit. Operation will now be restricted to the six Memory Groups.

To cancel Memory Group operation, repeat steps (1) through (4) above, choosing "DISABLE" in step (3).

ADVICE:

To avoid confusion, note that the PMS memory group and the PMS memories "P-1L" through "P-9U" will be so designated.

MEMORY GROUPS

Choosing the Desired Memory Group

If desired, memories just within a particular Memory Group may be recalled.

- Press the V/M button, if necessary, to enter the "Memory" mode.
- 2. Press the **F(M-LIST)** button, then touch [**GRP**] on the LCD. The "**GRP**" icon will appear on the display.





- 3. Rotate the **MULTI** knob to select the desired Memory Group.
- 4. Touch [MCH] on the LCD. The "MCH" icon will appear on the display.



5. Rotate the **MULTI** knob to select the desired Memory Channel within the Selected Memory Group.

ADVICE:

If no channels have been assigned to a particular Memory Group, that Group cannot be accessed.

OPERATION ON ALASKA EMERGENCY FREQUENCY: 5167.5 KHz (U.S. VERSION ONLY)

Section 97.401(d) of the regulations governing amateur radio in the United States permit emergency amateur communications on the spot frequency of 5167.5 kHz by stations in (or within 92.6 km of) the state of Alaska. This frequency is only to be used when the immediate safety of human life and/or property are threatened, and is never to be used for routine communications.

The **FT-991A** includes the capability for transmission and reception on 5167.5 kHz under such emergency conditions via the Menu system. To activate this feature:

- 1. Press the **MENU(SETUP)** button to enter the Menu mode.
- 2. Rotate the **MULTI** knob to select Menu item "149 EMERGENCY FREQ TX".
- Touch [SELECT] on the LCD, then rotate the MULTI knob to select "ENABLE."



4. Touch **[ENTER]** on the LCD to save the new setting.



- 5. Press the **MENU(SETUP)** button or [**BACK**] on the LCD to exit to normal operation. Emergency communication on this spot frequency is now possible.
- Press the V/M button, as necessary, to enter the Memory mode.
- 7. Press the **F(M-LIST)** button, then touch [**MCH**] on the LCD.





 Rotate the MULTI knob to select the emergency channel ("EMG"), which is found between channels "5-10" and "01ch").

NOTE:

- □ The receive-mode CLARIFIER functions normally while using this frequency, but variation of the transmit frequency is not possible. The full specifications of the **FT-991A** are not necessarily guaranteed on this frequency, but power output and receiver sensitivity should be fully satisfactory for the purpose of emergency communication.
- If you wish to disable operation capability on the Alaska Emergency Frequency, repeat the above procedures, but set the Menu item "149 EMERGENCY FREQ TX" to "DISABLE" in step 3.
- □ In an emergency, note that a half-wave dipole cut for this frequency should be approximately 45'3" on each leg (90'6" total length). Emergency operation on 5167.5 kHz is shared with the Alaska-Fixed Service. This transceiver is not authorized for operation, under the FCC Part 87, for aeronautical communications.

VFO and Memory Scanning

VFO SCANNING

Either the VFO or the memory channels of the **FT-991A** may be scanned, and the receiver will halt scanning on any frequency with a signal strong enough to open the receiver squelch.

- 1. Set the VFO-A to the frequency on which you would like to begin scanning.
- Press the F(M-LIST) button, then touch [SQL] on the LCD. Rotate the MULTI knob so that the background noise is just silenced.



 Press and hold in the microphone UP or DWN button for one second, or press the F(M-LIST) button followed by [SCAN] to start scanning in the specified direction on the VFO frequency.



4. If the scanner halts on an incoming signal, the decimal point between the "MHz" and "kHz" digits of the frequency display will blink.

ADVICE:

- □ If the incoming signal disappears, scanning will resume in about five seconds.
- On the SSB/CW and SSB-based Data modes, the scanner will pause on a received signal, then will step across the signal very slowly, giving you time to stop the scan, if you like. In these modes on the VFO, the scanner does not stop, however.
- 5. To cancel scanning, press the **PTT** switch, or touch [**SCAN**] on the LCD.



ADVICE:

- □ If the scan has paused on a signal, pressing the microphone **UP** or **DWN** button, or touching [**SCAN**] on the LCD will cause scanning to resume instantly.
- □ If you press the microphone **PTT** button during scanning, the scanner will halt at once. However, pressing the **PTT** button during scanning will not cause transmission.
- The manner in which the scanner resumes after it has paused on a signal may be selected by using Menu item "O38 MIC SCAN RESUME". The default "TIME" (5 sec) setting will cause the scanner to resume scanning after five seconds; however the scan setting may be changed to resume only after the received signal has dropped out.
- □ If the Main Tuning Dial knob is rotated while scanning is in progress, the scanning will continue up or down in frequency according to the direction of the Dial Knob rotation. (in other words, if the dial is rotated to the left when scanning toward a higher frequency, the direction of the scan will reverse.)

QUICK POINT:

If you have no interest in scanning, and wish to prohibit the microphone **UP/DWN** buttons from initiating scanning, you may disable scanning control from the microphone using Menu item "O37 MIC SCAN" (set it to "DISABLE").

VFO and Memory Scanning

Memory Scan

- Set the transceiver to the "Memory" mode by pressing the V/M button, if necessary.
- 2. Press the **F(M-LIST)** button, then touch [**SQL**] on the LCD. Rotate the **MULTI** knob so that the background noise is just silenced.



 Press and hold in the microphone UP or DWN button for one second, or press the F(M-LIST) button followed by [SCAN] to start scanning in the specified direction.



ADVICE:

- If the scanner halts on an incoming signal, the decimal point between the "MHz" and "kHz" digits of the frequency display will blink.
- □ If the incoming signal disappears, scanning will resume in about five seconds.
- 4. To cancel scanning, press the **PTT** switch, or touch [**SCAN**] on the LCD.



ADVICE:

- During Memory Group operation, only the channels within the current Memory Group will be scanned.
- □ If the scan has paused on a signal, pressing the microphone **UP** or **DWN** button, or touching [**SCAN**] on the LCD will cause scanning to resume instantly.
- □ If you press the microphone **PTT** button during scanning, the scanner will halt at once. However, pressing the **PTT** button during scanning will not cause transmission.
- □ The manner in which the scanner resumes after it has paused on a signal may be selected by using Menu item "O38 MIC SCAN RESUME". During memory scanning, the default "TIME" (5 sec) setting will cause the scanner to resume scanning after five seconds; however the scan may be set, to resume only after the received signal has dropped out.
- □ If the Main Tuning Dial knob is rotated while scanning is in progress, the memory channel scanning will continue up or down in accordance with the direction of the Dial Knob rotation. (In other words, if the dial is rotated to the left when scanning toward a higher channel number, the direction of the scan will reverse.)

QUICK POINT:

If you have no interest in scanning, and wish to prohibit the microphone **UP/DWN** buttons from initiating scanning, you may disable scanning control from the microphone using Menu item "O37 MIC SCAN" (set it to "DISABLE").

PMS (Programmable Memory Scanning)

To limit scanning (and manual tuning) within a particular frequency range, the Programmable Memory Scanning (PMS) feature utilizes nine special-purpose memory pairs ("P-1L/P-1U" through "P-9L/P-9U"). The PMS feature is especially useful in helping you to observe any operating sub-band limits, which apply to your Amateur license class.

- 1. Store the Lower and Upper tuning/scanning limit frequencies into the memory pair "P-1L" and "P-1U", respectively, or any other "L/U" pair of memories in the special PMS memory area. See page 104 for details regarding memory storage.
- 2. Press the V/M button to enter the "Memory" mode.
- 3. Press the **F(M-LIST)** button, then touch [**MCH**] on the TFT display. The LEDs indicating the Memory mode will illuminate.



- 4. Rotate the **MULTI** knob to select memory channel "P-1L" or "P-1U".
- Press the F(M-LIST) button, then touch [SQL] on the LCD. Rotate the MULTI knob so that the background noise is just silenced.



- Turn the Main Tuning Dial knob slightly (to activate memory tuning). Tuning and scanning are now limited to the range within the P-1L/P-1U limits until the V/M button is pressed again to return to memory channel or VFO operation.
- Press and hold in the microphone UP or DWN button for one second, or press the F(M-LIST) button followed by [SCAN] to start scanning in the specified direction.





ADVICE:

- □ If the scanner halts on an incoming signal, the decimal point between the "MHz" and "kHz" digits of the frequency display will blink.
- □ If the incoming signal disappears, scanning will resume in about five seconds.
- On the SSB/CW and SSB-based Data modes, the scanner will pause on a received signal, then will step across the signal very slowly, giving you time to stop the scan, if you like. However, in these modes on the VFO, the scanner does not stop.
- □ If the scan has paused on a signal, pressing the microphone **UP** or **DWN** button, or touching [**SCAN**] on the LCD will cause scanning to resume instantly.
- If the Main Tuning Dial knob is rotated while scanning is in progress, the scanning will continue up or down in frequency according to the direction of the Dial Knob rotation. (in other words, if the dial is rotated to the left when scanning toward a higher frequency, the direction of the scan will reverse.)
- □ If the microphone **PTT** button is pressed during scanning, the scanner will halt at once. Pressing the **PTT** button *during scanning* will not cause transmission.

USING THE GPS FUNCTION

Connecting a YAESU **FT1XD/FT1XD**, **FTM-400XD/FTM-400D** or a commercially available GPS receiver/antenna to the **FT-991A** will permit the transceiver to constantly receive and display the station location information.

By utilizing the GPS location information, you can register stations with which you frequently communicate and use the GM function to confirm whether they are within communication range.

WHAT IS GPS?

GPS or Global Positioning System is a satellite location system that is used to determine the current position on earth. It is a military system developed by the US Department of Defense with approximately 30 GPS satellites orbiting the earth at an altitude of about 20,000 km, When signals from three or more satellites in space are received, the current position information (longitude, latitude, altitude etc.) may be determined within an accuracy of several meters. The accurate time can also be received from the atomic clock built into the GPS satellite.

POSITIONING USING GPS

1. Press and hold in the front panel **ON/OFF** switch to turn the transceiver on.

The satellite search will begin and the "**x**" icon will be displayed at the top right of the screen.



ADVICE:

- □ It may take several minutes to acquire the satellites.
- When three or more satellites cannot be acquired, the icon display will disappear. In this case, positioning is not possible and the position information cannot be used.

About GPS Positioning

Positioning refers to the calculation of one's own position derived from the satellites orbit information and the transmission time of the radio waves. Positioning requires that three or more satellites be acquired. When positioning cannot be carried out properly, move to an open space as far away from buildings as possible and where there are fewer obstructions.

About the Error

Depending on the surrounding environment of the receiver location, an error of several hundred meters may occur. Although positioning is possible using only three satellites, depending on the positioning conditions, the positioning accuracy may become worse, or may no longer be possible under the following conditions:

Between high rise buildings, narrow roads between buildings, indoors and under the shade of buildings, below high voltage lines and underneath overhead structures, between trees and shrubs such as in forests and woods, inside tunnels and underground, when used behind a solar-energy reflecting glass, locations where a strong magnetic field occurs

When not Using the Radio for a Long Period of Time

When using the GPS function for the first time after purchasing the **FT-991A** transceiver, and when turning it on after It has not been used for a long period time, positioning may take several minutes in order to search for the satellites. Also, when using the device again several hours after switching off the power, positioning may take several minutes in order to search for the satellites.

POSITIONING USING GPS

Positioning Using an External GPS Device

A YAESU FT1XD/FT1D, FTM-400XD/FTM-400D or a commercially available GPS receiver/antenna may be connected to the GPS/CAT jack on the rear panel.

The **GPS/CAT** jack connector is illustrated below.

CONNECTING TO THE FT1XD/FT1D



- 1. Press the front panel **ON/OFF** switch to turn the transceiver off.
- 2. Plug the connector of the external device into the GPS/CAT jack on the rear panel.
- 3. Press and hold in the front panel **ON/OFF** switch to turn the transceiver on.
- 4. Press the **MENU(SETUP)** button to enter the Menu mode.
- 5. Rotate the MULTI knob to select Menu item "028 GPS/232C SELECT".
- 6. Touch [SELECT] on the LCD, then rotate the MULTI knob to set this Menu item to "GPS1" or "GPS2" (the default setting is "GPS1").
 - GPS1: Enables connection to an external GPS device.
 - GPS2: Enables connection to an external GPS device, and displays the location information in real time.
- 7. Touch [ENTER] on the LCD to save the new setting.
- 8. Press the **MENU(SETUP)** button or touch [**BACK**] on the LCD to exit to normal operation. When the external device acquires three or more satellites, the "?" icon will be displayed on the top right of the screen.









ADVICE:

- □ When connecting to an external GPS device, refer to the operating manual of the connected device as well.
- □ When using an external GPS device, separate the FT-991A transceiver away from the external GPS device to reduce the possibility of RF interference.

Using the GPS Function

DISPLAYING THE POSITION INFORMATION

Displaying the Current Station Position Information

When Menu Item "028 GPS/232C SELECT" is set to "GPS1"

- 1. Press and hold the **MENU(SETUP)** button.
- 2. Touch **[LAT/LON**] on the LCD.
- 3. Touch [**GPS**] on the LCD.



MENU(SETUP) Button



The latitude and longitude of this station will be displayed.

When Menu Item "028 GPS/232C SELECT" is set to "GPS2"

- 1. Press and hold the **MENU(SETUP)** button.
- Touch [LAT/LON] on the LCD. The latitude and longitude of this station will be displayed in real-time.

Entering the Location Information Manually

- 1. Press and hold the **MENU(SETUP)** button.
- 2. Touch [LAT/LON] on the LCD.
- 3. Touch [LAT] on the LCD.



 Enter the latitude, then touch [ENT] followed by [BACK].



5. Touch [LON] on the LCD.



6. Enter the longitude, then touch [ENT] followed by [BACK].



7. Press the **MENU(SETUP)** button to exit to normal operation.

ADVICE:

The manually registered location information can be erased by touching and holding [LAT] / [LON] on the LCD for one second.

USING THE GM / WIRES-X FUNCTION

WHAT IS THE GM FUNCTION?

The GM (group monitor) function monitors the set frequency to find if there are any stations operating with the GM function within communication range.

The **FT-991A** can then display the position and distance and other information for each member call sign on the screen. Besides identifying GM stations that are within the sphere of communications, the GM function is also a convenient method to instantly note the relative positions of all the members.



An explanation of the two methods of starting the GM operation is given on the following pages. Refer to the separate Operating Manual GM Edition for additional details on using the GM Functions (download the manual from our YAESU website).

BASIC METHODS TO USE THE GM FUNCTION

Displaying all the Stations where the GM Function is in Operation

1. Press the [MODE] button, then touch [C4FM]. Advice:

The GM function does not work in the analog FM mode.

- 2. Set the desired operating frequency.
- 3. Press the F(M-LIST) button, then touch [GM] on the LCD.



Up to 24 stations operating with the GM function within the sphere of communications will be listed on the TFT display.

ADVICE:

- Stations within the sphere of communications are displayed in blue.
- Stations outside the sphere of communications are displayed in grey.



4. Touch [**BACK**] on the LCD. The GM function will be turned off and the display will return to the previous screen.

WHAT IS THE WIRES-X FUNCTION?

The WIRES-X is a system that connects to other users via the Internet. This function enables users to communicate with other users regardless of the distance.

For details, refer to the separate WIRES-X Instruction Manual which is available on the Yaesu website.

RTTY (Radio Teletype) Operation

EXAMPLE OF CONNECTING RTTY COMMUNICATIONS DEVICE

Connecting to the TU (Terminal Unit)

Connect the RTTY communications TU (Terminal Unit) to the rear panel RTTY/DATA terminal. Be sure to read the instruction manual of the TU device before connecting it.

ADVICE:

Adjust the RTTY data output level using Menu item "099 RTTY OUT LEVEL".





RTTY (Radio Teletype) Operation

EXAMPLE OF CONNECTING RTTY COMMUNICATIONS DEVICE

Connecting to your Computer Note:

Install the RTTY application software and driver on your computer in advance.

- RTTY communication application (YAESU does not provide technical support for the use or operation of the application.)
- Virtual COM port driver (Visit the Yaesu website http://www.yaesu.com/ to download the designated driver and Installation Manual.)
- 1. Use a commercially available USB cable to connect the USB jack on the rear panel of the **FT-991A** and the computer.
- 2. Press the **MODE** button, and then touch the corresponding key on the LCD to select the RTTY-LSB operating mode. The "**R-L**" icon appears in the display.



 Press the MENU(SETUP) button. The Menu list will appear in the display. Rotate the MULTI knob to select Menu item "O60 PC KEYING". Touch [SE-LECT] on the LCD, then rotate the MULTI knob to set this Menu item to "RTS" or "DTR". Press the MENU(SETUP) button or touch [BACK] on the LCD to exit to normal operation.



"RTS" and "DTR" will be set as shown below.

		RTTY-PTT	RTTY-SHIFT
Menu item	RTS	RTS	DTR
"060 PC KEYING"	DTR	DTR	RTS

RTTY-PTT and RTTY-SHIFT operations can be set from the Standard-COM port of the virtual COM port.

On the computer, open Device Manager from the Control Panel to check the COM port number and set each item of the RTTY communication application.

4. From the computer Control Panel, open the Sound setting window to set "USB Audio CODEC" as the recording device.

EXAMPLE OF DATA COMMUNICATIONS DEVICE

Use commercial or free computer software for PSK data communications. See the illustration below for connecting the **FT-991A** transceiver to a computer.

Be sure to read the instruction manual of the interface device to be connected to the radio and computer.



ADVICE:

The **FT-991A** allows for PSK, Olivia, Contestia, etc. digital mode to be sent by the Data method or SSB. The conventional method is to use USB, except RTTY, however the Data method allows for more accurate carrier frequency control, which is helpful in a Contest or DX environment.

DATA-AFSK

(PSK, OLIVIA, CONTESTIA, RTTY etc.) FT-991A Settings

Press the MODE button, and then touch the corresponding key on the LCD to select the USB operating mode. The "USB" icon appears in the display.
 ADVICE:

USB is the conventional mode for AFSK transmission on all bands, however some users may be using LSB.

- 2. Press the **F(M-LIST)** button to display the function list.
- 3. Touch [**MONI**] on the LCD. The Monitor function will be set to "ON". The **MULTI** knob will function as the MONITOR adjustment knob.
- 4. Press the **MENU(SETUP)** button. The Menu list will appear in the display.
- Rotate the MULTI knob to select Menu item "108 SSB PTT SELECT". Touch [SELECT] on the LCD, then rotate the MULTI knob to set this Menu item to "RTS". Touch [ENTER] on the LCD.
- Rotate the MULTI knob to select Menu item "109 SSB PORT SELECT". Touch [SELECT] on the LCD, then rotate the MULTI knob to set this Menu item to "USB". Touch [ENTER] on the LCD. Press

the **MENU(SETUP)** button or touch [**BACK**] on the LCD to exit to normal operation.

Note:

All other SSB and DATA settings remain at their default.

Connect a USB Cable from the FT-991A USB port and your computer

ADVICE:

Before connecting the USB cable you must down load the SCU-17 Drivers. The Drivers can be found on the **FT-991A** FILES page at the Yaesu Web page, www. yaesu.com. Once the Drivers have been installed connect the USB cable to the computer and then to the radio. At your computer's Device Manager you will find a Standard Driver and Enhanced Driver installed.

Computer Settings

Soundcard

At your Computer Control Panel Sound set your Speaker Audio default to USB AUDIO CODEC.

COM PORT

Check your Com Port assignments at your Computer's Device Manager to be sure you have the Enhanced and Standard Drivers. Make a note of the Com Port numbers assigned.

EXAMPLE OF DATA COMMUNICATIONS DEVICE

Software Settings

NOTE:

There are many good Data Mode Operating Software programs available on the internet. Each of these programs will have their own Setup instructions, therefore to assist you, the following, while general in nature is common to most software setup.

COM PORT Settings

To start set the Com Port setting to the Enhanced Driver. If there is a problem switch to the Standard Driver.

PTT Settings

Set the PTT to RTS on DTR off.

SOUNDCARD

- a. At the software Soundcard setting, set to USB CO-DEC AUDIO
- b. At the software Soundcard Volume setting increase the volume to about 70% to start.

ADVICE:

If the soundcard volume setting is to low the radio will not switch to Transmit.

DATA MODE

(PSK, OLIVIA, CONTESTIA, RTTY etc.) FT-991A Settings

1. Press the **MODE** button, and then touch the corresponding key on the LCD to select the DATA-USB operating mode. The "**D-U**" icon appears in the display.

ADVICE:

USB is the conventional mode for Digital (not RTTY) transmission on all bands, however some users may be using LSB.

- 2. Press the **MENU(SETUP)** button. The Menu list will appear in the display.
- Rotate the MULTI knob to find Menu item "062", "063", "070", "071" or "072".
- 4. Touch [**SELECT**] on the LCD.
- 5. Rotate the **MULTI** knob to set these Menu item as shown below.

Menu Function	Setting
062 DATA MODE	PSK
063 PSK TONE	Adjust for desired center frequency.
070 DATA IN SELECT	MIC
071 DATA PTT SELECT	RTS
072 DATA PORT SELECT	USB

 Touch [ENTER] on the LCD, then press the MENU(SETUP) button or touch [BACK] on the LCD to exit to normal operation.

Note:

All other SSB and DATA settings remain at their default.

Connect a USB Cable from the FT-991A USB port and your computer

ADVICE:

Before connecting the USB cable you must down load the SCU-17 Drivers. The Drivers can be found on the **FT-991A** FILES page at the Yaesu Web page, www. yaesu.com. Once the Drivers have been installed connect the USB cable to the computer and then to the radio. At your computer's Device Manager you will find a Standard Driver and Enhanced Driver installed.

Computer Settings

Soundcard

At your Computer Control Panel Sound set your Speaker Audio default to USB AUDIO CODEC.

COM PORT

Check your Com Port assignments at your Computer's Device Manager to be sure you have the Enhanced and Standard Drivers. Make a note of the Com Port numbers assigned.

Software Settings

Note:

There are many good Data Mode Operating Software programs available on the internet. Each of these programs will have their own Setup instructions, therefore to assist you, the following, while general in nature is common to most software setup.

COM PORT Settings

To start set the Com Port setting to the Enhanced Driver. If there is a problem switch to the Standard Driver.

PTT Settings

Set the PTT to RTS on DTR off.

SOUNDCARD

- a. At the software Soundcard setting, set to USB CO-DEC AUDIO
- b. At the software Soundcard Volume setting increase the volume to about 70% to start.

ADVICE:

If the soundcard volume setting is to low the radio will not switch to Transmit.

The Menu system of the **FT-991A** provides extensive customization capability; the transceiver may be setup to complement personal operating preferences. Menu items are grouped by general utilization categories, and are numbered from "OO1 AGC FAST DELAY" to "153 WIRES DG-ID".

Using the Menu

1. Press the **MENU(SETUP)** button to engage the Menu mode.

The display will show the Menu Number and the Menu Item.

- 2. Rotate the **MULTI** knob to select the Menu item to be modified.
- Touch [SELECT] on the LCD, then rotate the MULTI knob to change the current setting of the selected Menu item.

ADVICE:

Touch [BACK] on the LCD to cancel the setting.





4. When the adjustment or setting is completed, touch [ENTER] on the LCD to save the new setting, then press the MENU(SETUP) button or touch [BACK] on the LCD to exit to normal operation.





Menu Resetting

Use this procedure to restore the Menu settings to their factory defaults, without affecting the programmed frequency memories.

- 1. Press the front panel **ON/OFF** switch to turn the transceiver off.
- 2. While holding the **MENU(SETUP)** button in, press and hold in the front panel **ON/OFF** switch to turn the transceiver on. Once the transceiver comes on, release the buttons.



No.	Menu Function	Available Settings	Default Value
001	AGC FAST DELAY	20 - 4000 (20msec/step)	300msec
002	AGC MID DELAY	20 - 4000 (20msec/step)	700msec
003	AGC SLOW DELAY	20 - 4000 (20msec/step)	3000msec
004	HOME FUNCTION	SCOPE/FUNCTION	SCOPE
005	MY CALL INDICATION	OFF - 5sec	1sec
006	DISPLAY COLOR	BLUE/GRAY/GREEN/ORANGE/PURPLE/RED/SKY BLUE	BLUE
007	DIMMER LED	1/2	2
008	DIMMER TFT	0 - 15	8
009	BAR MTR PEAK HOLD	OFF/0.5/1.0/2.0 (sec)	OFF
010	DVS RX OUT LEVEL	0 - 100	50
011	DVS TX OUT LEVEL	0 - 100	50
012	KEYER TYPE	OFF/BUG/ELEKEY-A/ELEKEY-B/ELEKEY-Y/ACS	ELEKEY-B
013	KEYER DOT/DASH	NOR/REV	NOR
014	CW WEIGHT	2.5 - 4.5	3.0
015	BEACON INTERVAL	OFF/1 - 240sec/270 - 690sec	OFF
016	NUMBER STYLE	1290/AUNO/AUNT/A2NO/A2NT/12NO/12NT	1290
017	CONTEST NUMBER	0 - 9999	1
018	CW MEMORY 1	TEXT/MESSAGE	TEXT
019	CW MEMORY 2	TEXT/MESSAGE	TEXT
020	CW MEMORY 3	TEXT/MESSAGE	TEXT
021	CW MEMORY 4	TEXT/MESSAGE	TEXT
022	CW MEMORY 5	TEXT/MESSAGE	TEXT
023	NB WIDTH	1/3/10msec	3msec
024	NB REJECTION	10/30/50dB	30dB
025	NB LEVEL	0 - 10	5
026	BEEP LEVEL	0 - 100	50
027	TIME ZONE	-12:00 - 0:00 - +14:00	0:00
028	GPS/232C SELECT	GPS1/GPS2/RS232C	GPS1
029	232C RATE	4800/9600/19200/38400 (bps)	4800bps
030	232C TOT	10/100/1000/3000 (msec)	10msec
031	CAT RATE	4800/9600/19200/38400 (bps)	4800bps
032	CAT TOT	10/100/1000/3000 (msec)	10msec
033	CAT RTS	ENABLE/DISABLE	ENABLE
034	MEM GROUP	ENABLE/DISABLE	DISABLE
035	QUICK SPLIT FREQ	-20 - 20kHz	5kHz
036	ТХ ТОТ	OFF/1 - 30 (min)	OFF (10*)
037	MIC SCAN	ENABLE/DISABLE	ENABLE
038	MIC SCAN RESUME	PAUSE/TIME	TIME
039	REF FREQ ADJ	-25 - 0 - 25	0
040	CLAR MODE SELECT	RX/TX/TRX	RX
041	AM LCUT FREQ	OFF/100Hz - 1000Hz (50Hz/step)	OFF
042	AM LCUT SLOPE	6dB/oct / 18dB/oct	6dB/oct
043	AM HCUT FREQ	700Hz - 4000Hz (50Hz/step) / OFF	OFF
044	AM HCUT SLOPE	6dB/oct / 18dB/oct	6dB/oct
045	AM MIC SELECT	MIC/REAR	MIC
046	AM OUT LEVEL	0 - 100	50
047	AM PTT SELECT	DAKY/RTS/DTR	DAKY
048	AM PORT SELECT	DATA/USB	DATA
049	AM DATA GAIN	0 - 100	50
050	CW LCUT FREQ	OFF/100Hz - 1000Hz(50Hz/step)	250Hz
051	CW LCUT SLOPE	6dB/oct / 18dB/oct	18dB/oct
052	CW HCUT FREQ	700Hz - 4000Hz(50Hz/step) / OFF	1200Hz
: Europe	an Version.		

No.	Menu Function	Available Settings	Default Value
053	CW HCUT SLOPE	6dB/oct / 18dB/oct	18dB/oct
054	CW OUT LEVEL	0 - 100	50
055	CW AUTO MODE	OFF/50M/ON	OFF
056	CW BK-IN TYPE	SEMI/FULL	SEMI
057	CW BK-IN DELAY	30 - 3000 (msec)	200msec
058	CW WAVE SHAPE	2/4 (msec)	4msec
059	CW FREQ DISPLAY	DIRECT FREQ/PITCH OFFSE	PITCH OFFSE
060	PC KEYING	OFF/DAKY/RTS/DTR	OFF
061	QSK DELAY TIME	15/20/25/30(msec)	15msec
062	DATA MODE	PSK/OTHERS	PSK
063	PSK TONE	1000/1500/2000(Hz)	1000Hz
064	OTHER DISP (SSB)	-3000 - 0 - 3000(10Hz/step)	0Hz
065	OTHER SHIFT (SSB)	-3000 - 0 - 3000(10Hz/step)	0Hz
066	DATA LCUT FREQ	OFF/100 - 1000(Hz)(50Hz/step)	300Hz
067	DATA LCUT SLOPE	6dB/oct / 18dB/oct	18dB/oct
068	DATA HCUT FREQ	700Hz - 4000Hz(50Hz/step)/OFF	3000Hz
069	DATA HCUT SLOPE	6dB/oct / 18dB/oc	18dB/oct
070	DATA IN SELECT	REAR/MIC	REAR
071	DATA PTT SELECT	DAKY/RTS/DTR	DAKY
072	DATA PORT SELECT	DATA/USB	DATA
073	DATA OUT LEVEL	0 - 100	50
074	FM MIC SELECT	MIC/REAR	MIC
075	FM OUT LEVEL	0 - 100	50
076	FM PKT PTT SELECT	DAKY/RTS/DTR	DAKY
077	FM PKT PORT SELECT	DATA/USB	DATA
078	FM PKT TX GAIN	0 - 100	50
079	FM PKT MODE	1200/9600	1200
080	RPT SHIFT 28MHz	0 - 1000kHz (10kHz/step)	100kHz
081	RPT SHIFT 50MHz	0 - 4000kHz (10kHz/step)	1000kHz
082	RPT SHIFT 144MHz	0 - 4000kHz (10kHz/step)	600kHz
083	RPT SHIFT 430MHz	0 - 10000kHz (10kHz/step)	5000kHz
084	ARS 144MHz	OFF/ON	ON
085	ARS 430MHz	OFF/ON	ON
086	DCS POLARITY	Tn-Rn/Tn-Riv/Tiv-Rn/Tin-Riv	Tn-Rn
		Displays the unique transceiver ID	
087	RADIO ID	(The ID is unique to each transceiver and cannot be	****
		changed.)	
088	GM DISPLY	DISTANCE/STRENGTH	DISTANCE
089	DISTANCE	km/mile	mile
090	AMS TX MODE	AUTO/MANUAL/DN/VW/ANALOG	AUTO
091	STANDBY BEEP	ON/OFF	ON
092	RTTY LCUT FREQ	OFF/100Hz - 1000Hz (50Hz/step)	300Hz
093	RTTY LCUT SLOPE	6dB/oct / 18dB/oct	18dB/oct
094	RTTY HCUT FREQ	700Hz - 4000Hz (50Hz/step) / OFF	3000Hz
095	RTTY HCUT SLOPE	6dB/oct / 18dB/oct	18dB/oct
096	RTTY SHIFT PORT	SHIFT/DTR/RTS	SHIFT
097	RTTY POLARITY-RX	NOR/REV	NOR
098	RTTY POLARITY-TX	NOR/REV	NOR
099	RTTY OUT LEVEL	0 - 100	50
100	RTTY SHIFT FREQ	170/200/425/850 (Hz)	170Hz
101	RTTY MARK FREQ	1275/2125 (Hz)	2125Hz
102	SSB LCUT FREQ	OFF/100Hz - 1000Hz (50Hz/step)	100Hz
103	SSB LCUT SLOPE	6dB/oct / 18dB/oct	6dB/oct

No.	Menu Function	Available Settings	Default Value
104	SSB HCUT FREQ	700Hz - 4000Hz (50Hz/step) / OFF	3000Hz
105	SSB HCUT SLOPE	6dB/oct / 18dB/oct	6dB/oct
106	SSB MIC SELECT	MIC/REAR	МІС
107	SSB OUT LEVEL	0 - 100	50
108	SSB PTT SELECT	DAKY/RTS/DTR	DAKY
109	SSB PORT SELECT	DATA/USB	DATA
110	SSB TX BPF	100-3000/100-2900/200-2800/300-2700/400-2600	300-2700
111	APF WIDTH	NARROW/MEDIUM/WIDE	MEDIUM
112	CONTOUR LEVEL	-40 - 0 - 20	-15
113	CONTOUR WIDTH	1 - 11	10
114	IF NOTCH WIDTH	NARROW/WIDE	WIDE
115	SCP DISPLAY MODE	SPECTRUM/WATER FALL	SPECTRUM
116	SCP SPAN FREQ	50/100/200/500/1000 (kHz)	100kHz
117	SPECTRUM COLOR	BLUE/GRAY/GREEN/ORANGE/PURPLE/RED/SKY BLUE	BLUE
440		BLUE/GRAY/GREEN/ORANGE/PURPLE/RED/	
118	WATER FALL COLOR	SKY BLUE/MULTI	MULTI
119	PRMTRC EQ1 FREQ	OFF/100 - 700 (100/step)	OFF
120	PRMTRC EQ1 LEVEL	-20 - 0 - 10	5
121	PRMTRC EQ1 BWTH	1 - 10	10
122	PRMTRC EQ2 FREQ	OFF/700 - 1500 (100/step)	OFF
123	PRMTRC EQ2 LEVEL	-20 - 0 - 10	5
124	PRMTRC EQ2 BWTH	1 - 10	10
125	PRMTRC EQ3 FREQ	OFF/1500 - 3200 (100/step)	OFF
126	PRMTRC EQ3 LEVEL	-20 - 0 - 10	5
127	PRMTRC EQ3 BWTH	1 - 10	10
128	P-PRMTRC EQ1 FREQ	OFF/100 - 700 (100/step)	200
129	P-PRMTRC EQ1 LEVEL	-20 - 0 - 10	0
130	P-PRMTRC EQ1 BWTH	1 - 10	2
131	P-PRMTRC EQ2 FREQ	OFF/700 - 1500 (100/step)	800
132	P-PRMTRC EQ2 LEVEL	-20 - 0 - 10	0
133	P-PRMTRC EQ2 BWTH	1 - 10	1
134	P-PRMTRC EQ3 FREQ	OFF/1500 - 3200 (100/step)	2100
135	P-PRMTRC EQ3 LEVEL	-20 - 0 - 10	0
136	P-PRMTRC EQ3 BWTH	1 - 10	1
137	HF TX MAX POWER	5 - 100	100
138	50M TX MAX POWER	5 - 100	100
139	144M TX MAX POWER	5 - 50	50
140	430M TX MAX POWER	5 - 50	50
141	TUNER SELECT	OFF/INTERNAL/EXTERNAL/ATAS/LAMP	INTERNAL
142	VOX SELECT	MIC/DATA	MIC
143	VOX GAIN	0 - 100	50
144	VOX DELAY	30 - 3000 (msec)	500msec
145	ANTI VOX GAIN	0 - 100	50
146	DATA VOX GAIN	0 - 100	50
147	DATA VOX DELAY	30 - 3000 (msec)	100msec
148	ANTI DVOX GAIN	0 - 100	0
149	EMERGENCY FREQ TX	DISABLE/ENABLE	DISABLE
150	RPT/WIRES FREQ	Select the operating frequency setting method when connecting to a local node	MANUAL
151	PRESET FREQUENCY	Presets frequencies	145.375.00 146.550.00 (USA)
152	SEARCH SETUP	Sets the criteria to sort the FAVORITE list	HISTORY
153	WIRES DG-ID	AUTO/01 - 99	AUTO
	·	·	,

001 AGC FAST DELAY

Function: Sets the AGC-FAST DELAY voltage decay characteristics.

Available Values: 20 - 4000msec (20msec/step)

Default Setting: 300msec

Description: Sets the AGC voltage decay characteristics in 20 msec steps after the input signal level becomes lower than the AGC detection level and the HOLD time is over.

002 AGC MID DELAY

Function: Sets the AGC-MID DELAY voltage decay characteristics.

Available Values: 20 - 4000msec (20msec/step)

Default Setting: 700msec

Description: Sets the AGC voltage decay characteristics in 20 msec steps after the input signal level becomes lower than the AGC detection level and the HOLD time is over.

003 AGC SLOW DELAY

Function: Sets the AGC-SLOW DELAY voltage decay characteristics.

Available Values: 20 - 4000msec (20msec/step) Default Setting: 3000msec

Description: Sets the AGC voltage decay characteristics in 20 msec steps after the input signal level becomes lower than the AGC detection level and the HOLD time is over.

004 HOME FUNCTION

Function: Selects the information to be displayed on the HOME screen.

Available Values: SCOPE/FUNCTION

Default Setting: SCOPE

Description: Selects the information to be displayed on the HOME screen (main screen).

SCOPE: Displays the scope screen.

FUNCTION: Displays the function key screen.

005 MY CALL INDICATION

Function: Sets the display time duration for MY CALL. Available Values: OFF - 5sec

Default Setting: 1sec

Description: Sets the display time duration for a message such as the call sign set from MY CALL when turning on the power.

006 DISPLAY COLOR

Function: Sets the background color of the VFO-A frequency display field.

Available Values: BLUE/GRAY/GREEN/ORANGE/ PURPLE/RED/SKY BLUE

Default Setting: BLUE

Description: Sets the background color of the VFO-A frequency display field. The color may be previewed before the selection is confirmed.

007 DIMMER LED

Function: Sets the key LED brightness level.

Available Values: 1 / 2

Default Setting: 2

Description: Sets the brightness level of the LED indicator located above the Main Tuning Dial knob. The effect of the changes may be observed as the brightness level is adjusted. "1" is the darkest.

008 DIMMER TFT

Function: Sets the TFT display brightness level.

Available Values: 0 - 15

Default Setting: 8

Description: Sets the brightness level of the TFT display. The effect of the changes may be observed as the brightness level is adjusted. The higher the setting, the brighter the illumination becomes.

009 BAR MTR PEAK HOLD

Function: Sets the bar meter peak hold. Available Values: OFF/0.5/1.0/2.0 (sec)

Default Setting: OFF

Description: Sets the time length the maximum value reading is shown on the meter (peak hold).

OFF: Disables the peak hold function.

0.5/1.0/2.0: Holds the maximum value for the time length that is set.

010 DVS RX OUT LEVEL

Function: Sets the voice memory monitoring level.

Available Values: 0 - 100

Default: 50

Description: You can adjust the voice memory monitoring level. The higher the setting, the higher the output level becomes.

011 DVS TX OUT LEVEL

Function: Sets the microphone output level for the voice memory.

Available Values: 0 - 100

Default: 50

Description: The microphone output level may be adjusted to the operators own voice and preference. For example, the output level may be set differently between the microphone and the voice memory. The higher the setting, the higher the output level becomes.

012 KEYER TYPE

Function: Switches the keyer operation.

Available Values: OFF/BUG/ELEKEY-A/ELEKEY-B/ ELEKEY-Y/ACS

Default Setting: ELEKEY-B

Description: Switches the keyer operation.

OFF:

Disables the keyer function.

BUG:

Functions as a "BUG key". Only the "Dot" side is automatically generated (the "Dash" side is generated manually).

ELEKEY-A:

A code element ("Dot" or "Dash" side) is transmitted upon pressing both sides of the paddle.

ELEKEY-B:

Pressing both sides of the paddle transmits the currently generated "Dash" side followed by "Dot" side (or reverse order).

ELEKEY-Y:

Pressing both sides of the paddle transmits the currently generated "Dash" side followed by "Dot" side (or reverse order).

While transmitting the "Dash" side, the first transmitted "Dot" side will not be stored.

ACS:

Functions as the "Keyer with automatic spacing control feature" which sets spacing between characters precisely to be the same length as a dash (three dots in length).

013 KEYER DOT/DASH

Function: Reverses the connections of the CW paddle front panel key jack

- Available Values: NOR/REV
- Default Setting: NOR
- Description: Reverses the connections of the CW paddle. NOR: Press the right side of the paddle to transmit the "Dot" signal and press the left side of the paddle to transmit the "Dash" signal.
 - REV: Press the left side of the paddle to transmit the "Dash" signal and press the right side of the paddle to transmit the "Dot" signal.

014 CW WEIGHT

Function: Adjusts the keyer CW weight.

Available Values: 2.5 - 4.5

Default Setting: 3.0

Description: Sets the "Dot":"Dash" ratio for the built-in electronic keyer.

015 BEACON INTERVAL

Function: Sets the interval time between repeats of the beacon message.

Available Values: OFF/1 - 240sec (1sec/step)/270 - 690sec (30sec/step)

Default Setting: OFF

Description: Sets the interval time between repeats of the beacon message.

A message (message memory/text memory) registered in the contest memory keyer, may be transmitted as a CW Beacon message.

If you do not want the message to repeat in a beacon mode, set this item to "OFF".

016 NUMBER STYLE

Function: Selects the contest number "Cut" format for an imbedded contest number.

Available Values: 1290/AUNO/AUNT/A2NO/A2NT/ 12NO/12NT

Default Setting: 1290

Description: Abbreviates numbers "One", "Two", "Nine" and "Zero" using Morse code when sending the contest number.

1290: Does not abbreviate the contest number.

- AUNO: Abbreviates to "A" for "One", "U" for "Two", "N" for "Nine", and "O" for "Zero".
- AUNT: Abbreviates to "A" for "One", "U" for "Two", "N" for "Nine", and "T" for "Zero".
- A2NO: Abbreviates to "A" for "One", "N" for "Nine", and "O" for "Zero". Does not abbreviate number "Two".
- A2NT: Abbreviates to "A" for "One", "N" for "Nine", and "T" for "Zero". Does not abbreviate number "Two".
- 12NO: Abbreviates to "N" for "Nine", and "O" for "Zero". Does not abbreviate numbers "One" and "Two".
- 12NT: Abbreviates to "N" for "Nine", and "T" for "Zero". Does not abbreviate numbers "One" and "Two".

017 CONTEST NUMBER

Function: Enters the contest number using Morse code. Available Values: 0 - 9999

Default Setting: 1

Description: Enters the contest number using Morse code (page 86).

018 CW MEMORY 1

Function: Selects the registration method for the contest memory keyer "CW MEMORY 1".

Available Values: TEXT/MESSAGE

Default Setting: TEXT

Description: Selects how to register text to the contest memory keyer "CW MEMORY 1".

TEXT: Use the optional **FH-2** or the touch panel to enter text (page 89).

MESSAGE: Use the keyer to register text to the contest memory keyer (page 86).

019 CW MEMORY 2

Function: Selects the registration method for the contest memory keyer "CW MEMORY 2".

Available Values: TEXT/MESSAGE

Default Setting: TEXT

Description: Selects how to register text to the contest memory keyer "CW MEMORY 2".

TEXT: Use the optional **FH-2** or the touch panel to enter text (page 89).

MESSAGE: Use the keyer to register text to the contest memory keyer (page 86).

020 CW MEMORY 3

Function: Selects the registration method for the contest memory keyer "CW MEMORY 3".

Available Values: TEXT/MESSAGE

Default Setting: TEXT

Description: Selects how to register text to the contest memory keyer "CW MEMORY 3".

TEXT: Use the optional **FH-2** or the touch panel to enter text (page 89).

MESSAGE: Use the keyer to register text to the contest memory keyer (page 86).

021 CW MEMORY 4

Function: Selects the registration method for the contest memory keyer "CW MEMORY 4".

Available Values: TEXT/MESSAGE

Default Setting: TEXT

Description: Selects how to register text to the contest memory keyer "CW MEMORY 4".

TEXT: Use the optional **FH-2** or the touch panel to enter text (page 89).

MESSAGE: Use the keyer to register text to the contest memory keyer (page 86).

022 CW MEMORY 5

Function: Selects the registration method for the contest memory keyer "CW MEMORY 5".

Available Values: TEXT/MESSAGE

Default Setting: TEXT

Description: Selects how to register text to the contest memory keyer "CW MEMORY 5".

- TEXT: Use optional **FH-2** or the touch panel to enter text (page 89).
- MESSAGE: Use the keyer to register text to the contest memory keyer (page 86).

023 NB WIDTH

Function: Sets the duration of the noise blanking pulse to match various types of noise compatible with the noise blanker function.

Available Values: 1msec/3msec/10msec

Default Setting: 3msec

Description: Reduces long duration noise as well as pulse noise by changing the setting.

024 NB REJECTION

Function: Selects the level of noise attenuation. Available Values: 10dB/30dB/50dB Default Setting: 30dB

025 NB LEVEL

Function: Sets the noise blanker level.

Available Values: 0 - 10

Default Setting: 5

Description: Sets the noise blanker level to reduce pulse noise such as noise caused by automotive ignition systems. The higher the setting, the higher the noise blanker level becomes.

026 BEEP LEVEL

Function: Sets the beep level.

Available Values: 0 - 100

Default Setting: 50

Description: Sets the beep sound volume level. The higher the setting, the louder the sound becomes.

027 TIME ZONE

Function: Sets the time zone. Available Values: -12:00 - 0:00 - +14:00

Default Setting: 0:00

Description: Sets the time difference with respect to the UTC (Coordinated Universal Time) in 30 minute increments.

028 GPS/232C SELECT

Function: Selects functions of the **GPS/CAT** jack. Available Values: GPS1/GPS2/RS232C Default Setting: GPS1

Description: Select the device that is to be connected to the **GPS/CAT** jack on the rear panel.

- GPS1: Enables connection to an external GPS device.
- GPS2: Enables connection to an external GPS device, and displays the location information in real time.
- RS232C: Enables connection for input of CAT commands.

029 232C RATE

Function: Sets the baud rate for a **GPS/CAT** jack command input.

Available Values: 4800/9600/19200/38400 bps

Default Setting: 4800 bps

Description: Sets the baud rate for an **RS-232C** command input.

030 232C TOT

Function: Sets the Time-Out Timer for an **RS-232C** command input. Available Values: 10/100/1000/3000 (msec)

Default Setting: 10msec

Description: Sets the Time-Out Timer countdown time for a **RS-232C** command input.

031 CAT RATE

Function: Sets the baud rate for a CAT command input. Available Values: 4800/9600/19200/38400 bps Default Setting: 4800 bps Description: Sets the baud rate for a CAT command input.

032 CAT TOT

Function: Sets the Time-Out Timer for a CAT command input.
Available Values: 10/100/1000/3000 (msec)
Default Setting: 10msec
Description: Sets the Time-Out Timer countdown time for a CAT command input.

033 CAT RTS

Function: Configures the CAT RTS port setting. Available Values: ENABLE/DISABLE Default Setting: ENABLE Description: Monitors the computer using the RTS signal. ENABLE: Monitors the computer status using the RTS signal.

DISABLE: Disables the monitoring function.

034 MEM GROUP

Function: Sets the memory group function.Available Values: ENABLE/DISABLEDefault Setting: DISABLEDescription: Set this setting to "ENABLE" to divide the memory channels into 6 groups.

035 QUICK SPLIT FREQ

Function: Selects the amount of frequency offset when the Quick Split feature is enabled.

Available Values: -20 - 0 - 20kHz (1kHz/step)

Default Setting: 5kHz

Description: Sets the amount of frequency offset when the Quick Split feature is enabled.

Advice: Press and hold the **SPLIT** button on the front panel to activate VFO-B split frequency operation, thereby offsetting the transmitter by the specified frequency.

Each time the **SPLIT** button is pressed and held, the offset frequency is increased by the setting amount.

036 TX TOT

Function: Sets the Time-Out Timer countdown time. Available Values: OFF/1 - 30min

Default Setting: OFF (10 min, European Version)

Description: When the time-out timer function is active, a beep is emitted when a continuous transmission nears the set time. About 10 seconds later, forces the transceiver returns to the receiving mode.

037 MIC SCAN

Function: Sets the microphone automatic scanning function to ON or OFF.

Available Values: ENABLE/DISABLE

Default Setting: ENABLE

Description: Selects the operation of the **UP/DWN** buttons on the microphone.

ENABLE (ON):

Starts scanning automatically by pressing and holding the **UP/DWN** button for 1 second or more (Scanning continues even after releasing the button). To stop scanning, press the **UP/DWN** button again briefly or press the **PTT** button to transmit.

DISABLE (OFF):

Scans only while pressing and holding the **UP**/**DWN** button. To stop scanning, release the button.

038 MIC SCAN RESUME

Function: Sets the Scan Resume function.

Available Values: PAUSE/TIME

Default Setting: TIME

- Description: Sets the Scan Resume function (in AM/FM mode).
 - PAUSE: During automatic scanning, the scanner will hold until the signal disappears.
 - TIME: If the signal does not disappear within five seconds, the scanner will resume scanning for the next active channel (frequency). If there is no signal, the scanner continues scanning automatically.

039 REF FREQ ADJ

Function: Adjusts the reference oscillator. Available Values: -25 - 0 - 25

Default Setting: 0

Description: The frequency may be calibrated when connecting a frequency counter to the transceiver, or when receiving a standard frequency such as WWV or WWVH.

040 CLAR MODE SELECT

Function: Selects the clarifier operation.

Available Values: RX/TX/TRX

Default Setting: RX

Description: Selects the clarifier operation when the **CLAR** button is pressed.

- RX: Functions as the RX clarifier which changes only the receiver frequency without changing transmit frequency.
- TX: Functions as the TX clarifier which changes only the transmit frequency without changing the receiver frequency.
- TRX: Functions as the TRX clarifier which changes the transmit frequency and the receiver frequency simultaneously.

041 AM LCUT FREQ

Function: Sets the low-frequency cutoff audio filter in AM mode.

Available Values: OFF/100Hz - 1000Hz (50Hz/step) Default Setting: OFF

Description: This is the low-frequency cutoff audio filter in AM mode.

The cutoff frequency can be set at 50 Hz increments between 100 Hz and 1000 Hz.

042 AM LCUT SLOPE

Function: Sets the slope of the low-frequency cutoff audio filter in AM mode.

Available Values: 6dB/oct / 18dB/oct

Default Setting: 6dB/oct

Description: Selects the slope of the low-frequency cutoff audio filter in AM mode.

043 AM HCUT FREQ

Function: Sets the high-frequency cutoff audio filter in AM mode.

Available Values: OFF/700Hz - 4000Hz (50Hz/step) Default Setting: OFF

Description: This is the high-frequency cutoff audio filter in AM mode.

The cutoff frequency can be set at 50 Hz increments between 700 Hz and 4000 Hz.

044 AM HCUT SLOPE

Function: Sets the slope of the high-frequency cutoff audio filter in AM mode.

Available Values: 6dB/oct / 18dB/oct

Default Setting: 6dB/oct

Description: Selects the slope of the high-frequency cutoff audio filter in AM mode.

045 AM MIC SELECT

Function: Selects the microphone input jack for AM mode.

Available Values: MIC/REAR

Default Setting: MIC

- Description: Selects the microphone input jack to be used in AM mode.
 - MIC: Audio is input from the **MIC** jack on the front panel.
 - REAR: Disables the microphone circuit on the front panel and inputs audio/data from the **USB** jack or **RTTY/DATA** jack on the rear panel.

046 AM OUT LEVEL

Function: Sets the level of the receive AM signal output from the **RTTY/DATA** jack.

Available Values: 0 - 100

Default Setting: 50

047 AM PTT SELECT

Function: Sets the PTT control for the AM transmit signal.

Available Values: DAKY/RTS/DTR

Default Setting: DAKY

Description: Selects the PTT control method for the AM transmit.

- DAKY: Controls the AM transmit signal from the **RTTY/DATA** jack (pin 3) on the rear panel.
- DTR: Controls the AM transmit signal from the USB virtual COM/DTR ports.
- RTS: Controls the AM transmit signal from the USB virtual COM/RTS ports.

048 AM PORT SELECT

Function: Selects the input jack of the AM signal.

Available Values: DATA/USB

Default Setting: DATA

- Description: Selects the input jack of the AM signal when "045 AM MIC SELECT" is set to "DATA".
 - DATA: Inputs from the **RTTY/DATA** jack on the rear panel.
 - USB: Inputs from the **USB** jack on the rear panel.

049 AM DATA GAIN

Function: Sets the level of the AM signal input when "045 AM MIC SELECT" is set to "DATA".

Available Values: 0 - 100

Default Setting: 50

050 CW LCUT FREQ

Function: Sets the low-frequency cutoff audio filter in CW mode.

Available Values: OFF/100Hz - 1000Hz (50Hz/step)

Default Setting: 250Hz

Description: This is the low-frequency cutoff audio filter in CW mode.

The cutoff frequency can be set at 50 Hz increments between 100 Hz and 1000 Hz.

051 CW LCUT SLOPE

Function: Sets the slope of the low-frequency cutoff audio filter in CW mode.

Available Values: 6dB/oct / 18dB/oct

Default Setting: 18dB/oct

Description: Selects the slope of the low-frequency cutoff audio filter in CW mode.

052 CW HCUT FREQ

Function: Sets the high-frequency cutoff audio filter in CW mode.
Available Values: OFF/700Hz - 4000Hz (50Hz/step)
Default Setting: 1200Hz
Description: This is the high-frequency cutoff audio filter in CW mode.
The cutoff frequency can be set at 50 Hz increments between 700 Hz and 4000 Hz.

053 CW HCUT SLOPE

Function: Sets the slope of the high-frequency cutoff audio filter in CW mode. Available Values: 6dB/oct / 18dB/oct Default Setting: 18dB/oct Description: Selects the slope of the high-frequency cutoff audio filter in CW mode.

054 CW OUT LEVEL

Function: Sets the level of the CW signal output from the **RTTY/DATA** jack. Available Values: 0 - 100

Default Setting: 50

055 CW AUTO MODE

Function: Enables/disables CW keying while operating on SSB. Available Values: OFF/50M (50MHz)/ON Default Setting: OFF Description: OFF: Disables CW keying while operating on SSB.

- 50M: Enables CW keying while operating SSB on 50 MHz (but not HF).
- ON: Enables CW keying while operating SSB on all TX bands.

056 CW BK-IN TYPE

Function: Sets the CW brake-in function.

Available Values: SEMI/FULL

Default Setting: SEMI

Description: Selects the CW brake-in function.

SEMI: A brief delay is provided after the CW keying operation, before the transceiver returns to receive mode.

The receiver recovery time may be changed using MENU "057 CW BK-IN DELAY".

FULL: The transceiver immediately returns to receive mode after every CW key-up (QSK mode).

057 CW BK-IN DELAY

Function: Sets the CW delay time.

Available Values: 30msec - 3000msec (10msec/step) Default Setting: 200msec

Description: In semi break-in mode, this setting determines the delay time before returning to receive mode after the CW keying operation. The delay time can be changed in 10 msec steps between 30 msec and 3000 msec.

058 CW WAVE SHAPE

Function: Selects the CW carrier wave-form shape (rise/ fall times).

Available Values: 2ms/4ms

Default Setting: 4ms (msec)

Description: Sets the rise and fall times of the keying envelope in CW mode (transmit waveform).

059 CW FREQ DISPLAY

Function: Sets the PITCH frequency offset. Available Values: DIRECT FREQ/PITCH OFFSET Default Setting: PITCH OFFSET Description: Sets the displayed frequency offset when switching the transceiver mode between SSB and CW.

DIRECT FREQ:

Displays the same frequency in CW mode as in SSB mode without any offset added. PITCH OFFSET:

Displays the frequency in CW mode with the pitch offset added. When CW BFO is set to USB, the displayed frequency will be increased and when CW BFO is set to LSB, the displayed frequency will be decreased with pitch offset added.

060 PC KEYING

Function: Sets the **RTTY/DATA** jack for keying.

Available Values: OFF/DAKY/RTS/DTR

Default Setting: OFF

Description:

- OFF: Disables keying from DATA PTT (pin 3) of the **RTTY/DATA** jack.
- DAKY: Controls the transmit from the **RTTY**/ **DATA** jack (pin 3) on the rear panel.
- RTS: Controls the transmit from the USB virtual COM/RTS ports.
- DTR: Controls the transmit from the USB virtual COM/DTR ports.

061 QSK DELAY TIME

Function: Sets the time delay before transmitting the keying signal.

Available Values: 15/20/25/30msec

Default Setting: 15msec

Description: The delay time in QSK mode before transmitting the CW signal may be set in 5 msec steps.

062 DATA MODE

Function: Selects the operating scheme in DATA mode. Available Values: PSK/OTHERS Default Setting: PSK Description: Selects the operating scheme (PSK or OTHERS) in DATA mode.

063 PSK TONE

Function: Set the PSK tone. Available Values: 1000/1500/2000Hz Default Setting: 1000Hz Description: Selects the PSK tone frequency.

064 OTHER DISP (SSB)

Function: Sets the displayed frequency offset in DATA mode.

Available Values: -3000 - 0 - 3000Hz (10Hz/step) Default: 0Hz

Description: Sets the displayed frequency offset in DATA mode. The frequency can be set in steps of 10 Hz.

065 OTHER SHIFT (SSB)

Function: Sets the carrier point in DATA mode. Available Values: -3000 - 0 - 3000Hz (10Hz/step) Default: 0Hz

Description: Sets the carrier point in DATA mode. The frequency can be set in steps of 10 Hz.

066 DATA LCUT FREQ

Function: Sets the low-frequency cutoff audio filter in DATA mode.

Available Values: OFF/100Hz - 1000Hz (50Hz/step) Default Setting: 300Hz

Description: This is the low-frequency cutoff audio filter in DATA mode.

The cutoff frequency can be set at 50 Hz increments between 100 Hz and 1000 Hz.

067 DATA LCUT SLOPE

Function: Sets the slope of the low-frequency cutoff audio filter in DATA mode.

Available Values: 6dB/oct / 18dB/oct

Default Setting: 18dB/oct

Description: Selects the slope setting of the low-frequency cutoff audio filter in DATA mode.

068 DATA HCUT FREQ

Function: Sets the high-frequency cutoff audio filter in DATA mode.

Available Values: OFF/700Hz - 4000Hz (50Hz/step)

Default Setting: 3000Hz

Description: This is the high-frequency cutoff audio filter in DATA mode.

The cutoff frequency can be set at 50 Hz increments between 700 Hz and 4000 Hz.

069 DATA HCUT SLOPE

Function: Sets the slope of the high-frequency cutoff audio filter in DATA mode.

Available Values: 6dB/oct / 18dB/oct

Default Setting: 18dB/oct

Description: Selects the slope setting of the high-frequency cutoff audio filter in DATA mode.

070 DATA IN SELECT

Function: Selects the input jack for DATA mode.

Available Values: MIC/REAR

Default Setting: REAR

- Description: Selects the input jack to be used in DATA mode.
 - MIC: Inputs signals from the **MIC** jack on the front panel.
 - REAR: Inputs signals from the **USB** jack or **RTTY/DATA** jack on the rear panel.

071 DATA PTT SELECT

Function: Sets the PTT control during the sending/receiving of data.

Available Values: DAKY/RTS/DTR

Default Setting: DAKY

- Description: Selects the PTT control method during the sending/receiving of data.
 - DAKY: Controls the transmit from the **RTTY**/ **DATA** jack (pin 3) on the rear panel.
 - DTR: Controls the transmit from the USB virtual COM/DTR ports.
 - RTS: Controls the transmit from the USB virtual COM/RTS ports.

072 DATA PORT SELECT

Function: Selects the input jack of the data signal. Available Values: DATA/USB

Default Setting: DATA

Description: Selects the input jack of the data signal when "070 DATA IN SELECT" is set to "REAR".

- DATA: Inputs the data from the **RTTY/DATA** jack on the rear panel.
- USB: Inputs the data from the **USB** jack on the rear panel.

073 DATA OUT LEVEL

Function: Sets the output level during the sending/receiving of data (PSK31, SSTV, etc.).

Available Values: 0 - 100

Default Setting: 50

Description: Sets the output level during the sending/ receiving of data (PSK31, SSTV, etc.). The higher the setting, the higher the output level becomes.

074 FM MIC SELECT

Function: Selects the microphone input jack for FM mode.

Available Values: MIC/REAR

Default Setting: MIC

- Description: Selects the microphone input jack to be used in FM mode.
 - MIC: Inputs from the **MIC** jack on the front panel.
 - REAR: Disables the microphone circuit on the front panel and inputs from the **USB** jack or **RTTY/DATA** jack on the rear panel.

075 FM OUT LEVEL

Function: Sets the level of the FM receiving signal output from the **RTTY/DATA** jack.

Available Values: 0 - 100 Default Setting: 50

076 FM PKT PTT SELECT

Function: Sets the PTT control for the FM signal. Available Values: DAKY/RTS/DTR

Default Setting: DAKY

Description: Selects the PTT control method for the FM signal.

- DAKY: Controls the transmit from the **RTTY**/ **DATA** jack (pin 3) on the rear panel.
- DTR: Controls the transmit from the USB virtual COM/DTR ports.
- RTS: Controls the transmit from the USB virtual COM/RTS ports.

077 FM PKT PORT SELECT

Function: Selects the input jack of the FM packet signal. Available Values: DATA/USB

Default Setting: DATA

- Description: Selects the input jack of the FM signal when "074 FM MIC SELECT" is set to "DATA".
 - DATA:Inputs from the **RTTY/DATA** jack on the rear panel.

USB: Inputs from the **USB** jack on the rear panel.

078 FM PKT TX GAIN

Function: Sets the transmission gain during the FM packet operation.

Available Values: 0 - 100

Default Setting: 50

079 FM PKT MODE

Function: Sets the baud rate (communication speed) during the FM packet operation. Available Values: 1200/9600 Default Setting: 1200

080 RPT SHIFT 28MHz

Function: Sets the RPT offset frequency on the 28 MHz band. Available Values: 0 - 1000kHz (10kHz/step) Default Setting: 100kHz

Description: Sets the repeater offset frequency on the 28 MHz band.

081 RPT SHIFT 50MHz

Function: Sets the RPT offset frequency on the 50 MHz band.

Available Values: 0 - 4000kHz (10kHz/step)

Default Setting: 1000kHz

Description: Sets the repeater offset frequency on the 50 MHz band.

082 RPT SHIFT 144MHz

Function: Sets the RPT offset frequency on the 144 MHz band.

Available Values: 0 - 4000kHz (10kHz/step)

Default Setting: 600kHz

Description: Sets the repeater offset frequency on the 144 MHz band.

083 RPT SHIFT 430MHz

Function: Sets the RPT offset frequency on the 430 MHz band.

Available Values: 0 - 10000kHz (10kHz/step)

Default Setting: 5000kHz

Description: Sets the repeater offset frequency on the 430 MHz band.

084 ARS 144MHz

Function: Sets the ARS function on the 144 MHz band. Available Values: OFF/ON Default Setting: ON Description:

> OFF: Disables the ARS function. ON: Enables the ARS function.

085 ARS 430MHz

Function: Sets the ARS function on the 430 MHz band. Available Values: OFF/ON Default Setting: ON Description:

OFF: Disables the ARS function. ON: Enables the ARS function.

086 DCS POLARITY

Function: Selects the DCS code polarity. Available Values: Tn-Rn/Tn-Riv/Tiv-Rn/Tiv-Riv

Default Setting: Tn-Rn

- Description: When using the DCS function, the transceiver can transmit/receive the DCS code with the phase reversed.
 - Tn-Rn: Transmit (in phase), receive (in phase)
 - Tn-Riv: Transmit (in phase), receive (reverse phase)
 - Tiv-Rn: Transmit (reverse phase), receive (in phase)
 - Tiv-Riv: Transmit (reverse phase), receive (reverse phase)

087 RADIO ID

Function: Displays the unique transceiver ID assigned at the time of shipment (5-digit alphanumeric characters).

Available Values: Cannot be changed.

Default Setting: Differs depending on the transceiver.

088 GM DISPLAY

Function: Sorts the group stations to be displayed when using the GM function.

Available Values: DISTANCE/STRENGTH Default Setting: DISTANCE

Description:

DISTANCE:

Active group member stations are displayed according to their distance from this station, beginning with the closest member station.

STRENGTH:

Active group member stations are displayed according to their signal strengths, beginning with the strongest signal first.

089 DISTANCE

Function: Sets the unit of measure to indicate the distance between your station and communication stations when using the GM function.

Available Values: km/mile

Default Setting: mile

090 AMS TX MODE

Function: Sets the operation of the AMS function.

Available Values: AUTO/MANUAL/DN/VW/ANALOG Default Setting: AUTO

- Description: When using the AMS (AUTO) function, the transceiver selects one of the three transmission modes automatically according to the received signal.
 - AUTO: Selects one of the transmission modes automatically according to the received signal.
 - MANUAL: By briefly pressing the **PTT** switch, the operating mode may be switched between digital and analog mode.
 - DN: Transmits in DN mode.
 - VW: Transmits in VW mode.
 - ANALOG: Transmits in FM mode (analog).

091 STANDBY BEEP

Function: Sets the Standby Beep function for digital communications.

Available Values: OFF/ON

Default Setting: ON

Description: During a digital communication, an audible beep sounds to indicate that the contact station has completed a transmission (Standby Beep function).

092 RTTY LCUT FREQ

Function: Sets the low-frequency cutoff audio filter in RTTY mode.

Available Values: OFF/100Hz - 1000Hz (50Hz/step)

Default Setting: 300Hz

Description: This is the low-frequency cutoff audio filter in RTTY mode.

The cutoff frequency can be set at 50 Hz increments between 100 Hz and 1000 Hz.

093 RTTY LCUT SLOPE

Function: Sets the slope of the low-frequency cutoff audio filter in RTTY mode.

Available Values: 6dB/oct / 18dB/oct

Default Setting: 18dB/oct

Description: Selects the slope setting of the low-frequency cutoff audio filter in RTTY mode.

094 RTTY HCUT FREQ

Function: Sets the high-frequency cutoff audio filter in RTTY mode.

Available Values: OFF/700Hz - 4000Hz (50Hz/step)

Default Setting: 3000Hz

Description: This is the high-frequency cutoff audio filter in RTTY mode.

The cutoff frequency can be set at 50 Hz increments between 700 Hz and 4000 Hz.

095 RTTY HCUT SLOPE

Function: Sets the slope of the high-frequency cutoff audio filter in RTTY mode.

Available Values: 6dB/oct / 18dB/oct

Default Setting: 18dB/oct

Description: Selects the slope setting of the high-frequency cutoff audio filter in RTTY mode.

096 RTTY SHIFT PORT

Function: Sets the SHIFT input jack for RTTY mode. Available Values: SHIFT/DTR/RTS Default Setting: SHIFT

Description: Selects the SHIFT input jack for RTTY mode.

- SHIFT: Inputs from the **RTTY/DATA** jack (pin 4) on the rear panel.
- DTR: Controls the signal from the USB virtual COM/DTR ports.
- RTS: Controls the signal from the USB virtual COM/RTS ports.

097 RTTY POLARITY-RX

Function: Sets the shift direction for receiving in RTTY mode.

Available Values: NOR/REV

Default Setting: NOR

Description: Sets the shift direction for receiving in RTTY mode.

- NOR: The space frequency will be lower than the mark frequency.
- REV: The mark frequency will be lower than the space frequency.

098 RTTY POLARITY-TX

Function: Sets the shift direction for transmitting in RTTY mode.

Available Values: NOR/REV

Default Setting: NOR

Description: Sets the shift direction for transmitting in RTTY mode.

- NOR: The space frequency will be lower than the mark frequency.
- REV: The mark frequency will be lower than the space frequency.

099 RTTY OUT LEVEL

Function: Sets the output level during the sending/receiving of data in RTTY mode.

Available Values: 0 - 100

Default Setting: 50

Description: Sets the data output level during the sending/receiving of data in RTTY mode. The higher the setting, the higher the output level becomes.

100 RTTY SHIFT FREQ

Function: Sets the shift width for RTTY mode. Available Values: 170/200/425/850 (Hz) Default Setting: 170Hz Description: Sets the shift width for RTTY mode.

101 RTTY MARK FREQ

Function: Sets the mark frequency for RTTY mode. Available Values: 1275/2125 (Hz) Default Setting: 2125Hz Description: Sets the mark frequency for RTTY mode.

102 SSB LCUT FREQ

Function: Sets the low-frequency cutoff audio filter in SSB mode.

Available Values: OFF/100Hz - 1000Hz (50Hz/step) Default Setting: 100Hz

Description: This is the low-frequency cutoff audio filter in SSB mode.

The cutoff frequency can be set at 50 Hz increments between 100 Hz and 1000 Hz.

103 SSB LCUT SLOPE

Function: Sets the slope of the low-frequency cutoff audio filter in SSB mode.

Available Values: 6dB/oct / 18dB/oct

Default Setting: 6dB/oct

Description: Selects the slope setting of the low-frequency cutoff audio filter in SSB mode.

104 SSB HCUT FREQ

Function: Sets the high-frequency cutoff audio filter in SSB mode.

Available Values: OFF/700Hz - 4000Hz (50Hz/step) Default Setting: 3000Hz

Description: This is the high-frequency cutoff audio filter in SSB mode. The cutoff frequency can be set at 50 Hz

increments between 700 Hz and 4000 Hz.

105 SSB HCUT SLOPE

Function: Sets the slope of the high-frequency cutoff audio filter in SSB mode.

Available Values: 6dB/oct / 18dB/oct

Default Setting: 6dB/oct

Description: Selects the slope setting of the high-frequency cutoff audio filter in SSB mode.

106 SSB MIC SELECT

Function: Selects the microphone input jack for SSB mode.

Available Values: MIC/REAR

Default Setting: MIC

- Description: Selects the microphone input jack to be used in SSB mode.
 - MIC: Inputs from the **MIC** jack on the front panel.
 - REAR: Disables the microphone circuit on the front panel and inputs from the **USB** jack or **RTTY/DATA** jack on the rear panel.

107 SSB OUT LEVEL

Function: Sets the level of the SSB receiving signal out-

put from the **RTTY/DATA** jack.

Available Values: 0 - 100 Default Setting: 50

108 SSB PTT SELECT

Function: Sets the PTT transmit control for the SSB signal.

Available Values: DAKY/RTS/DTR

Default Setting: DAKY

Description: Selects the PTT transmit control method for the SSB signal.

- DAKY: Controls the transmit signal from the **RTTY/DATA** jack (pin 3) on the rear panel.
- DTR: Controls the transmit signal from the USB virtual COM/DTR ports.
- RTS: Controls the transmit signal from the USB virtual COM/RTS ports.

109 SSB PORT SELECT

Function: Sets the input jack of the SSB signal.

Available Values: DATA/USB

Default Setting: DATA

Description: Selects the input jack of the SSB signal when "106 SSB MIC SELECT" is set to "DATA".

DATA:Inputs from the **RTTY/DATA** jack on the rear panel.

USB: Inputs from the **USB** jack on the rear panel.

110 SSB TX BPF

Function: Sets the frequency characteristics of the DSP band-pass filter for transmitting in SSB mode.

Available Values: 100-3000/100-2900/200-2800/300-2700/400-2600

Default Setting: 300-2700Hz

Description: Selects the frequency characteristics setting of the DSP band-pass filter when transmitting in SSB mode.

111 APF WIDTH

Function: Sets the bandwidth of the audio peak filter. Available Values: NARROW/MEDIUM/WIDE Default Setting: MEDIUM

Description: In CW mode the APF peak center frequency is set according to the CW PITCH frequency and the chosen APF bandwidth value. In order to listen to the desired signal comfortably, select one of the three bandwidths of the peak filter.

112 CONTOUR LEVEL

Function: Adjusts the GAIN of the CONTOUR circuit. Available Values: -40 - 0 - 20

Default Setting: -15

Description: Sets level of the attenuation or the gain of the CONTOUR circuit.

113 CONTOUR WIDTH

Function: Sets the bandwidth ("Q") of the CONTOUR circuit.

Available Values: 1 - 11

Default Setting: 10

Description: Sets the bandwidth (WIDTH) of the CON-TOUR circuit.

114 IF NOTCH WIDTH

Function: Sets the attenuation bandwidth characteristic of the DSP IF notch filter on the VFO-A.

Available Values: NARROW/WIDE

Default Setting: WIDE

Description: Selects the attenuation bandwidth characteristic setting of the DSP IF notch filter to "NARROW" or "WIDE".

115 SCP DISPLAY MODE

Function: Sets the scope for either the spectrum or the waterfall display.

Available Values: SPECTRUM/WATER FALL

Default Setting: SPECTRUM

Description: Selects the type of display when the scope feature activates.

SPECTRUM: Enables the spectrum display. WATER FALL: Enables the waterfall display.

116 SCP SPAN FREQ

Function: Sets the bandwidth of the spectrum scope sweeping.

Available Values: 50/100/200/500/1000 (kHz)

Default Setting: 100kHz

Description: Sets the bandwidth (SPAN) of the spectrum scope.

117 SPECTRUM COLOR

Function: Selects the color of the Spectrum Scope display.

Available Values: BLUE/GRAY/GREEN/ORANGE/ PURPLE/RED/SKY BLUE Default Setting: BLUE

118 WATER FALL COLOR

Function: Selects the color of the Water Fall display. Available Values: BLUE/GRAY/GREEN/ORANGE/ PURPLE/RED/SKY BLUE/MULTI Default Setting: MULTI

119 PRMTRC EQ1 FREQ

Function: Sets the center frequency of the low range for the 3 band parametric MIC rophone equalizer.

Available Values: 100 - 700 (Hz)/OFF (100Hz/step) Default Setting: OFF

Default Setting: OFF Description: Selects the cer

Description: Selects the center frequency setting of the low range of the 3 band parametric microphone equalizer between "100 Hz" and "700 Hz".

120 PRMTRC EQ1 LEVEL

Function: Sets the gain for the low range of the 3 band parametric microphone equalizer.

Available Values: -20 - 0 - 10 (dB)

Default Setting: 5

Description: Adjusts the gain for the low range of the 3 band parametric microphone equalizer between "-20 dB" and "+10 dB".

121 PRMTRC EQ1 BWTH

- Function: Sets the width variation ("Q") for the low range of the 3 band parametric microphone equalizer.
- Available Values: 1 10

Default Setting: 10

Description: Selects the value of the width (Q) for the low range for the 3 band parametric microphone equalizer between "1" and "10".

122 PRMTRC EQ2 FREQ

Function: Sets the center frequency for the middle range of the 3 band parametric microphone equalizer.

Available Values: 700 - 1500 (Hz)/OFF (100Hz/step) Default Setting: OFF

Description: Selects the center frequency setting for the middle range of the 3 band parametric microphone equalizer between "700 Hz" and "1500 Hz".

123 PRMTRC EQ2 LEVEL

Function: Sets the gain for the middle range of the 3 band parametric microphone equalizer.

Available Values: -20 - 0 - 10 (dB)

Default Setting: 5

Description: Selects the gain setting for the middle range of the 3 band parametric microphone equalizer between "-20 dB" and "+10 dB".

124 PRMTRC EQ2 BWTH

Function: Sets the width variation ("Q") for the middle range of the 3 band parametric microphone equalizer.

Available Values: 1 - 10

Default Setting: 10

Description: Selects the width ("Q") for the middle range of the 3 band parametric microphone equalizer between "1" and "10".

125 PRMTRC EQ3 FREQ

Function: Sets the center frequency for the high range of the 3 band parametric microphone equalizer.

Available Values: 1500 - 3200 (Hz)/OFF (100Hz/step) Default Setting: OFF

Description: Selects the center frequency setting for the high range of the 3 band parametric microphone equalizer between "1500 Hz" and "3200 Hz".

126 PRMTRC EQ3 LEVEL

Function: Sets the gain for the high range of the 3 band parametric microphone equalizer.

Available Values: -20 - 0 - 10 (dB)

Default Setting: 5

Description: Selects the gain setting for the high range of the 3 band parametric microphone equalizer between "-20 dB" and "+10 dB".

127 PRMTRC EQ3 BWTH

Function: Selects the width setting ("Q") for the high range of the 3 band parametric microphone equalizer.

Available Values: 1 - 10

Default Setting: 10

Description: Selects the width ("Q") setting for the high range of the 3 band parametric microphone equalizer between "1" and "10".

128 P-PRMTRC EQ1 FREQ

Function: Sets the center frequency of the low range for the 3 band parametric microphone equalizer when the speech processor is activated.

Available Values: 100 - 700 (Hz)/OFF (100Hz/step)

Default Setting: 200

Description: Activates when the speech processor is "ON". Adjusts the center frequency for the low range of the 3 band parametric microphone equalizer between "100 Hz" and "700 Hz".

129 P-PRMTRC EQ1 LEVEL

Function: Selects the gain setting for the low range of the 3 band parametric microphone equalizer when the speech processor is activated.

Available Values: -20 - 0 - 10 (dB)

- Default Setting: 0
- Description: Activates when the speech processor is "ON"and sets the gain for the low range of the 3 band parametric microphone equalizer between "-20 dB" and "+10 dB".

130 P-PRMTRC EQ1 BWTH

Function: Selects the width ("Q") for the low range of the 3 band parametric microphone equalizer when the speech processor is activated.

Available Values: 1 - 10

Default Setting: 2

Description: Activates when the speech processor is "ON" and sets the width ("Q") for the low range of the 3 band parametric microphone equalizer between "1" and "10".

131 P-PRMTRC EQ2 FREQ

Function: Selects the center frequency for the middle range of the 3 band parametric microphone equalizer when the speech processor is activated.

Available Values: 700 - 1500 (Hz)/OFF (100Hz/step) Default Setting: 800

Description: Selects the center frequency for the middle range of the 3 band parametric microphone equalizer between "700 Hz" and "1500 Hz" when the speech processor is activated.

132 P-PRMTRC EQ2 LEVEL

Function: Sets the gain for the middle range of the 3 band parametric microphone equalizer when the speech processor is activated.

Available Values: -20 - 0 - 10 (dB)

Default Setting: 0

Description: Selects the gain setting for the middle range of the 3 band parametric microphone equalizer between "-20 dB" and "+10 dB" when the speech processor is activated.

133 P-PRMTRC EQ2 BWTH

Function: Sets the width ("Q") for the middle range of the 3 band parametric microphone equalizer when the speech processor is activated.

Available Values: 1 - 10

Default Setting: 1

Description: Activates when the speech processor is "ON", and selects the width ("Q") setting for the middle range of the 3 band parametric microphone equalizer between "1" and "10".

134 P-PRMTRC EQ3 FREQ

Function: Sets the center frequency for the high range of the 3 band parametric microphone equalizer when the speech processor is activated.

Available Values: 1500 - 3200 (Hz)/OFF (100Hz/step) Default Setting: 2100

Description: Activates when the speech processor is "ON", and selects the center frequency setting for the high range of the 3 band parametric microphone equalizer between "1500 Hz" and "3200 Hz".

135 P-PRMTRC EQ3 LEVEL

Function: Sets the gain for the high range of the 3 band parametric microphone equalizer when the speech processor is activated.

Available Values: -20 - 0 - 10 (dB)

Default Setting: 0

Description: Activates when the speech processor is "ON", and selects the gain setting for the high range of the 3 band parametric microphone equalizer between "-20 dB" and "+10 dB".

136 P-PRMTRC EQ3 BWTH

Function: Sets the width ("Q") for the high range of the 3 band parametric microphone equalizer when the speech processor is activated.

Available Values: 1 - 10

Default Setting: 1

Description: Activates when the speech processor is "ON", and sets the width ('Q") for the high range of the 3 band parametric microphone equalizer between "1" and "10".

137 HF TX MAX POWER

Function: Sets the transmit RF power output of the HF band.

Available Values: 5 - 100

Default Setting: 100

138 50M TX MAX POWER

Function: Sets the transmit RF power output of the 50 MHz band. Available Values: 5 - 100

Default Setting: 100

139 144 TX MAX POWER

Function: Sets the transmit RF power output of the 144 MHz band.

Available Values: 5 - 50 Default Setting: 50

140 430M TX MAX POWER

Function: Sets the transmit RF power output of the 430 MHz band.

Available Values: 5 - 50 Default Setting: 50

141 TUNER SELECT

Function: Sets the functions of the antenna tuner.

Available Values: OFF/INTERNAL/EXTERNAL/ ATAS/LAMP

Default Setting: INTERNAL

Description: Selects the antenna tuner to be used or sets the connections for a linear amplifier.

- INTERNAL: Select this item when using the internal antenna tuner.
- EXTERNAL: Select this item when using the external antenna tuner (the optional **FC-40**, etc.).
- ATAS: Select this item when using the active tuning antenna system **ATAS-120A**.
- LAMP: Select this item when connecting the linear amplifier to the **TUN/LIN** jack on the rear panel.
- OFF: Select this item when not using the antenna tuner or the linear amplifier.

142 VOX SELECT

Function: Selects the function of the VOX operation. Available Values: MIC/DATA Default Setting: MIC

Default Setting: MIC

- Description: Selects the function of the VOX operation. MIC: Operates via input from the **MIC** jack (mi
 - crophone). DATA: Operates via input from the **RTTY/DATA** or **USB** jack.

143 VOX GAIN

Function: Sets the VOX gain. Available Values: 0 - 100

Default Setting: 50

Description: Sets the operation sensitivity of the VOX circuit. "1" represents the minimum sensitivity and "100" represents the maximum sensitivity. The VOX operation sensitivity may be adjusted while transmitting the signal.

144 VOX DELAY

Function: Sets the VOX delay time. Available Values: 30 - 3000 msec (10 msec/step) Default Setting: 500 msec

Description: While operating VOX, the recovery time (delay time) before returning to receive mode from transmit mode may be set at 10 msec intervals. The delay time may be adjusted while transmitting the signal.

145 ANTI VOX GAIN

Function: Sets the VOX anti-trip. Available Values: 0 - 100 Default Setting: 50

Description: The sensitivity of the anti-trip circuit may be adjusted so that the VOX circuit does not accidently engage due to the sounds from the transceiver speaker. Increase the anti-trip value to the point that sounds from the transceiver speaker do not engage the transmitter while using VOX operation.

146 DATA VOX GAIN

Function: Sets the VOX GAIN while operating VOX during the sending/receiving of data (PSK31, RTTY, etc.).

Available Values: 0 - 100

Default Setting: 50

Description: Set the data input VOX gain to the point that the data signal reliably engages the transmitter, and also releases the transmit when there is no data signal.

147 DATA VOX DELAY

Function: Sets the VOX DELAY time while operating VOX during the sending/receiving of data (PSK31, RTTY, etc.).

Available Values: 30msec - 3000msec Default Setting: 100msec

148 ANTI DVOX GAIN

Function: Sets the data VOX ant-trip.

Available Values: 0 - 100

Default Setting: 0

Description: The sensitivity of the anti-trip circuit may be adjusted so that the VOX circuit does not accidently engage due to the received data while operating VOX. Increase the setting to a value that the VOX circuit does not engage due to the received data (the higher the value the greater the operation sensitivity).

149 EMERGENCY FREQ TX

Function: Enables TX/RX operation on the Alaska Emergency Channel, 5167.5kHz.

Available Values: ENABLE/DISABLE

- Default Setting: DISABLE
- Description: When this Menu Item is set to ENABLE, the spot frequency of 5167.5 kHz will be enabled. The Alaska Emergency Channel will be fount between the PMS memory channel "P-9U" and the memory channel "O1".
- **Important**: The use of this frequency is restricted to stations operating in or near Alaska, and only for emergency purposes (never for routine operations). See §97.401(c) of the FCC regulations.

150 PRT/WIRES FREQ

Function: Select the operating frequency setting method when connecting to a local node.

Available Values: MANUAL/PRESET

Default Setting: MANUAL

Description:

- MANUAL: Manually set the frequency to access the local node.
- PRESET: Access the local node by selecting a preset frequency channel.

151 PRESET FREQUENCY

Function: Presetting (registering frequency channels in advance) permits convenient connection to local nodes.

Available Values: -

Default Setting: 145.375.00/146.550.00 (USA version)

152 SEARCH SETUP

Function: To select the FAVORITE list sort criteria. Available Values: HISTORY/ACTIVITY Default Setting: HISTORY

Description:

- HISTORY: Displays the list sorted in order, beginning with the most recently connected destination station.
- ACTIVITY: Displays the list sorted in descending order, beginning with the room with the most connected nodes. Nodes are listed after rooms.

153 WIRES DG-ID

Function: Setting the DG-ID number for WIRES-X.

Available Values: AUTO/01 to 99

Default Setting: AUTO

Description:

- AUTO: May connect to the node station available in your area.
- 01 to 99: May connect to the node station whose DG-ID matches.
FC-40 External Automatic Antenna Tuner (for Wire Antenna)

The **FC-40** makes use of the control circuitry built into the transceiver, which allows the operator to control and monitor automatic operation of the **FC-40**, which mounts near the antenna feedpoint. The **FC-40** uses specially selected, thermally stable components, and is housed in a waterproof case to withstand severe environmental conditions with high reliability.

A carefully-chosen combination of solid-state switching components and high-speed relays allows the **FC-40** to match a wide variety of antennas to within a 2:1 SWR on any amateur band frequency (160 through 6 meters), typically in less than eight seconds. Transmitter power required for matching may be as little as 4 - 60 Watts, and matching settings are automatically stored in memory for instant recall when the same frequency range is selected later.

Please see the **FC-40** Operating Manual for detailed information.

Interconnections to FT-991A

After mounting the **FC-40**, connect the cables from the **FC-40** to the ANT and TUNER jacks on the rear panel of the **FT-991A** Transceiver.



FC-40 External Automatic Antenna Tuner (for Wire Antenna)

Setup the FT-991A

The optional **FC-40** Automatic Antenna Tuner provides automatic tuning of a coaxial line to present nominal 50-ohm impedance to the **FT-991A**'s ANT jack.

Before operation can begin, the **FT-991A** microprocessor must be setup to accommodate the **FC-40** automatic tuner. This is done using the Menu Mode:

- 1. Press the **MENU(SETUP)** button to enter the Menu mode.
- 2. Rotate the **MULTI** knob to select the Menu Item "141 TUNER SELECT".
- Touch [SELECT] on the LCD, then rotate the MULTI knob to select "EXTERNAL".



4. Touch [ENTER] on the LCD to save the new setting.



5. Press the **MENU(SETUP)** button or touch [**BACK**] on the LCD to exit to normal operation.

Operation

- 1. Press the **TUNE** button briefly to activate the Automatic Antenna Tuner.
- 2. The "**TUNER**" icon will appear in the TFT display.
- 3. Press and hold the **TUNE** button for one second to begin automatic tuning. The transmitter will be engaged, and the "**TUNER**" icon will blink while tuning is in progress.
- Tuning will stop automatically when a low SWR is achieved. You may Press the **TUNE** button while tuning is in progress, to cancel the automatic tuning.
- To disable the Automatic Antenna Tuner, press the TUNE button briefly again.



NOTE:

- □ Be sure to connect a good earth ground to the GND terminal of the **FC-40**.
- The carrier signal transmits continuously while tuning is in progress. Please monitor the operating frequency before beginning the tuning process. Be sure you are not interfering with others who may already be using the frequency.
- □ It is normal to hear the sound of the relays while tuning is in progress.
- □ If the impedance cannot be matched by the **FC-40** better than 2:1, and the "**HI-SWR**" icon blinks, the microprocessor will not retain the tuning data for that frequency, as the **FC-40** presumes that you will want to adjust or repair your antenna system to correct the high SWR condition.

ACTIVE-TUNING ANTENNA SYSTEM (ATAS-120A) OPERATION

ATAS-120A is a multi-band auto-tuning antenna that can be used in the amateur bands from the HF band to the UHF band (7/14/21/28(29)/50/144/430)

Using the active tuning mechanism, tuning can be carried out automatically by the control signal from **FT-991A**. Please refer to the **ATAS-120A** Operating Manual for the assembly and installation of **ATAS-120A**.

Interconnections to FT-991A

Connect "ATAS-120A" to the ANT terminal of FT-991A with a coaxial cable as shown in the diagram below.

ADVICE:

- □ Turn off the external power supply switch and the **FT-991A** power supply switch first before connecting the cables.
- Grounding is required for the **ATAS-120A**. Make sure the antenna base is in contact with the car body to ensure proper grounding.

NOTE:

- Do not plug or unplug the connector of the antenna cable with wet hands. Do not plug or unplug the connector during transmission as well. This may result in electric shock, injury, etc.
- ☐ The unit cannot be used with both the antenna tuner and **ATAS-120A** connected.



ATAS-120A connection example

ACTIVE-TUNING ANTENNA SYSTEM (ATAS-120A) OPERATION

Settings Before Operating the Tuner

- 1. Press the **MENU(SETUP)** button to enter the Menu mode.
- 2. Rotate the **MULTI** knob to select the Menu item "141 TUNER SELECT".
- Touch [SELECT] on the LCD, then rotate the MULTI knob to set this Menu item to "ATAS". The "ATAS" icon will appear in the display.



4. Touch [ENTER] on the LCD to save the new setting.



5. Press the **MENU(SETUP)** button or touch [**BACK**] on the LCD to exit to normal operation.

Tuning Operation

The tuning of the **ATAS-120A** is carried out automatically.

1. Press the **TUNE** button to begin automatic tuning. The transmitter will be engaged, and the "**ATAS**" icon will blink while tuning is in progress.

Press the **TUNE** button to stop the tuning in the middle of the process.

Note:

- □ Check the grounding and installation conditions if "**HI-SWR**" is flashing (tuning cannot be carried out).
- □ As transmit signals are emitted during tuning, take note not to interfere with any communication that is already in progress on the frequency.



Manual Tuning

Carry out the tuning of the **ATAS-120A** manually.

Press the **PTT** switch on the microphone to transmit and then press the **UP/DWN** button on the microphone to adjust the antenna until the meter indicates the minimum SWR.

The meter on the screen will automatically change to a SWR meter.

MOUNTING BRACKET MMB-90 INSTALLATION

MMB-90 is a mobile bracket used to mount the FT-991A series in an automotive vehicle.

Installation Procedure

1. Use the enclosed double-sided tape to temporarily mount the bracket at the installation location and then fasten the bracket securely with the enclosed screws so that it does not loosen or detach due to vibrations etc.

Mount the unit securely using commercial stays etc. if the installation location is weak.

If you are mounting the unit using tapping screws, pay due attention to the strength of the installation location and check that the bracket does not detach easily.

2. Use the enclosed knob screws to mount the main transceiver unit to **MMB-90**.

NOTE:

To install the **MMB-90**, before commencing work, first use the following points as a guide to find a suitable installation location that will allow the transceiver to be easily operated.

- Please choose a location that will not affect the operation of the air bag system for cars equipped with air bags.
- \Box That will not obstruct the field of view in front.
- □ That will not impede driving.
- □ That will not result in danger to the passengers in the assistant driver's seat and rear seats etc.
- \Box That is not exposed to direct sunlight and hot air etc.
- □ That is well-ventilated.

Select a flat mounting surface. If the mounting surface is not flat, the bracket may be distorted, resulting in the inability to mount the transceiver.

Be sure to use screws of the specified size to install each part according to the specified method. Malfunctions will result if screws of the wrong sizes are used, or if the unit is mounted wrongly.



The viewing angle of the transceiver may be adjusted by changing the location of the front mounting screws.



Specifications

General	
Rx Frequency Range :	30 kHz - 56 MHz, 118 MHz - 164 MHz, 420 MHz - 470 MHz (operating)
	1.8 MHz - 54 MHz, 144 MHz - 148 MHz, 430 MHz - 450 MHz (specified per-
	formance, Amateur bands only)
Tx Frequency Ranges :	1.8 MHz - 54 MHz, 144 MHz - 148 MHz, 430 MHz - 450 MHz (Amateur bands
	only)
Frequency Stability:	±0.5 ppm (after 1 minute @+14 °F to +122 °F [-10 °C to +50 °C])
Operating Temperature Range :	+14 °F to +122 °F (-10 °C to +50 °C)
Emission Modes:	A1A (CW), A3E (AM), J3E (LSB, USB), F3E (FM), F7W (C4FM), F2D
Frequency Steps:	5/10 Hz (SSB, CW, & AM), 100 Hz (FM, C4FM)
Antenna Impedance:	50 Ohms, unbalanced
	16.7 - 150 Ohms, unbalanced (Tuner ON, 1.8 MHz - 30 MHz Amateur bands)
	25 - 100 Ohms, unbalanced (Tuner ON, 50 MHz Amateur band)
Power Consumption (Approx.):	Rx (no signal) 1.8 A
	Rx (signal present) 2.2 A
	Tx 23 A (HF/50 MHz 100 W), 15 A (144/430 MHz 50 W)
Supply Voltage:	DC 13.8 V \pm 15% (Negative Ground)
Dimensions (WxHxD):	9.0" x 3.2" x 10.0" (229 x 80 x 253 mm)
Weight (Approx.):	9.5 lbs (4.3 kg)
Transmitter	
Power Output:	5 - 100 watts (2 - 25 watts AM carrier)
Modulation Types:	J3E (SSB): Balanced,
	A3E (AM): Low-Level (Early Stage),
	F3E (FM): Variable Reactance
	F7W (C4FM): 4-level FSK
Maximum FM Deviation:	±5.0 kHz/±2.5 kHz
Harmonic Radiation:	Better than -50 dB (1.8 MHz - 30 MHz Amateur bands)
	Better than -63 dB (50 MHz Amateur band)
	Better than -60 dB (144 MHz, 430 MHz Amateur bands)
SSB Carrier Suppression:	At least 50 dB below peak output
Undesired Sideband Suppression:	At least 50 dB below peak output
Bandwidth:	3 kHz (LSB/USB), 500 Hz (CW), 6 kHz (AM), 16 kHz (FM/C4FM)
Audio Response (SSB):	Not more than –6 dB from 300 to 2700 Hz
Microphone Impedance:	600 Ohms (200 to 10 kOhms)

Receiver				
Circuit Type:	SSB/CW/AM: Trip	le-conversion Super he	eterodyne	
	FM/C4FM: Double-conversion Super heterodyne			
Intermediate Frequencies:	40.455 MHz			
	SSB/CW/AM: 69.4	50 MHz/9.000 MHz/2	4 kHz	
	FM/C4FM: 69.450	MHz/450 kHz		
Sensitivity:	SSB/CW (BW: 2.4	kHz, 10 dB S+N/N)		
	0.158 μV	(1.8 - 30 MHz) (AMP	2 "ON")	
	0.125 µV	(50 - 54 MHz) (AMP	2 "ON")	
	0.11 μV (144 - 148 MHz)		
	0.11 µV (430 - 450 MHz)		
	AM (BW: 6 kHz, 1	0 dB S+N/N, 30 % mc	dulation @400 Hz)	
	5 μV (0.5	- 1.8 MHz) (AMP 2 "	ON")	
	1.6 μV (1	.8 - 30 MHz) (AMP 2	"ON")	
	1.25 μV (50 - 54 MHz) (AMP 2 "ON")			
	FM (BW: 15 kHz, 12 dB SINAD)			
	0.35 μV (28 - 30 MHz) (AMP 2 "ON")			
	0.35 μV (50 - 54 MHz) (AMP 2	"ON")	
	0.18 µV (144 - 148 MHz)			
	0.18 µV (430 - 440 MHz)			
	There is no specific	ation for frequency rai	nges not listed.	
Squelch Sensitivity (TYP.):	SSB/CW/AM 1.	0 μV (1.8 - 30 MHz, 5	50 - 54 MHz) (AMP2 "ON")	
	1.	0 μV (144 - 148 MHz	, 430 - 450 MHz)	
	FM 0.	35 μV (28 - 30 MHz, 1	50 - 54 MHz) (AMP2 "ON")	
	0.	125 μV (144 - 148 MI	Hz, 430 - 450 MHz)	
	There is no specific	ation for frequency rai	nge not listed.	
Selectivity:	Mode	6 dB	-60 dB	
	CW/RTTY/PKT	0.5 kHz or better	750 Hz or less	
	SSB	2.4 kHz or better	3.6 kHz or less	
	AM	6 kHz or better	15 kHz or less	
	FM	12 kHz or better	30 kHz or less (-50 dB)	
Image Rejection:	70 dB or better (1.8	MHz - 50 MHz Amat	eur bands)	
	60 dB or better (144	4/430 MHz Amateur b	and)	
Maximum Audio Output:	2.5 W into 4 Ohms	with 10% THD		
Audio Output Impedance:	4 to 8 Ohms (4 Ohr	ns: nominal)		
Conducted Radiation:	Less than 4 nW			

Specifications are subject to change, in the interest of technical improvement, without notice or obligation, and are guaranteed only within the amateur bands.

Symbol placed on the equipment

--- Direct current

Index

A	
A/B Button	22
A=B Button	22
About ATU Memories	64
About ATU Operation	64
About Coaxial Cable	13
About GPS Positioning	116
About the Display	24
Accessories & Options	7
Active-Tuning Antenna System (ATAS-120A)	145
Adjustable Receiver Audio Filter	60
Adjusting the Clock	10
Adjusting the Main Tuning Dial Torque	9
Adjusting the Noise Blanker Level	49
Adjusting the SSB Transmitted Bandwidth	69
AF GAIN Knob	23
AGC	59
Alaska Emergency Frequency: 5167.5 khz	112
A>M Button	23
AM Mode Transmission	61
AMS (Automatic Mode Select) Operation	40
Antenna Considerations	13
ANT Jack (144/430MHz)	27
ANT Jack (HF/50MHz)	28
ARS	95
ATAS-120A	145
ATT (Attenuator)	47
Attenuator	47
ATU Operation	63
Audio Peak Filter	58
Automatic Gain Control	59
Automatic Mode Select	40
Automatic Repeater Shift (ARS)	95
Available Options	8

B

BAND Button	21
Band Stack Operation	39
Base Station Wire Stand	. 9
Basic Operation	32
Before You Begin	. 9
-	

С

97
)5
)7
1
23
6
25
23
25
5
6
6
6
86

Contest Number Programming	87
CONTOUR Control	50
Convenient Memory functions 1	103
C.S Button	22
C.S (Custom Switch)	39
Current Mode (Modulation Form) Indicator	24
Custom Switch	39
CW Convenience Features	84
CW Delay Time Setting	85
CW Pitch Adjustment	85
CW Spotting (Zero-Beating)	84

D

DATA (PSK) Operation	122
DC IN Jack	27
DG-ID/DP-ID Features	99
Digital Group ID (DG-ID) feature	99
Digital Mode Operation	97
Digital Noise Reduction (DNR)	56
Digital NOTCH Filter (DNF)	56
Digital Personal ID (DP-ID) feature	101
DIMMER	37
Displaying the Position Information	118
DNF	56
DNR	56

Electronic Keyer	80
Enhancing Transmit Signal Quality	65
Entering the Location Information Manually	118
Erasing Memory Channel Data	107
EXT SPKR Jack	28

F

Ε

FAST Button23FAST Indicators26FC-40 External Automatic Antenna Tuner143FH-2 Remote Control Switches30F(M-LIST) Button21FM Mode Operation93Front Panel Controls & Switches20Full Reset12Full Reset (Except SETUP settings)12Function Menu25

G

General Description	1
GM Function	119
GND	. 27
GPS/CAT Jack	. 27
GPS Function	116
GPS Signal Capturing Indicator	. 25
Grounding	. 14
Н	
HI-SWR Indicator	. 24
Home Channel	105



•	
Icons	24
IF Noise Blanker (NB)	49
IF NOTCH Filter	55
IF SHIFT Operation	51
Inputting the Call Sign	11
Installation and Interconnections	16
Installation of Optional Accessories	143
Intercept Point Optimization	48
IPO (Intercept Point Optimization)	48

Keyboard Frequency Entry	44
Keyer Operating Mode	82
Keyer Weight (Dot/Dash) Ratio	81
KEY Jack	20
Key, Keyer, and Computer-Driven Keying	
Interconnections	17

Labeling Memories	106
LED Indicators	26
LOCK	37
LOCK Button	23
LOCK Indicators	26

Main Band RX/TX Indicators 2	26
Main Control Buttons (SWAP) 2	25
Main Tuning Dial Knob 2	23
Memory Channel Recall 10	04
Memory Group Assignment 11	10
Memory Groups 11	10
Memory List 2	25
Memory Mode RX/TX Indicators 2	26
Memory Operation 10	03
Memory Storage 10	04
Memory Tune 10)8
Menu List	25
Menu Mode 12	24
Menu Resetting	12
MENU(SETUP) Button	21
Message Memory	36
Message Memory Programming 8	88
Meters	25
MH-31A8J Microphone Switches 2	29
MH-36E8J Microphone Switches	31
MIC Jack	20
MMB-90 14	47
MODE Button	21
MONITOR	74
More Frequency Navigation Techniques	44
Mounting Bracket MMB-90 14	47
MULTI Knob 2	21
MULTI Knob Operations	24

Ν

NAR	54
NARROW (NAR)	54
NB	49
Noise Blanker	49
NOTCH Filter 55,	56
0	
ON/OFF Switch	20

	20
Operating Mode Indicators	24
Operation Frequency	25
Operation on 60-Meter (5 MHz) Band	35

Ρ

Parametric Microphone Equalizer	65
PHONES Jack	20
Plug/Connector Pinout Diagrams	19
PMS (Programmable Memory Scanning)	115

\mathbf{O}

QMB (Quick Memory Bank)	103
Quick Memory Bank	103

R

RCL/STO Button 2	22
Rear Panel 2	27
Recalling the Home Channel 10)5
Receiver Operation 4	6
REM/ALC Jack 2	28
Repeater Operation	94
Resetting Memories (Only) 1	2
Resetting the Microprocessor 1	2
Reversing the Keyer Polarity 8	33
RF Gain 5	57
RF GAIN Knob 2	23
RTTY/DATA Jack 2	27
RTTY (Radio Teletype) Operation 12	20
RX Indicator (Green) 2	26

S

Setting with the MULTI Knob..... 44 Setup for Straight Key 78 Specifications 148 Split Memory 109 Split Operation Using the TX Clarifier 75 Standard Memory Operation..... 104 Supplied Accessories 7 Sweep Mode..... 43

INDEX

•	
Table of Contents	. 3
TEXT Memory	89
TFT Liquid Crystal Display	24
To change the function assigned to the main control	
button	25
Toggling to the Digital Communication Mode	41
Tone Squelch Operation	96
Transmitter Convenience Features	70
TUNE Button	22
TUN/LIN Jack	27
TX Indicator (Red)	26
TXW Button	22

Т

USB Jack	28
Using the Automatic Antenna Tuner	63
Using the Built-in Electronic Keye	80

U

V VFO-B Data 25 VFO COLOR 38 VFO Scanning 113 VL-1000 Linear Amplifier Interconnections 18 V/M Button 23 Voice Memory 70 VOX 72 W WIDTH S2 VIRES-X Zero-Beating 84

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- □ Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- 1. Changes or modifications to this device not expressly approved by YAESU MUSEN could void the user's authorization to operate this device.
- 2. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions; (1) this device may not cause harmful interference, and (2) this device must accept any interference including interference that may cause undesired operation.
- 3. The scanning receiver in this equipment is incapable of tuning, or readily being altered, by the User to operate within the frequency bands allocated to the Domestic public Cellular Telecommunications Service in Part 22.

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

DECLARATION BY MANUFACTURER

The scanner receiver is not a digital scanner and is incapable of being converted or modified into a digital scanner receiver by any user.

WARNING: MODIFICATION OF THIS DEVICE TO RECEIVE CELLULAR RADIOTELEPHONE SERVICE SIGNALS IS PROHIBITED UNDER FCC RULES AND FEDERAL LAW.

CAN ICES-3 (B) / NMB-3 (B)

European Users should note that operation of this unit in Transmit mode requires the operator to have a valid Amateur Radio Licence from their respective Countries Amateur Radio Licencing Authority for the Frequencies and Transmitter Power levels that this Radio transmits on. Failure to comply may be unlawful and liable for prosecution.

EU Declaration of Conformity

We, Yaesu Musen Co. Ltd of Tokyo, Japan, hereby declare that this radio equipment FT-991A is in full compliance with EU Radio Equipment Directive 2014/53/EU. The full text of the Declaration of Conformity for this product is available to view at http://www.yaesu.com/jp/red

ATTENTION – Conditions of usage

This transceiver works on frequencies that are regulated and not permitted to be used without authorisation in the EU countries shown in this table. Users of this equipment should check with their local spectrum management authority for licensing conditions applicable for this equipment.

Disposal of Electronic and Electrical Equipment

Products with the symbol (crossed-out wheeled bin) cannot be disposed as household waste. Electronic and Electrical Equipment should be recycled at a facility capable of handling these items and their waste by-products.

Please contact a local equipment supplier representative or service center for information about the waste collection system in your country.



AT Dŀ

E

R



Copyright 2020 YAESU MUSEN CO., LTD. All rights reserved.

No portion of this manual may be reproduced without the permission of YAESU MUSEN CO., LTD.

YAESU MUSEN CO., LTD.

Tennozu Parkside Building 2-5-8 Higashi-Shinagawa, Shinagawa-ku, Tokyo 140-0002 Japan

YAESU USA 6125 Phyllis Drive, Cypress, CA 90630, U.S.A.

YAESU UK

Unit 12, Sun Valley Business Park, Winnall Close Winchester, Hampshire, SO23 0LB, U.K.

2003k-ES-1 Printed in Japan

